


VILLAIN

SERVICE MANUAL SSV SERIES PRODUCTS



Index

GENERAL INFORMATION	1-1
REGULAR MAINTENANCE	2-1
ENGINE	3-1
FRONT AND REAR AXLE	4-1
FUEL SYSTEM	5-1
COOLING SYSTEM	6-1
INTAKE SYSTEM	7–1
DRIVE CHAIN SYSTEM	8-1
FRONT AND REAR SUSPENSION	9-1
RIM AND TIRE	10-1
BRAKE SYSTEM	11-1
STEERING SYSTEM	12-1
FRAME/BODY AND TRIM	13-1
ELECTRICAL SYSTEM	14-1

SUMMARY

This manual provides information on UTV diagnosis, maintenance procedures, adjustments, and specifications for use by maintenance technicians. All materials, illustrations and product descriptions contained in this manual are in accordance with the status at the time of publication. To ensure the efficient safety of vehicles.

With quality, improve vehicle continuous research and development, this may lead to parts of the manual account do not tally with the vehicle actual situation, so the state of the vehicle body shall prevail, when in doubt it is suggested that you contact the segway dealership, mentioned the latest status of this manual or information relating to the product part number or special tools.

No part of this manual may be copied or stored in any form without the permission of Segway Technologies LTD. The above declaration applies to all texts, ICONS and forms.

- 1. This manual is provided by Segway Technology Co., Ltd. and is prepared for qualified professional and technical personnel. Attempts to repair and maintain the vehicle without proper training and without proper tools and equipment may injure the maintainer or others and may damage or disable the vehicle in normal operation.
- 2. Correct vehicle repair and maintenance is very important for the personal safety of maintenance personnel and the safe and reliable operation of motor vehicles. If a part needs to be replaced, please use the same part or the part designated by Segway.
- 3. The maintenance procedures recommended in this manual are effective methods of repair and maintenance, some of which require the use of specialized tools.

Therefore, if replacement parts, repair procedures or tools are to be used that are not approved or recommended by Segway, it must first be confirmed that there is no risk to personal safety or safe operation of the vehicle.



SEGWAY TECHNOLOGY CO., LTD.

Web: SegwayPowersports.us

TERMINOLOGY

Α	ampere(s)	lb	pounds(s)
ABDC	after bottom dead center	m	meter(s)
AC	alternating current	mm	Millimeter(s)
ATDC	after top dead center	min	minute(s)
BBDC	before bottom dead center	N	newton(s)
BDC	bottom dead center	Nm	Newton meters
BTDC	before top dead center	Pa	pascal(s)
С	degree(s) Celcius	HP(PS)	horsepower
CVT	centrifugal variable Transmission	psi	pound(s) per square inch
DC	direct current	r	revolution
F	farad(s)	rpm	revolution(s) per minute
F	degree(s) Fahrenheit	TDC	top dead center
ft	foot, feet	TIR	total indicator reading
g	gram(s)	V	volt(s)
kg/cm²	Kilograms per square centimeter	W	watt(s)
h	hour(s)	Ω	ohm(s)
L	liter(s)		

NOTES BEFORE MAINTENANCE

This manual includes a variety of "warnings", "attention", "tips", etc., which must be carefully followed in order to reduce the risk of injury during repair or maintenance. Improper repair or maintenance will damage the vehicle or bring safety hazards to the vehicle.

A WARNING

WARNING indicates a potential hazard that may result in severe injury or death to the operator, bystander or person(s) inspecting or servicing the vehicle.

A CAUTION

CAUTION indicates a potential hazard that may result in personal injury or damage to the vehicle.

TIPS

TIPS provide maintenance information to give the corresponding reminder, express and explanation.

IMPORTANT

IMPORTANT provides key reminders during disassembly, assembly, and inspection of components.


VEHICLE IDENTIFICATION NUMBER/ENGINE SERIAL CODE	1-2
TECHNICAL PARAMETERS OF VEHICLE	1-3
UNIT CONVERSION TABLE	1-6
TORQUE	1-7


VEHICLE IDENTIFICATION NUMBER/ENGINE SERIAL CODE

Vehicle identification number

The frame number is stamped on the frame cross tube under the right cargo box at the rear of the vehicle.

Reference the vehicle identification number (VIN) when corresponding about the Segway Powersports vehicle.





TECHNICAL PARAMETERS OF VEHICLE

ITEM		PARAMETERS		
		SGW1000F-S1	SGW1000F-S2	
Length×width×he	ight	3375mm×1630mm×1800mm	3380mm×1850mm×1850mm	
Wheelbase		2590mm		
Front wheelbase		1340mm	1570mm	
Rear wheelbase		1350mm	1575mm	
Curb weight		860kg	880kg	
Ground clearance	e	360mm	380mm	
Turning diameter		12000mm	13000mm	
Height of seat from ground		560mm(EPA)/ 670mm(T1a\T1b)	620mm	
Steering wheel di	iameter	310mm		
Carrying load		90 kg		
Reserve fuel volu	me	5L		
Rim type and	Front wheel	Aluminum rim1465	Anti drop aluminum rim1465	
specification	Rear wheel	Aluminum rim1470	Anti drop aluminum rim1470	
Tire type and	Front wheel	29×9.00R14	30×10.00R14	
specification	Rear wheel	29×11.00R14	30×10.00R14	
_	Front wheel (PSI/kPa)	18PSI (124kPa)	18PSI (124kPa)	
Tire pressure Rear wheel (PSI/kPa)		18PSI (124kPa) 18PSI (124kPa)		
Туре		Hydraulic, disc type, H type		
Driving brake Operation Mode		Foot operation		
	Туре	Mechanical		
Parking brake Operation mode		Hand operation		

Suspension	Front	Double wishbone independent suspension
type	Rear	Multi-link independent suspension
Shock	Front	Hydraulic spring-external airbag
absorber type	Rear	Hydraulic spring-external airbag
Air filter type		Paper filter type
Muffler type		Impedance
Engine type		Parallel double cylinder, water cooling, four stroke
Engine model		293MY
Displacement		999 cm ³
Compression	ratio	12.0:1
Bore diameter (mm) × stroke (mm)	93mm×73.6mm
Starting methor	od	Electric start
Ignition type		Eletcricity(ECU)
Spark plug ty	ре	NGK CPR7EA /TORCH B7RTC
Spark plug cle	earance	0.7~0.9mm
Lubrication m	ethod	Pressure splash
Cooling meth	od	Liquid cooling
Coolant capa	city	9500 mL
Lubricant	Engine	SAE10W-40/SJ or Higher
type	Front axle gear	SAE 75/80W-90 GL5
	Gearbox	SAE 75/80W-90 GL5
	Engine	3300mL
Lubricating oil capacity	Front Axle	180 mL
	Gearbox	1500mL
Fuels(Gasoline Unleaded)		87#
Fuel tank capacity		44L
Total volume of storage box		8L
CVT transmission ratio		0.891~3.608

	Headlamp Driving beam	28.4W		
	Headlamp Passing beam	14.9W		
Loadlight	Front position lamp	2.4W		
Headlight	Daytime running lamp	27.6W		
	Front durection indicator	21.6W		
	Illumination of headlamp (single)cd	21.6W		
	Rear brake light color/specification	Red/12.78 W		
Rear light	Rear position light color/specification	Red/2.12 W		
	Rear turn signal color/specification	Amber/2.32 W		
Color/Specification of Rear License Plate Light		White/2.5 W		
Battery capac	ity	12V/32Ah		
Shift operatio	n mode	Mechanical		
Auxiliary DC	Outlet	12V		
Instrument		TFT		
Central contro	ol screen (inch) (optional)	10.6		
Soot holt	Driver	Four-point roll-up		
Seat belt	Passenger	Four-point strap		
Power output mode	Shaft drive			
Front winch (lb/m)	3500(4500 optional)			

UNIT CONVERSION TABLE

	Torque	
Unit	coefficient	Convert to
N·m	× 0.1020	kg·m
N·m	×0.7376	ft·lbs
N·m	×8.851	in·lbs
kg⋅m	×9.807	N·m
kg·m	×7.233	ft·lbs
kg·m	×86.80	in·lbs
in·lbs	×0.833	ft·lbs
in·lbs	×0.116	kg·m
	Pressure	T
kPa	× 0.01020	kg/cm²
kPa	× 0.1450	psi
kPa	× 0.7501	cmHg
kg/cm²	× 98.07	kPa
kg/cm²	× 14.22	psi
cm Hg	× 1.333	kPa
	Power	
N	× 0.1020	kg
N	× 0.2248	lb
kg	× 9.807	N
kg	× 2.205	lb
	Volume	
L	× 0.2642	gal (US)
L	× 0.2200	gal (imp)
L	× 1.057	qt (US)
<u>L</u>	× 0.8799	qt (imp)
<u> -</u>	× 2.113	pint (US)
L _	× 1.816	pint (imp)
mL	0.03381	oz (US)
mL	0.02816 0.06102	oz (imp) cu in
mL	Speed	Cu III
km/h	× 0.6214	mph
	Power	···F''
kW	× 1.360	PS
kW	× 1.341	HP
PS	× 0.7355	kW
PS	× 0.9863	HP
	Temperature	
°C to °F : °C x 9/5 + 32 = °F		
°F to °C : °F - 32 x 5/9 = °C		

TORQUE

The following tables list the tightening torque for the major fasteners, and the parts requiring use of a non-permanent locking agent or liquid gasket.

Letters used in the "Remarks" column mean:

L: Apply a non-permanent locking agent.

MO: Apply molybdenum disulfide oil solution (mixture of the engine oil and molybdenum disulfide grease in a weight ratio 10:1).

EO: Apply engine oil.

SS: Apply silicone sealant

Lh: Left-hand ThreadsR: Replacement Parts

S: Follow the specific tightening sequence.

Engine standard fastener torque						
	Torque					
NO.	Fastener	N·m	kgf∙m	ft·lb	Fastening part	Remarks
1	Screw M6×16	8~12	0.8~1.2	69~103.6 in·lb		
2	Screw M8×25	22~28	2.2~2.8	16.2~20.7		
3	Screw M6×16	16~20	1.6~2.0	11.8~14.7		
4	Screw M8×25	29~35	2.9~3.5	21.4~25.8		
5	Hexagon flange bolt M10×1.25×25	75~85	7.5~8.5	55.3~62.7		
6	Hexagon flange bolt M12×1.25×30	112~128	11.2~12.8	82.6~94.4		
		Engine	special fast	ener torque		
1	Bolt M12×1.25×185	112~128	11.2~12.8	82.6~94.4	CVT Clutch primary	
2	Bolt M10×1.25×80	75~85	7.5~8.5	55.3~62.7	CVT Clutch secondary	
3	Cylinder head bolt M11×1.25×150	1. 12 2. 35 3. Tighten at 180° angle	1. 1.2 2. 3.5 3. Tighten at 180° angle	1. 8.8 2. 25.8 3. Tighten at 180° angle	Cylinder head assemble bolt	Through three tightening
4	Box bolt combination M10×1.25×110	1. 12 2. 28 3. Tighten at 90° angle	1. 1.2 2. 2.8 3. Tighten at 90° angle	1. 8.8 2. 20.6 3. Tighten at 90° angle	Lower crankcase assembly bolt	Through three tightening
5	Bolt M8×90	33~36	3.4~3.7	24~27	4 lower crankcases bolts	
6	Bolt M8×40	33~36	3.4~3.7	24~27	2 upper crankcase bolts	
7	Piston nozzle pressure regulator	18~22	1.8~2.2	13~16	Upper crankcase cylinder bore	

8	bolt M10	1. 25 2. 45 3. Tighten at 60° angle	1. 2.5 2. 4.5 3. Tighten at 60° angle	1. 18.4 2. 33 3. Tighten at 60° angle	Connecting rod bolt	Through three tightening
9	bolt M12×1.25×30-LH	145~155	14.5~15.5	107~114	Crankshaft magneto rotor	
10	bolt M6×16	7~9	0.7~0.9	62~80 in·lb	Water pump impeller	
11	bolt M24	18~22	1.8~2.2	13~16	Lower crankcase	
12	bolt M10×1.25×45	55~65	5.5~6.5	40.5~48	Driven bevel gear cover	
13	bolt M8×40	25~35	2.5~3.5	18~25.8	Driven bevel gear cover	
14	bolt M8×125	25~35	2.5~3.5	18~25.8	Driven bevel gear cover	
15	Nut M33×1.5	240~250	24~25	177~184	1 driven bevel gear nut, 2 3rd axle nuts	
16	Nut M30×1.5-LH	195~205	19.5~20.5	144~151	Four-axis driving bevel gear	
17	Nut M30×1.5	195~205	19.5~20.5	144~151	Four-axis assembly	
18	Neutral position spring plug	23~27	2.3~2.7	17~20	Left crankcase	
19	Engine drain plug m14	16~20	1.6~2.0	12~15	Oil drain screw hole	
20	Shoulder bolt	10~14	1.0~1.4	7~10	4 Cylinder head cover bolts	
21	Shoulder bolt	10~14	1.0~1.4	7~10	Tension plate, guide plate	
22	Water pipe adapter	23~27	2.3~2.7	17~20	Lower crankcase cover, left crankcase cover	
23	Oil filter adapter	35~45	3.5~4.5	17~20	Left crankcase cover oil filter	
24	Flow orifice φ1	1.9~2.5	0.19~0.25	17~22 in·lb	Gear box oil pump body	
25	Oil regulator valve unit	20~24	2.0~2.4	14.7~17.7	Lower crankcase M16 screw hole	
26	Stud M8×43	22~26	2.2~2.6	16.2~19	Cylinder head exhaust port assembly exhaust pipe	
27	bolt M6×40	12~16	1.2~1.6	8.8~12	Shift gear of shift drum	
28	Nut M22×1	175~185	17.5~18.5	130~136	Gearbox counter shaft, overload protector	
29	bolt M6×12	18~22	1.8~2.2	13~16	Timing driven sprocket	
30	Shoulder bolt M6×21	12~16	1.2~1.6	8.8~12	Shift positioning plate	
31	Screw M6×16	18~22	1.8~2.2	13~16	Magneto overrunning clutch	
		Othe	er threaded	fasteners		
1	M6×1.0	9~11	0.9~1.1	80~97 in·lb		
2	M8×1.25	20~26	2.0~2.6	14.7~19		
3	M10×1.5	55~65	5.5~6.5	40.5~48		

Standard fastener torque of the whole vehicle					
NO	Torque				D 1
NO.	Fastener	N·m	kgf∙m	ft·lb	Remarks
1	Bolt M6	8~12	0.8~1.2	69~103.6 in·lb	
2	Bolt M8	30 ~ 40	3.0~4.0	22.1~29.5	
3	Bolt M10	40 ~ 50	4.0~5.0	29.5~36.9	
4	Bolt M12	50 ~ 60	5.0~6.0	36.9~44.3	
	Torque of s	special fastene	rs for vehicle		
1	Engine install bolt M10×1.25×20	40~50	4.0~5.0	29.5~36.9	L
2	Engine install bolt M10×1.25×40	65~75	6.5~7.5	40.5~55.3	
3	Engine install bolt M10×1.25×155	65~75	6.5~7.5	40.5~55.3	
4	Engine install bolt M12×1.25×85	110~120	11.2~12.2	81~88	
5	Front Axle install bolt M10×1.25×20	40 ~ 50	4.0~5.0	29.5~36.9	L
6	Front Axle install bolt 5789 M8×90	20~26	2.0~2.6	14.7~19	
8	Front Suspension bolt M8×30	20~26	2.0~2.6	14.7~19	
9	Front Suspension bolt M10×1.25×45	65 ~ 75	6.5~7.5	40.5~55.3	
10	Front Suspension bolt M10×1.25×55	65 ~ 75	6.5~7.5	40.5~55.3	
11	Front Suspension bolt M12×1.25×145	110~120	11.2~12.2	81~88	
12	Front Suspension bolt M12×1.25×65	110~120	11.2~12.2	81~88	
13	Front and rear balance rod connecting rod nutM10×1.25	40 ~ 50	4.0~5.0	29.5~36.9	L
14	Rear suspension bolt M8×30	20~26	2.0~2.6	14.7~19	
15	Rear suspension bolt M10×1.25×55	65 ~ 75	6.5~7.5	40.5~55.3	
16	Rear suspension bolt M12×1.25×90	110~120	11.2~12.2	81~88	
17	Rear suspension bolt M12×1.25×120	110~120	11.2~12.2	81~88	
18	Rear suspension bolt M12×1.25×145	110~120	11.2~12.2	81~88	
19	Rear suspension bolt M12×1.25×170	110~120	11.2~12.2	81~88	
20	Axle mounting nut (Thread M12×1.25)	110~120	11.2~12.2	81~88	
21	Beadlock ring mounting boltM8×25	20~26	2.0~2.6	14.7~19	L
22	Axle mounting nut M24×2	290 ~ 310	29.6~31.6	213.7~228.0	
23	EPS mounting bolt M10×1.25×95	$55 \sim 65$ (Test nut)	5.5~6.5	40.5~48	
24	Steering rod (With EPS) (Thread M12×1.25)	110~120	11.2~12.2	81~88	L

25	EPS Install bolt M8×16	20~26	2.0~2.6	14.7~19	L
26	Steering wheel lock nut M14×1.5	65 ∼ 75	6.5~7.5	40.5~55.3	
27	Steering column mounting bolt M8	20~26	2.0~2.6	14.7~19	L
28	Brake caliper body mounting bolt M10×1.25×25	40 ~ 50	4.0~5.0	29.5~36.9	L
29	Brake disc mounting bolt (Thread M8)	35~40	3.5~4.0	25.8~29.5	L
30	Oxygen Sensor (Thread M18×1.5)	45 ~ 55	4.5~5.5	29.5~40.5	

MAINTENANCE PERIODIC TABLE	2-3
Maintenance Reference	2-6
Grease	2-8
GENERAL VEHICLE INSPECTION AND MAINTENANCE	2-9
Pre-Ride / Daily Inspection	2-9
Frame, Nuts, Bolts, and Fasteners	2-9
Shift Cable Inspection / Adjustment	2-10
FUEL SYSTEM AND AIR INTAKE	2-11
Fuel System	2-11
Fuel Filter	2-11
Fuel Lines	2-12
Engine Intake Pre-Filter Service	2-13
Air Filter Service	2-13
ENGINE	2-14
Engine Oil Level	2-14
Engine Oil Change	2-14
Replace oil filter/oil strainer	2-16
Add engine oil	2-17
Engine / Oil Tank Breather Hose Inspection	2-18
Engine Cylinder Leakdown Test	2-18
Spark arrester	2-19
TRANSMISSION AND FRONT GEARCASE	2-20
Check the level of rear gear box	2-20
Check the level of front gear box	2-21
Front/rear gearbox oil discharge	2-21

COOLING SYSTEM	2-23
Cooling System Hoses	2-23
Cooling bottle coolant	2-24
PVT / FINAL DRIVE / WHEEL AND TIRE	2-25
CVT belt	2-25
The CVT dry	2-25
PVT / FINAL DRIVE / WHEEL AND TIRE	2-25
Drive Shaft Boot Inspection	2-26
Wheel	2-26
Wheel Removal	2-27
Wheel Installation	2-27
ELECTRICAL AND IGNITION SYSTEM	2-28
Battery disassembly	2-28
Battery charging	2-28
ELECTRICAL AND IGNITION SYSTEM	2-28
Battery installation	2-29
Spark plug	2-29
Spark plug inspection	2-30
SUSPENSION	2-31
Oil shock absorber	2-31
SUSPENSION	2-31
BRAKE SYSTEM	2-32
Brake oil	2-33
Brake component	2-33

PERIODIC MAINTENANCE

Careful periodic maintenance will help keep your vehicle in the safest, most reliable condition. Inspection, adjustment and lubrication of important components are explained in the periodic maintenance chart.

Inspect, clean, lubricate, adjust and replace parts as necessary. When inspection reveals the need for replacement parts, use genuine parts available from your authorized dealer.

Service and adjustments are important for proper vehicle operation. If you're not familiar with safe service and adjustment procedures, have a qualified dealer perform these operations.

Maintenance intervals in the following chart are based upon average riding conditions .Vehicles subjected to severe use must be inspected and serviced more frequently.

Severe use is defined as:

- ◆ Frequent immersion in mud, water, or sand
- **♦** Frequent or prolonged operation in dusty environments
- ♦ Short trip cold weather operation
- ◆ Racing or racing-style high RPM use
- **♦** Prolonged low speed, heavy load operation
- **◆** Extended idle

MAINTENANCE CHART KEY

SYMBOL	DESCRIPTION
•	Perform these procedures more often for vehicles subjected to severe use.
D	Have an authorized dealer or other qualified person perform these services.

▲ WARNING

Improperly performing the procedures marked with a D could result in component failure and lead to serious injury or death. Have an authorized dealer or other qualified person perform these services.

Perform all services at whichever maintenance interval is reached first. Record maintenance and service in the Maintenance Log.


保养周期表


ITEM			ENANCE INTER	REMARKS		
		HOURS	HOURS CALENDAR MILES (KM)		T LEW WITE	
	Steering		Pre-Ride			
	Front suspension		Pre-Ride			
	Rear suspension		Pre-Ride		Vigually inappet test	
	Tires/ Wheels/ fasteners		Pre-Ride		Visually inspect, test, or check components. Make adjustments and/ or schedule repairs	
	Brake fluid level		Pre-Ride		when required	
	Brake system		Pre-Ride			
	Accelerator		Pre-Ride			
	Engine oil level		Pre-Ride			
•	Air filter, pre-filter		Daily		Inspect; clean often; replace as needed	
	Coolant		Daily		Check level	
	Power steering unit (if equipped)		Daily		Inspect daily; clean often	
	Headlight/taillight/ worklight		Daily		Check operation; apply dielectric grease if replacing lamps	
•	Air filter, main element		Weekly	3700 (6000)	Inspect; replace as needed	
▶ D	Brake pad wear	10 H	Monthly	100 (160)	Inspect periodically	
	Battery	20 H	Monthly	200 (320)	Check terminals; clean; test	
	Fuel System	20 H	Monthly		Inspect; cycle key to pressurize fuel pump; check lines and fittings for leaks and abrasion	
•	Engine oil change	25 H	1 M	620 (1000)	Break-in oil and filter change	
•	Front gearcase oil	25 H	1 M	200 (320)	Break-in oil level check	
•	Rear gearcase oil	25 H	1 M	200 (320)	Break-in oil level check	
•	General lubrication	50 H	3 M	500 (800)	Lubricate all fittings, pivots, cables, etc.	
	Throttle Body Intake Duct	50 H	6 M		Inspect duct for proper sealing/air leaks	

ITEM		MAINTENANCE INTERVAL (WHICHEVER COMES FIRST)			REMARKS	
		HOURS	CALENDAR	MILES (KM)	KLWAKKS	
	Drive belt	50 H	6 M	500 (800)	Inspect; adjust; replace as needed	
	Cooling system	50 H	6 M	1000(1600)	Inspect coolant strength seasonally; pressure test system yearly	
•	Engine oil change	100 H	6 M	1800(3000)	Change the oil and filter	
•	Oil lines and fasteners	100 H	6 M	1000(1600)	Inspect for leaks and loose fittings	
•	Front gearcase oil	100 H	12 M	1800(3000)	Change fluid;	
•	Rear gearcase oil	100 H	12 M	1800(3000)	Change fluid	
D	Fuel system/filter	100 H	12 M	1000(1600)	Cycle key to pressurize fuel pump; check for leaks at fill cap, fuel lines/rail and fuel pump; replace lines every two years	
•	Radiator (if applicable)	100 H	12 M	1000 (1600)	Inspect; clean external surfaces	
•	Cooling hoses (if applicable)	100 H	12 M	1000 (1600)	Inspect for leaks	
•	Engine mounts	100 H	12 M	1000 (1600)	Inspect	
	Exhaust muffler/ pipe / Joints	100 H	12 M	1000 (1600)	Inspect; clean; replace worn parts	
D	Spark plug	100 H	12 M	1000(1600)	Inspect; replace as needed	
D	Clutches (drive and driven)	100 H	12 M	3700 (6000)	Inspect; clean; replace worn parts	
D	Front wheel bearings	100 H	12 M	1000 (1600)	Inspect; replace as needed	
D	Brake fluid	200 H	24 M	2000(3200)	Change every two years	
	Spark arrester	300 H	36 M	3000(4800)	Clean out	
•	Coolant		60 M		Replace coolant	
D	Valve clearance	500 H		5600 (9000)	Inspect; adjust	
	Idle speed				Adjust as needed	
D	Toe adjustment				Inspect periodically; adjust when parts are replaced	
	Headlight aim				Adjust as needed	


Maintenance Reference


Item	Recommended Model	Capacity	Inspection Method	Schedule
Engine Oil	SAE10W-40/SG Or higher grade	3 qts. (3300 ml)	Maintain level in safe range on dipstick	Refer to Maintenance Schedule
Engine Coolant		8.63 qts. (9500 ml)	Maintain the level between the fill lines.	Refer to Maintenance Schedule






Item	Recommended Model	Capacity	Inspection Method	Schedule
Brake fluid	DOT4		Maintain the level between the fill lines.	Refer to Maintenance Schedule
Front axle gear oil	SAE 75/80W-90 GL5	0.16 qts. (180 mL)	Maintain the fluid to the Fill Plug level	Refer to Maintenance Schedule
Rear axle gear oil	SAE 75/80W-90 GL5	1.36 qts. (1500 ml)	Maintain the fluid to the Fill Plug level	Refer to Maintenance Schedule








Grease

The front and rear suspension arms, balance rods and driving shafts of the vehicle are designed with fueling nozzles. Grease these parts with lubricating oil regularly, make sure these parts are dry before filling.

Item	Recommended Model	Capacity	Inspection Method	Schedule
Front arm (upper and lower) / Front balance bar	Semi-synthetic waterproof grease	Grease fill (MAX 2 pumps)		Per 2000 miles
Rear balance bar	Semi-synthetic waterproof grease	Grease fill (MAX 2 pumps)	Grease fill (MAX 2 pumps)	Per 2000 miles
Driving shaft	Semi-synthetic waterproof grease	Grease fill (MAX 2 pumps)	Grease fill (MAX 2 pumps)	Per 2000 miles



GENERAL VEHICLE INSPECTION AND MAINTENANCE


Pre-Ride / Daily Inspection

Perform the following pre-ride inspection daily, and when servicing the vehicle at each scheduled maintenance.

- ◆ Engine Oil Check for proper level on dipstick located in oil tank (refer to "Engine Oil Level" procedure)
- ◆ Tires check condition and pressures
- ◆ Fuel tank fill to proper level
- All brakes check operation and fluid leveL and adjustment (includes parking brake on INT'L Model)
- ◆ Throttle check for free operation and closing
- Headlights/Taillights/Brakelights also check operation of all indicator lights, instrument cluster and switches
- ◆ Ignition switch check for proper function
- Wheels check for tightness of wheel nuts and axle nuts; check to be sure axle nuts are secured by cotter pins
- ◆ Engine Intake Pre-Filter Inspect pre-filter and clean with soapy water and compressed air if necessary
- PVT Intake Pre-Filter Inspect pre-filter and clean with soapy water and compressed air if necessary
- ◆ Steering check for free operation noting any unusual looseness in any area
- Loose parts visually inspect vehicle for any damaged or loose nuts, bolts or fasteners
- ◆ Engine coolant check for proper level at the recovery bottle
- Drive Shaft Boots Inspect inner and outer boots for tears or damage on both front and rear drive shafts
- ◆ Check all front and rear suspension components for wear or damage.

Frame, Nuts, Bolts, and Fasteners

◆ Periodically inspect the torque of all fasteners in accordance with the maintenance schedule. Check that all cotter pins are in place. Refer to specific fastener torques listed in each chapter.



Shift Cable Inspection / Adjustment

Shift cable adjustment may be necessary if symptoms include:

No gear position or AWD display on instrument cluster Ratcheting noise on deceleration

Inability to engage into a gear

Excessive gear lash (noise)


Gear selector moving out of desired range


[A] pivot bushings

【B】dust boot

[C] shift cable

- ◆ Locate the shift cable attached to the transmission case in the right rear wheel well area.
- Inspect shift cable, pivot bushings, and dust boot.
 Replace if worn or damaged.






【B】lower jam nut

- Adjust the shift cable so there is the same amount of cable travel when shifting slightly past HIGH gear and PARK.
- ◆ Thread the upper or lower jam nut as required to obtain proper cable adjustment.



This procedure may require a few attempts to obtain the proper adjustment.

- Once the proper adjustment is obtained, place the shift cable and upper jam nut into the mount. Tighten the lower jam nut against the mount.
- Start engine and shift through all gears to ensure the shift cable is properly adjusted. If transmission still ratchets after cable adjustment, the transmission will require service.



FUEL SYSTEM AND AIR INTAKE

Fuel System

▲ WARNING

Gasoline is very flammable under certain conditions

- ◆ You must be extremely careful when dealing with gasoline.
- ◆ When refueling, the engine must be shut off and must be done outdoors or in a well-ventilated area.
- ◆ At or near the refueling or gasoline storage location. No smoking, no open flames or sparks.
- Do not overflow when refueling. Do not fill the tank to the neck.
- If gasoline gets on your skin or clothes, wash them with soap and water immediately and change clothes.



Symptoms of a restricted fuel tank vent include the following: collapsing fuel tank, engine miss or hesitation, loss of engine performance or high exhaust temperatures.

[A] Fuel Filter 1

【B】Fuel Filter 2


- ◆ The fuel filter [A] is located behind the passenger seat and can be seen by removing the passenger seat and the maintenance cover behind it. The fuel filter [B] is located on the left under the driver's seat, visible when the driver's seat is removed.
- ◆ Locate and inspect the in-line filter. Note the direction of the arrow on the filter if removed.
- ◆ If there is debris visible in the filter, replace it.


NOTE


- Be sure to install the filter in the orientation shown in the previous photo.
- Check the fuel tank vent line for signs of wear, deterioration or damage. Replace vent line if necessary.
- ◆ Be sure the vent line is routed properly and secured with cable tie(s).


IMPORTANT


Make sure vent line is not kinked or pinched.











Fuel Lines

- [A] Main fuel tank
- **(B)** Auxiliary fuel tank
- [C] Rear high pressure oil pipe
- **[D]** Negative pressure connection hose for negative pressure pump
- First check whether there is leakage at the pipeline connected onto the fuel tank, and check whether the fuel pipeline connected to the fuel tank is worn, deteriorated, or damaged. Replace the fuel line if necessary.
- Check whether the pipeline connection on the auxiliary fuel tank is leaking, and check whether the fuel pipeline connected to the auxiliary fuel tank is worn, deteriorated, or damaged. Replace the fuel line if necessary.
- Locate the rear high-pressure oil pipe connected to the engine under the cargo box, and check the wiring and quick connect device for signs of failure, wear, deterioration, damage or leakage. Replace if necessary.
- Find the negative pressure connection hose of the negative pressure pump connected to the engine under the cargo box, and check the wiring and quick connection device for signs of failure, wear, deterioration, damage or leakage. Replace if necessary
- Be sure fuel lines are routed and retained properly.

IMPORTANT

Make sure lines are not kinked or pinched.




It is recommended to check the engine intake prefilter regularly. The filter should be inspected using the following procedure:

The primary air filter is located under the rear storage box.

[A] Primary air filter

The primary filter screen must be cleaned every time the air filter core is replaced. If the primary filter screen is damaged,replace it.




Air Filter Service

- ◆ The air filter element of this vehicle is a paper air filter element. The filter needs to be replaced after a period of use. For details, see the periodic maintenance table.
- [A] Air filter cover snap
- [B] Air filter cover
- [C] Air Filter element

The air filter is located under the rear storage box, see the disassembly steps.

- 1. Remove the 4 buckles 【A】 of the air filter cover, and lift the air filter cover 【B】 together with the intake pipe.
- 2. Take out the air filter element [C].
- 3. Take the filter element out of the box, replace the filter element for cleaning or replacement.
- 4. Reinstall the filter element on the filter.
- 5. Reinstall the air filter cover.



ENGINE

Engine Oil Level

IMPORTANT

Always check the oil level when the engine is cold. If the engine is hot when the oil level is checked, the level will appear to be overfull.

Access the oil tank dipstick through the oil tank access panel located in the left front corner of the cargo box.

Engine oil model:


SAE10W-40/SG Or higher grade

Remove the rear cargo bed。


Engine oil capacity:

3 qts. (3300 ml)

To check oil level follow the procedure listed below:




- **→** F
 - Park the vehicle on a level ground. Wait at least 5 minutes to allow the oil to flow back to the bottom of the engine.
 - Put a piece of cotton cloth under the end of the oil dipstick, and then pull out the oil dipstick.
 - ♦ Wipe the oil dipstick clean.
 - Reinsert completely;
 - Put a piece of cotton cloth under the end of the oil dipstick, then pull out the oil dipstick and check the oil level.



【B】 Lower engraved line

[C] Dipstick



Check the oil level as shown in the figure below: The oil level is between the Upper engraved line [A] and the Lower engraved line [B]. It is the proper oil level. Below the lower scale means the oil is too little, and the upper scale means the oil is too full, too little or Too full is not suitable.

After cleaning the oil dipstick, fully insert it again.

Engine Oil Change

Always change engine oil and filter at the intervals outlined in the Periodic Maintenance Chart. Always change the oil filter whenever changing the engine oil. The oil tank drain plug is located on the bottom of the oil tank. Access the drain plug through left rear wheel well.

WARNING

Whenever changing oil change the oil filter.

Oil emission position 1 is located inside the left rear wheel of the vehicle, and oil emission position 2 is located the bottom of the vehicle.



【B】O-ring


[C] oil plug

【D】O-ring

[E] oil drain plug

Discharge position 1

- Put the vehicle on the horizontal surface;
- ◆ Start the engine.Let it heat up for two to three minutes while it's idle:
- Stop the engine;
- ◆ Remove drain plug 【A】 and remove O-ring 【B】;





5. Take out the oil strainer [C] and wait for the waste oil to be discharged completely.


Discharge position 2

- ◆ Remove drain plug 【E】, take off O-ring 【D】 and wait for the waste oil to be discharged completely. Hot oil can cause skin burns. Keep the hot oil away from the skin.
- Reinstall drain plug.

Torque specifications:







Replace oil filter/oil strainer

IMPORTANT

Change the oil filter and clean the oil strainer every time you change the oil

Change Oil Filter

The oil filter is located inside the left rear wheel of the vehicle. Please refer to the fluid recommendation table for capacity and plug torque. Always change the filter at the same time as the oil change.

[A] Oil Filter

- Use a jack to lift the rear of the vehicle to a certain height.
- ◆ Remove the bolts under the left rear shock absorber, and place the shock absorber tilted back aside.
- Unscrew the oil filter with a tool, and pay attention to the direction of the screw when unscrewing.
- Install a new filter and manually rotate it clockwise until the filter gasket touches the sealing surface until it is tightened.
- ◆ Re-fix the lower installation point of the left shock absorber with bolt M12×1.25×7.




【B】oil drain plug


[C] O-ring

【D】oil strainer



- Remove the drain plug, take off the O-ring, and take out the oil strainer;
- Put the oil strainer into the cleaning aid for cleaning, and dry the cleaned strainer;
- Reinstall the washed oil strainer and replace the new O-ring when installing.





Add engine oil

The engine oil adding port is located under the cargo engine maintenance cover.

- Unscrew the oil cap counterclockwise.
- ◆ Add an appropriate amount of the recommended type of oil and do not overfill it. The oil level between the upper scale and the lower scale is appropriate.
- ◆ Retighten the oil cap.
- Put the gear shifter in parking gear.
- ◆ Lock parking brake.
- Start the engine and leave it idle for 1 to 2 minutes.
- Stop the engine.
- ♦ Check for leaks.
- ◆ Check the oil level and add oil as needed to make the oil level reach the mark on the ruler.
- Properly handle used filters and oil.


Valve Clearance Inspection


IMPORTANT: Valve clearance inspection should be performed on a cold engine, at room temperature.


- 1.Remove the seats and engine service panel.
- 2.Disconnect the negative (-) battery cable.
- 3.Remove the rear bumper and cargo box as an assembly (see Chapter 5).
- 4.Remove the (8) screws that retain the outer clutch cover.
- 5. Maneuver the outer clutch cover for drive clutch access.

NOTE

Removal of left rear wheel or left rear shock is NOT necessary to perform this procedure.







Engine / Oil Tank Breather Hose Inspection


The engine and oil tank are equipped with a breather hose. Inspect the breather hoses for possible kinks or wear. The hoses are form fitted for proper fit.

- [A] Engine
- 【B】Engine breather hose
- [C] Air filter
- [D] auxiliary tank
- (E) Main tank
- [F] Oil tank breather hose
- ◆ Engine Breather Hose: from the engine to the air filter..
- ◆ Oil Tank Breather Hose: 沿着正副油箱中间向上一直延伸到加油口。

NOTE: Make sure hoses are not kinked or pinched.

Engine Cylinder Leakdown Test

A cylinder leak-down test is the best indication of engine condition. Follow tester manufacturer's instructions to perform a cylinder leak-down test. Never use high pressure leakage testers as crankshaft seals may dislodge and leak.



Spark arrester

Spark eliminator prevents random sparks from entering other vehicles parts. Regular maintenance can prevent carbon accumulation, whereas delayed maintenance will reduce engine performance.


WARNING

Make sure the exhaust pipes are cool. The engine has just stopped working and the pipes can overheat and cause people burn.

To reduce fire hazards, ensure that there are no combustible material in the area when removing them from spark plugs.

Safety glasses are recommended in this procedure.

The exhaust pipe must be cleaned of accumulated carbon periodically as follows:





[A] Pan head screw M6×12

【B】平垫圈

[C] Muffler spark arrester

 Remove the 6 fastening bolts on the left and right muffler spark arrester [A]





- 2. Disassemble the muffler spark arrester
- Use a non-synthetic brush to clean the arrester screenr. A synthetic brush may melt if components are warm. If necessary blow debris from the screen with compressed air.
- 4. Inspect the screen for wear and damage. Replace a worn or damaged screen.
- Reinstall the muffler spark arrester and fastening screws

TRANSMISSION AND FRONT GEARCASE

Check and replace the demand drive fluid at intervals in the periodic maintenance diagram.

A CAUTION

If the front gearbox makes too much noise during 4WD operation, change the demand drive fluid. If the noise continues, please check the service of your dealer or other qualified service facility.

Use the recommended oil. Use of other liquids may result in improper unit operation. Maintain liquid level at bottom of filling hole thread.

Check the level of rear gear box





[B] Oil dipstick


[C] Upper reticle


[D] Undercut

- Park the vehicle on the level ground. The engine warmer should wait at least five minutes to allow the oil to flow back to the bottom of the engine.
- 2. Place a piece of cotton cloth under the end of the oil ruler and pull out the oil ruler.
- 3. Wipe the oil ruler clean.
- 4. Re-insert completely;
- 5. Put a piece of cotton cloth under the end of the oil ruler, then pull out the oil ruler and check the oil level. Check the oil level as shown in the figure below: upper scale and lower scale. The oil level between upper scale and lower scale is the appropriate oil level. Lower than the lower scale means the oil level is too low, while higher than the upper scale means the oil level is too full, too little or too full is not appropriate
- 6. Wipe the oil ruler before reinserting it completely.









Check the level of front gear box

The front axle gearbox filling plug is located on the left side of the front gearbox, keeping the lubricating oil level flush with the bottom of the filling plug.


[A] Front axle gearbox

[B] Filling plug

[C] O ring

- 1. Position vehicle on a level surface.
- 2. Remove the fill plug and check the lubricant level.
- 3. If lubricant level is not even with bottom threads, add recommended lubricant as needed. Do not overfill.
- 4. Reinstall the fill plug and torque to specification.

Torque of **Drain Plug**16-20N.m(11.8-14.8ft·lb)



Front/rear gearbox oil discharge

- [A] Front axle oil drain plug
- 【B】 Rear gearbox oil drain plug
- [C] Oring
- 1. Place a container under the vehicle to collect waste oil.
- 2. Put the vehicle on the horizontal surface and remove the injection plug and O ring.
- 3. Reinstall the injection plug after oil discharge is completed. Torque to required value:

Torque of **Drain Plug**

16-20N.m(11.8-14.8ft·lb)

A C C B

Front axle oil filling


- [A] Filling plug
- 【B】 Drain Plug
- 【B】O-ring

Torque of Filling Plug/Drain pulg

16-20N.m(11.8-14.8ft·lb)

- 1. Position the vehicle on a horizontal plane. Remove the drain plug.
- 2. Place the drain tray under the demand drive unit. Remove the drain plug **[B]**. Allow the fluid to drain completely.
- 3. Clean and reinstall the drain plug [B]. Torque to desired value.
- 4. Add the recommended amount of liquid.
- 5. Reinstall the injection plug. Torque to desired value.
- 6. Check the leakage situation. Dispose of used liquids properly.

Rear gearbox oil filling




【B】O-ring

[C] Oil dipstick


【D】O-ring

Torque of **Drain pulg**16-20N.m(11.8-14.8ft·lb)

- 1. Position the vehicle on a horizontal plane. Remove the drain plug.
- 2. Place the drain tray under the demand drive unit. Remove the drain plug 【A】. Allow the fluid to drain completely.
- 3. Clean and reinstall the drain plug 【A】. Torque to desired value.
- 4. Unscrew the oil dipstick of the rear gearbox.Add the recommended amount of liquid.
- 5. Re-tighten the oil dipstick of the rear gearbox.
- 6. Check the leakage situation. Dispose of used liquids properly.







Cooling System Overview

The engine coolant level is controlled, or maintained, by the recovery system. The recovery system components are the recovery bottle, radiator filler neck, radiator pressure cap and connecting hose.


As coolant operating temperature increases, the expanding (heated) excess coolant is forced out of the radiator past the pressure cap and into the recovery bottle. As engine coolant temperature decreases the contracting (cooled) coolant is drawn back up from the tank past the pressure cap and into the radiator.

WARNING

Some coolant level drop on new machines is normal as the system is purging itself of trapped air. Observe coolant levels often during break-in period.

Overheating of engine could occur if air is not fully purged from system.


Cooling System Hoses




Replace the hose if any fraying, cracks 【B】 or bulges 【C】 are noticed.

Check that the hoses are securely connected and clamps are tightened correctly.

- ◆ Inspect all vehicle hoses for cracks, deterioration, abrasion or leaks. Replace if necessary.
- Check tightness and condition of all hose spring clamps. Replace if necessary.
- ◆ Inspect all engine hoses for cracks, deterioration, abrasion or leaks. Replace if necessary.
- Check tightness and condition of all hose spring clamps. Replace if necessary.





Cooling bottle coolant

The coolant bottle is located under the cargo bed at the rear of the vehicle.

- 1. After removing the cargo bed, observe the liquid level in the bottle.
- If the liquid level is low, remove the cap and add the coolant as needed. Keep the coolant level between the MIN and MAX mark on the bottle (while the liquid cools).

[A] MAX

(B) MIN

- Unscrew the lid and pour in new coolant. Observe the coolant position when pouring and do not exceed the maximum liquid level;
- 4. Reinstall the lid.
- 5. Install the ventilation hood.

Radiator Coolant

To ensure that the coolant maintains its ability to protect the engine, we recommend that the system be completely emptied every five (5) years with the addition of a new antifreeze 50/50 premix.


A CAUTION

A steam overflow can cause burns.Do not remove the pressure cap when the engine is warm or hot. The engine must be cooled before the pressure cap is removed

Replace coolant with fresh antifreeze 50/50 premix when any cooling system fluid is discharged for maintenance or repair. If the recovery bottle is empty, check the liquid level in the radiator. Add coolant as needed.

[A] Pressure CapRecovery

- 1. After removing the cargo bed.
- 2. Remove the pressure cap.
- 3. Add the coolant slowly through the radiator filling port using a funnel.
- Reinstall the pressure cap. The use of non-standard pressure caps will affect the normal operation of the recovery system. Your dealer can provide the correct replacement parts



PVT / FINAL DRIVE / WHEEL AND TIRE

CVT belt

Replace the CVT drive belt according to the time specified in the vehicle maintenance schedule. If the CVT belt is damaged, it should also be replaced.

When replacing the belt, clean the pipe and clutch and the engine compartment for debris.

▲ WARNING

Failure to remove all debris when the belt is replaced can result in vehicle damage, loss of control and serious injury or death



[B] CVT Cover

【C】CVT Driving Wheel mounting bolt

【D】Washer

[E] Driving wheel parts

[F] CVT Driven Wheel mounting bolt

【G】Driven wheel parts


[H] CVT belt

Stop the engine before replacement and allow the vehicle to cool down.

- Loosen the 10 fastening bolts on the CVT cover and remove the CVT cover.
- Loosen the fixing bolts and washers on the CVT driving wheel component and the driven wheel respectively.
- Loosen the fixing bolts and washers on the CVT driving wheel component and the driven wheel respectively.
- 4. Remove the CVT belt to be replaced.
- Move the driven moving plate assembly forcefully to increase the gap between the driven and driving plate, and then install the new CVT belt on the driven wheel part.

If there are debris in the CVT inner box, please remove all debris completely.

6. Install the other end of the CVT belt on the driving wheel, reinstall the driving wheel and driven wheel



- components with the new belt installed on the engine, and tighten the bolts to the specified torque.
- 7. Turn the driven wheel component counterclockwise until the CVT belt is fully tightened.
- 8. Install the CVT cover and tighten the fixing bolts.

The CVT dry

In some cases, the water may soak into the CVT system and dry it before driving.


- 1. Remove the clutch drain plug.
- 2. Wait for the water to drain out and reinstall the water drain plug.
- Place the transmission in "P" gear and pull up the parking handle.
- 4. Start the engine.
- Lightly step on the accelerator pedal to increase the engine speed and maintain it for 10-15 seconds to expel moisture and air, and dry the belt and CVT. It is strictly forbidden to fully open the throttle.
- 6. Allow engine speed to be kept at idle speed. Use the brake. Convert transmission to the lowest available range.
- 7. Belt skid test. If the belt slides, repeat the process.
- 8. Your segway dealer can help if your vehicle needs service.


Drive Shaft Boot Inspection


Inspect the front and rear drive shaft boots for damage, tears, wear or leaking grease. If the boots exhibit any of these symptoms, they should be replaced. Check to see the boot clamps are properly positioned. Refer to Chapter 7 for drive shaft boot replacement.

CAUTION

Do not lubricate the stud or the lug nut.







Recommended	Front wheel	Rear wheel
tire pressure	18 psi (124 kPa)	18 psi (124 kPa)

The recommended size			
The front wheel	The rear wheel		
29×9.0R14/ 30×10.00R14	29×11R14/ 30×10.00R14		

Wheel

Driving a vehicle with incorrect tire pressure may result in the following consequences:

- Reduce fuel efficiency
- Reduce driving comfort and shorten tire life
- ♦ Safety reduction

When checking tire pressure, follow the following instructions:

- Inspection can only be carried out after the tire cools down
- ◆ If the vehicle has been parked for at least 3 hours, or has not driven more than 1.5km (0.9mi), the check at this time can get an accurate reading of the cold tire inflation pressure.
- Do use tire pressure gauges. Tire appearance can sometimes be misleading. In addition, even a few pounds less air in a tire can affect driving and handling performance.
- Don't reduce the tire pressure after driving.
 Increased tire pressure is normal after driving.

Wheel Removal

- 1. Position the vehicle on a level surface.
- 2. Place the transmission in PARK and stop the engine.
- 3. Loosen the wheel nuts slightly. If wheel hub removal is required, remove the wheel cap, cotter pin and loosen the hub nut slightly.
- 4. Elevate the appropriate side of the vehicle by placing a suitable stand under the frame.
- 5. Remove the wheel nuts and remove the wheel.

Wheel Installation

The installation of tires is opposite to the removal of tires. Please tighten the four tire nuts to the specified torque value.

Torque of Mounting nuts
100~120N.m (51-59ft·lb)

WARNING

Do not use wheels of different sizes than recommended in the User's Manual as this can cause the vehicle to lose control.

ELECTRICAL AND IGNITION SYSTEM

Battery disassembly

A CAUTION

If the electrolyte overflows, immediately wash it off with a solution of 1 tablespoon baking soda and 1 cup water to prevent damage to the vehicle.

The battery is located behind the driver seat. If you want to replace or maintain the battery, please follow the following steps:



[A] Driver's seat

[B] Battery protective cover


[C] Battery

[D] Battery strap

[E] Battery positive wire

[F] Battery negative wire

- ◆ Please remove the seat 【A】.
- ◆ Hold the groove behind the battery guard plate with your hands and move forward, and remove the battery board;
- ◆ Remove the battery strap;
- Turn up the Protective rubber sleeve;
- ◆ Remove the battery negative pole screw and disconnect the black (negative) 【F】 battery cable.
- ◆ Remove the battery positive pole screw and disconnect the red (positive) 【E】 battery cable.
- ♦ Remove the battery from the vehicle.




A CAUTION


When charging, the hydrogen produced by the 12V battery is combustible explosive gas. Therefore, please follow the following precautions before charging:


If charging the 12V battery is still installed in the car, be sure to disconnect the ground cable.

Make sure the power switch on the charger is off when connecting and disconnecting the charger cable to the 12V battery.

Only charge slowly (5A or less). If charged quickly, the 12V battery may explode.








Battery installation



To reduce the chance of sparks: Whenever the battery is removed, disconnect the black (negative) cable first. When reinstalling the battery, finally install the black (negative) cable.

- Clean battery cables and terminals with a hard wire brush. Corrosion can be removed with a solution of 1 cup water and 1 tablespoon baking soda. Rinse well and dry thoroughly.
- 2. Put the battery in the tray.
- 3. Connect and tighten the red (positive) cable.
- 4. Connect and tighten the black (negative) cable.
- 5. Install a clear battery vent from the vehicle to the battery vent.(For conventional batteries only).
- 6. Install the battery press plate;
- 7. Tighten the battery clamp bolt;
- 8. Verify that cables are properly wired.




Spark plug

Refer to the recommended spark plug type and clearance specifications. Spark plug torque specification.

A CAUTION

Using unrecommended spark plugs can cause serious engine damage. Always use the recommended spark plugs or their equivalents.


MAINTENANCE



Charle Dive	Model	spark plug clearance
Spark Plug	CPR7EA / B7RTC	0.7-0.9mm


Removal of rear cargo bed

The cargo bed is a snap-in quick-release structure. Hold the groove on the top of the cargo bed with both hands and move it backward to remove it.



Remove the rear Cargo Bed

Loosen the M6×35 bolts fixing the air filter housing assembly with a tool, and remove the bolts and bushings. At this time, the air filter housing assembly and the air filter inlet pipe joint can be turned up backwards, the spark plug is located below, and the spark plug can be replaced.



Spark plug inspection

Spark plug condition indicates engine running. Check or change the spark plugs with reference to the maintenance time of the periodic maintenance schedule.

A CAUTION

Remove the spark plug for inspection need wear protective gloves, or hot exhaust system and engine will cause burns.

[A] Bolt

[B] Ignition coil

[C] Spark plug

[D] Spark plug sleeve

The spark plug is located under the rear cargo bed and the air filter. First remove the rear storage box, and then remove the air filter. The twin-cylinder engine has two spark plugs. When replacing the spark plugs, please replace both spark plugs at the same time.

- 1. Remove the ignition coil fixing bolts;
- 2. Take out the ignition coil;
- 3. The spark plug is located below the ignition coil. Use tool to turn the spark plug cap 1/4 and remove it from the spark plug.
- 4. Rotate the spark plug counterclockwise and remove it
- 5. Inspect the spark plug

Spark plug normal status: The electrode part is grayish white, grayish yellow or light brown, and the electrode gap is about 0.7-0.9mm.

Spark plug to be replaced: The spark plug appears electrode ablation, carbon deposition, clearance is too large, at this time the spark plug should be replaced.

前左 制动 制动 和 和 和 和 和 格 和 后 右 制动 后 者 制动

BRAKE SYSTEM

The front and rear brakes are hydraulic disc type brakes activated by the brake pedal.

WARNING

be replaced.

Brake fluid levels must be checked periodically: overfilling of the brake cylinder may cause brake resistance or brake locking, which may result in serious injury or death. Keep brake fluid at the recommended level and do not overfill. Must check brake disc brake disc wear condition regularly: if brake disc wear, should

The following inspection is recommended to keep the braking system in good working condition. If the brake is in heavy use during normal operation, check it frequently.

- Always keep the brake fluid at an appropriate level.
 Please refer to master cylinder/brake fluid section for details.
- ◆ Check the braking system for liquid leakage.
- Check whether the brake travels too long or feels soft.
- Check whether the friction gasket is worn, damaged or loose. When replacing the brake gasket, the brake pad must be replaced when the remaining limit thickness of the brake pad is not less than 1mm.
- Check the safety and surface condition of the disc. Use the recommended brake cleaner or liqueur to clean any grease. Do not use spray lubricants or other petroleum-based products. If any damage (crack, excessive corrosion, warping) is found, please check the dealer's service before operation.

Brake oil

Use the recommended brake oil:

|--|

No adjustment is required for the hydraulic assisted braking system. Check the brake oil level of the auxiliary braking system frequently. If the level is shown to be low, perform the following operations. The brake oil cup is located below the front panel.

- Remove the front shelf and the lower cover of the instrument. See Page112 for the removal method;
- 2. Observe the liquid level in the container:




(B) MIN

The brake fluid level is most suitable between the upper plane and the lower plane. If it is lower than the lower plane, please add the recommended brake fluid and observe the liquid level.

A CAUTION


Brake fluid can damage plastic and painted surfaces and should be added with caution. If the brake fluid comes into contact with the skin or eyes, flush with plenty of water immediately. If you feel unwell, seek medical advice immediately.




Brake pads and brake discs

The wear of brake pads and brake discs will depend on the severity of use and driving conditions. Brake pads wear faster in wet and muddy conditions. Regularly check the wear of the brake pads and brake discs according to the maintenance schedule. If the wear of the brake pads and brake discs exceeds the required value, the brake pads and brake discs must be replaced.


Brake pad	Standard thickness	5.0mm
thickness	Minimum thickness	1.0mm
brake discs	Standard thickness	5.0mm
thickness	Minimum thickness	4.0mm






E	xploded view	3-1-2
Te	echnical parameter	3-1-4
S	pecial Tools	3-1-5
E	ngine oil flow chart	3-1-6
0	il and oil filter	3-1-7
	Oil level check	3-1-7
	Engine oil change	3-1-8
	Remove the oil filter	3-1-8
	Clean the oil filter combination	3-1-8
0	il pressure	3-1-9
	Measure oil pressure	3-1-9
0	il pump	3-1-10
	Remove the oil filter assembly	3-1-10
	Install the oil filter assembly	3-1-10
	Remove the oil pump assembly	3-1-10
	Install the oil pump assembly	3-1-10
	Remove the main engine oil pump rotor	3-1-11
	Install the main engine oil pump rotor	3-1-11
	Remove the auxiliary oil pump rotor	3-1-12
	Install the auxiliary oil pump rotor	3-1-12
	Remove the oil pump shaft and oil seal	3-1-12
	Install the oil pump shaft and oil seal	3-1-12
0	il cooler assembly	3-1-13
	Remove the oil cooler assembly	3-1-13
	Install the oil cooler assembly	3-1-13

Exploded view





No	Factorer	Torque		Domonko	
No.	Fastener	N·m	kgf∙m	ft·lb	Remarks
1	Bolt m6×16	9.8	1.0	87 in•lb	
2	Bolt m6×40	9.8	1.0	87 in•lb	
3	Oil pump chain guard plate				
4	Bolt m6×20	9.8	1.0	87 in•lb	
5	Oil pump chain assembly				
6	Oil pump driven sprocket				
7	Washer 6.5				
8	Oil pump shaft				
9	Needle roller p4×15.8				
10	Oil pump cover ii				
11	Auxiliary oil pump rotor combination				
12	Washer 10.6×18×1				
13	Oil seal 11×17×4				
14	Oil pump body				
15	Oil strainer seal ring				
16	Oil strainer assembly				
17	Main oil pump rotor combination				
18	Oil pump cover i				
19	Oil pump components				
20	Oil cooler assembly				
21	Oil pump components				

G: Use grease suitable for oil seals and O-rings

L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.


R: Spare parts


Technical parameter

Item	Parameter
Engine Oil:	
Grade	API SJ Or higher
Viscosity	SAE 10W-40
Filling amount	3.3 L (3.0 US qt) (First time, no residual oil in the engine)
	3 L (2.72 US qt) (Regular oil change)
Oil pressure measurement (working temperature):	More than 69 kPa (10psi) @1400r/min (rpm) More than 276 kPa (40 psi) @7000r/min (rpm)
Oil Pressure Sensor:	Always open, working pressure: 250±10kPa

Special Tools











Engine oil flow chart





Oil and oil filter

▲ WARNING


Running the vehicle with insufficient engine oil, deterioration or contamination may cause the engine or transmission system to jam, malfunction and damage

Oil level check

- ◆ Park the vehicle on a flat ground and keep it level
- ◆ If the oil has just been changed, start the engine, run it at idle speed for 5 minutes, fill the oil filter

A CAUTION


Let the engine idle for a few minutes so that the oil can reach all parts of the engine. Engine running in a state of lack of fuel will cause serious damage



- ◆ Stop the engine, wait 2 minutes, let the oil in the oil circuit return to the oil pan
- Pull out the oil dipstick assembly 【A】, dry the oil on the dipstick, and reinsert the dipstick tube
- ◆ Pull out the oil dipstick assembly 【A】 and check the oil level. The liquid level should be between the upper "F" level line 【B】 and the lower "L" level line 【C】

If the oil level is too high, the excess oil can be released through the oil drain plug

If the oil level is too low, you can replenish the oil through the oil filler. Using Segway Specialize Lubricant Oil Synthetic Blend Engine Oil 10W-40 is highly recommended.



Engine oil change

 Please refer to the Engine Oil Replacement Chapter in the Regular Maintenance chapter.


Remove the oil filter

 Please refer to the engine oil filter removal chapter in the regular maintenance chapter to refuel the oil filter

Clean the oil filter combination

- ◆ Disassemble
 - 【A】 Screw plugM24
 - 【B】 O-ring23×2.65
 - [C] Oil filter combination
 - 【D】 O-ring18×1.9






 Clean the coarse filter with a high flash point solvent to remove particles sticking to the filter.




Clean the filter in a well-ventilated area, and pay attention to no sparks or flames near the work area. Do not use gasoline or other low-flammability solvents to avoid the risk of fire.

TIPS

- When cleaning rough filters, check for metal particles that can damage the engine's interior
- Check the filter carefully for damage, holes, broken wires, or peeling gaskets. If the filter is damaged, replace with new parts





Oil pressure

Measure oil pressure

- ◆ Connect the oil pressure gauge connector 【C】 to the oil pressure gauge 【B】
- Clean the area around the oil pressure sensor [A] and remove the oil pressure sensor
- Connect the oil pressure gauge connector 【C】
- Start the engine, make the engine reach working temperature, observe the reading of the oil pressure gauge

Special tools:

Oil pressure gauge, 10 kgf/cm²: E01GZ0030001 Oil pressure gauge connector: E01GZ0031001

Oil pressure requirement (heat engine state)

More than 69 kPa (10psi) @1400r/min (rpm) More than 276 kPa (40 psi) @7000r/min (rpm)

- Shutdown engine.
- ◆ Remove the oil pressure gauge and connector


WARNING


When disassembling the pressure gauge connector, pay attention to prevent the hot engine oil from being scalded. The hot engine oil will flow out through the oil passage.

- Install the oil pressure sensor and tighten it to the specified torque
- ◆ Tightening torque

Oil pressure sensor

15 N·m (1.5 kgf·m, 11 ft·lb)





Oil pump


Remove the oil filter assembly

- Disassemble:
 - 【A】 Bolt M6×16
 - 【B】 Oil strainer assembly
 - 【C】 Oil strainer seal ring

Install the oil filter assembly

Put 【C】 on the 【B】 tube, the larger side of the outer ring is in contact with the upper flange surface of 【B】 Apply a proper amount of engine oil to the outer ring of 【C】, align the position of the oil hole, and press in 【B】 Install bolt 【A】, tighten it by torque Tightening torque







Remove the oil pump assembly

Disassemble

- 【A】 Bolt M6×20
- [B] Oil pump components
- Remove the bolt 【A】, turn 【B】 to an appropriate angle, and take it out after the chain is disconnected
- Disassemble:
 - 【C】Bolt M6×20
 - 【D】 Washer 6.5
 - **[E]** Oil pump driven sprocket




- ◆ Align the position of the 【E】 notch with the upper shaft of 【B】, and install 【E】 and 【D】
- ◆ Apply thread fastening glue to the thread of 【C】, screw in the bolt, and tighten it according to the torque
- ◆ Turn 【E】, it should turn flexibly and should not be stuck
- ◆ Put 【E】 into the chain, screw in the bolts 【A】 in order, and tighten to the specified torque
- ◆ Tightening torque



Bolt [C]

9.8 N•m (1.0kgf•m, 87 in•lb)




Remove the main engine oil pump rotor


- ◆ Disassemble:
 - 【A】BoltM6×20
 - 【B】 Oil pump cover I
 - 【C】 Cylindrical pin 6×10
 - 【D】 Main engine oil pump outer rotor
 - **[E]** Inner rotor of main engine oil pump
 - 【F】Roller pin

Install the main engine oil pump rotor

- ◆ Insert the needle 【F】 into the needle hole of the oil pump shaft
- ◆ Install the main engine oil pump inner rotor 【E】, main engine oil pump outer rotor 【D】, cylindrical pin 【C】 in order
- ◆ Apply sealant on the joint surface of the oil pump cover I 【B】, align the position of the pin hole and install it
- ◆ Screw in the bolt 【A】 and tighten to the specified torque in sequence
- ◆ Tightening torque

Bolt 【A】 9.8 N•m (1.0kgf•m, 87 in•lb)





Remove the auxiliary oil pump rotor

- Disassemble:
 - 【A】 Bolt M6×20
 - 【B】 Oil pump cover II
 - 【C】 Cylindrical pin 6×10
 - 【D】 Outer rotor of auxiliary oil pump
 - **[E]** Inner rotor of auxiliary oil pump
 - [F] Roller pin

Install the auxiliary oil pump rotor


- Replace with a new oil seal 【B】 and press it into the oil pump body. The sealing lip side should face inward
- Insert the oil pump shaft, the side with the threaded hole should face outward

Remove the oil pump shaft and oil seal

- [A] Oil pump shaft
- 【B】 Oil seal 11×17×4

Install the oil pump shaft and oil seal

- Replace with a new oil seal 【B】 and press it into the oil pump body. The sealing lip side should face inward
- Insert the oil pump shaft, the side with the threaded hole should face outward



Oil cooler assembly

Remove the oil cooler assembly

- Drain the engine coolant and oil
- Disassemble
 - [A] Oil cooler assembly
 - 【B】Bolt M6×40
 - [C] Bolt M6×16
 - 【D】 OO-ring 19×2.5

Install the oil cooler assembly

- ◆ Use a new O-ring and press it into the seal groove
- ◆ Align the bolt holes of the oil cooler and screw in the bolts 【B】【C】
- ◆ Tightening torque

Bolt [B] [C]

9.8 N•m (1.0kgf•m, 87 in•lb)

◆ Replenish engine coolant and oil

A CAUTION


During installation, check whether the O-ring is intact and not twisted. If the O-ring is damaged, it will cause oil leakage, which may cause abnormal wear or even damage to the internal parts of the engine. If necessary, please replace the new O-ring in time


EFI SYSTEM

E	xploded View	3-2-2
ΕI	FI SYSTEM	.3-2-4
	Disassemble the ignition coil	.3-2-4
	Disassemble the electronic throttle body assembly	.3-2-4
	Install the ignition coil	.3-2-4
	Install the electronic throttle body assembly	.3-2-4

EFI SYSTEM

Exploded view





No.	o. Fastener		Domonico		
INO.		N·m	kgf∙m	ft·lb	Remarks
1	Bolt M6×20	9.8	1.0	87 in•lb	
2	Ignition coils				
3	Electronic throttle body assembly				
4	Fuel injector				
5	Intake air temperature pressure sensor				
6	ECU				
7	Accelerator pedal assembly				

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.


R: Spare parts



EFI system


Remove the ignition coil

◆ Remove the two bolts 【A】, pull out the ignition coil
【B】




Disassemble the electronic throttle valve assembly


◆ Loosen the clamps on the intake pipes and disassemble the electronic throttle valve assembly



Install the ignition coil

- ◆ Insert the ignition coil 【B】 into the ignition coil hole of the cylinder head cover, and connect the spark plug
- ◆ Screw in the bolt 【A】 and tighten it according to the torque
- Tightening torque







Install the electronic throttle valve assembly

Loosen the clamps on the intake pipes, align the electronic throttle valve assembly with the intake pipe and insert, and tighten the two intake pipe clamps.

Exploded view	3-3-2
Special Tools	3-3-4
Remove the starter motor	3-3-5
Starting system	3-3-5
Install the starter motor	3-3-5
Disassemble the starting overload protector and the double gear assembly	3-3-6
Install starting overload protector and double gear assembly	3-3-6
Disassemble the magneto rotor	3-3-7
Install the magneto rotor	3-3-7
Check the starting overrunning clutch	3-3-7
Disassemble the starting overrunning clutch	3-3-8
Install the starting overrunning clutch	3-3-8

Exploded view





No.	Factoria		Torque		Damanisa
INO.	Fastener	N·m	kgf∙m	ft·lb	Remarks
1	Magneto rotor assembly				
2	Flat Washers 12×24×1				
3	Needle bearing HK121612				
4	Double gear shaft				
5	Starter motor				
6	Starting overload protector				
7	Starting double gear				
8	Starting overrunning clutch assembly				
9	Starting driven gear assembly				
10	Hexagon socket head screw M6×16	9.8	1.0	87 in•lb	L
11	Bolt M6×35	9.8	1.0	87 in•lb	
12	Bolt M12×1.25×30	150	15.3	111	

G: Use grease suitable for oil seals and O-rings

L: Use fastening agent.


O: Apply oil.

SS: Use silicone sealant.


S: Tighten in order.

R: Spare parts

Special Tools









Starting system

Remove the starter motor

◆ Disconnect the connecting wire harness on the starter motor and remove the two bolts 【A】




 Pull out the starter motor 【B】 and remove the starter motor




Install the starter motor

- ◆ Check whether the O-ring 【A】 at the gear end of the starter motor is intact, and apply a proper amount of engine oil on the surface of the O-ring
- ◆ Align the starter motor 【B】 with the mounting hole and insert
- ◆ Screw in two bolts 【C】 to fix the starter motor




Bolt [C]

9.8 N·m (1 kgf·m, 87 in•lb)




Disassemble the starting overload protector and the double gear assembly

◆ Remove the gasket and gear shaft, take out the double gear assembly 【A】 and the starting overload protector 【B】





Check whether the gear is damaged, check the clearance of the gear shaft hole, if the clearance is too large, you need to replace the gear assembly





Install starting overload protector and double gear assembly

- ◆ Install the gear shaft 【A】 into the starting double gear assembly 【B】 and the starting overload protector 【C】, and install shims at both ends
- ◆ After meshing the large gear of 【B】 with the small gear of 【C】, install it into the upper crankcase









Disassemble the magneto rotor

- Remove the left crankcase cover sub-assembly (see the chapter on crankcase assembly)
- ◆ Use the magneto rotor anti-rotation wrench 【A】 to fix the magneto rotor 【B】, and at the same time turn the wrench clockwise to remove the bolt 【C】
- ◆ Screw the magneto rotor puller 【D】 into the thread of the magneto rotor, fix the puller disc with a wrench, turn the puller rod with another wrench, and remove the magneto rotor


Install the magneto rotor

- Remove impurities and oil on the crankshaft installation cone and the matching cone of the magneto rotor
- Combine the magneto rotor and the overrunning clutch and align it with the crankshaft.
- Use special tools to fix the magneto rotor and tighten the mounting bolts

Bolt 150 N•m (15.3kgf•m, 111ft•lb)


Check the starting overrunning clutch

- Place the magneto rotor and the overrunning clutch on the worktable, and place the magneto rotor and overrunning clutch on the worktable on the gear surface, with the gear side facing up, and rotating the gear clockwise should rotate freely
- Rotate the gear counterclockwise, the gear should be locked in place immediately without slipping




Disassemble the starting overrunning clutch


- ◆ Take out the starting driven gear assembly 【A】 from the overrunning clutch
- Check whether the bearing surface of the starting driven gear and the bushing surface are worn, check whether the bearing surface of the starting driven gear and the bushing surface are worn and damaged



◆ Remove 8 connecting bolts 【B】 to separate the overrunning clutch from the magneto rotor



 Separate the one-way assembly from the fixing seat, and check whether the roller surface in the one-way assembly is worn or damaged



Install the starting overrunning clutch


- Assemble the starting overrunning clutch 【B】
- ◆ Apply thread fastening glue to the threaded surface of the mounting bolt 【A】, assemble the starting overrunning clutch and the magneto rotor, and tighten the bolts

Bolt **[**A**]** 9.8 N·m (1 kgf·m, 87 in•lb)


CRANKCASE\CRANKSHAFT\BALANCE SHAFT

Explosive view	3-4-3
Explosive view of Up and down the case sub-assembly	3-4-3
Explosive view of Left crankcase cover sub-assembly	3-4-5
Explosive view of Upper crankcase cover sub-assembly	3-4-7
Explosive view of Lower crankcase cover sub-assembly	3-4-8
Explosive view of Oil pan sub-assembly	3-4-9
Technical parameter	3-4-10
Special tools	3-4-11
Left Crankcase cover	3-4-12
left crankcase cover Disassembly	3-4-12
check left crankcase cover	3-4-13
install left crankcase cover	3-4-13
Crankcase\crankshaft\balance shaft	3-4-14
Crankcase Assembly	3-4-14
Remove balance shaft	3-4-16
Check balance shaft	3-4-17
Remove the crankshaft	3-4-17
Check the crankshaft	3-4-18
Mounting balancing shaft	3-4-19
Install the crankshaft	3-4-19
Crankcase assembly	3-4-20
Bearing selection	3-4-23
Group identifier	3-4-23
Bearing shell group	3-4-23
Spindle bushing selection	3-4-24
Balancing shaft bearing bush optional	3-4-24
Connecting rod bearing bush optional	3-4-24

Explosive view



Explosive view of Up and down the case sub-assembly



No.	o. Fastener Torque N·m kgf·m ft·lb		е	- Remarks	
INO.			kgf∙m	ft·lb	Remarks
1	Piston injector pressure regulating valve				
2	Piston injector assembly	20	2	14.8	
3	Bolt M6×35	9.8	1.0	87 in•lb	
4	Dowel Pin 6×10				
5	Bolt M6×75	25	2.5	18.4	
6	Bolt M6×75	9.8	1.0	87 in•lb	
7	Bolt M6×16	9.8	1.0	87 in•lb	
8	Oil Seal 13.8x2.5				
9	oil pipe assembly				
10	oil outlet pipe				
11	Screw plug M14	18	1.8	13. 3	
12	Screw plug M24	22	2. 2	16. 2	
13	Oil Seal 23x2.65				
14	Oil filter Assembly				
15	Oil Seal 18x1.9				
16	Balance shaft bushing				
17	Upper crankcase crankshaft bush				
18	Lower crankcase crankshaft bush				
19	Oil Seal 47×70×12				
20	Bolt M10×1.25×110				
21	Bolt M8×90	35	3.5	26	
22	oil pressure regulating valve				
23	Nut M10 x 1.25				
24	Stud M10×1.25×60				

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.

Explosive view of Left crankcase cover sub-assembly



No. Fastener		Torque			Domorko
INO.	i disterier	N·m	kgf∙m	ft·lb	Remarks
1	Left crankcase cover gasket				
2	Bolt M6X 35	9.8	1.0	87 in•lb	
3	Magneto stator assembly				
4	4 Steel belt elastic hose clamp 19				
5	Oil cooler inlet pipe				
6	Bolt M6X 12	9.8	1.0	87 in•lb	
7	water pipe clamp				
8	A worm drive hose hoop 50				
9	water Pump outlet pipe				
10	Oil filter	12	1.2	8.9	
11	Oil filter connector	35	3.5	17	
12	Dowel Pin 6×10				
13	Connecting water pipe joint				

14	Magneto line pressing plate				
15	hole circlip 20				
16	Deep groove ball bearings 629-2RS				
17	Bolt M6X 20	9.8	1.0	87 in•lb	
18	crankshaft position sensor				
19	O-Ring 17X2				
20	overflow pipe				
21	Bolt M6X25	9.8	1.0	87 in•lb	
22	Sensor wire harness clamp				
23	inspection cover				
24	O-Ring 35X3.5				
25	Bolt M6X 55	9.8	1.0	87 in•lb	
26	Left crankcase cover assembly				
27	OIL duct plug				
28	Aluminum Spacer 14×21×1.5				

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.

Explosive view of Upper crankcase cover sub-assembly



No.	Fastener	Torque			Remarks
INO.		N·m	kgf∙m	ft∙lb	Remarks
1	Upper crankcase cover gasket				
2	Oil gauge assembly				
3	Oil gauge pipe assembly				
4	Oil gauge pipe gasket				
5	Bolt M6×16	9.8	1.0	87 in•lb	
6	Bolt M6×25	9.8	1.0	87 in•lb	
7	Watercourse connector gasket				
8	Bolt M6X 55	9.8	1.0	87 in•lb	
9	Upper crankcase cover				
10	Watercourse connector				

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.

Explosive view of Lower crankcase cover sub-assembly



Nia	Fastener	Torque			Damanka
No.		N·m	kgf∙m	ft∙lb	Remarks
1	Lower crankcase cover gasket				
2	Lower crankcase cover assembly				
3	bolt M6×25	9.8	1.0	87 in•lb	
4	Connecting water pipe joint				
5	Aluminum Spacer 14×21×1.5				
6	ring 19X2.5				
7	Oil cooler assembly				
8	bolt M6×16	9.8	1.0	87 in•lb	
9	bolt M6×40	9.8	1.0	87 in•lb	

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.

Explosive view of Oil pan sub-assembly



No	No. Fastener		Torque	Remarks	
INO.	rasteriei	N·m	kgf∙m	ft∙lb	Remarks
1	Oil pan gasket				
2	Oil pan				
3	Bolt M6X20		1.0	87 in•lb	
4	O-Ring 13.8X2.5				
5	Screw plug M14 assembly	16	1.6	11.8	

G: Use grease suitable for oil seals and O-rings

L: Use fastening agent.

O: Apply oil.


SS: Use silicone sealant.

S: Tighten in order.

Technical Parameter

Item	Standard			
Crankcase:				
spindle bore	l group: 51.007 ~ 51.012 mm (2.0082" ~ 2.0083")			
	group: 51.012 ~ 51.017 mm (2.0083" ~ 2.0085")			
	group: 51.018 ~ 51.026 mm (2.0086" ~ 2.0089")			
Balance shaft bore	group: 41.000 ~ 41.008 mm (1.6142" ~ 1.6145") group: 41.008 ~ 41.016 mm (1.6145" ~ 1.6148")			

Special tools









Left Crankcase Cover

left crankcase cover Disassembly


◆ Loosen the clamp in two places 【B】, remove the water pump outlet pipe 【A】



◆ Loosen the clamp in two places 【C】, remove the oil cooler inlet pipe 【D】




◆ Remove 11pcs bolts for left crankcase cover



◆ Gently pry around the left crankcase cover and take the left crankcase cover out from the crankcase


A CAUTION

The magneto rotor is magnetic, so be careful when installing and removing the left crankcase cover. Do not place your finger between the left crankcase cover and the crankcase to avoid injury.



check left crankcase cover

- ◆ Check the state of bearing 【A】, wire harness【B】, stator coil 【C】.
- ◆ If you need to replace the bearing, can be heated by the left crankcase cover bearing hole or use special bearing disassembly tools to remove the bearing.




install left crankcase cover

◆ Align the left crankcase cover assembly 【B】 and the new gasket 【A】 with the positioning pins on the crankcase and load into the left crankcase cover.

A CAUTION


The magneto rotor is magnetic, so be careful when installing and removing the left crankcase cover. Do not place your finger between the left crankcase cover and the crankcase to avoid injury.



Tighten the bolts in sequence


Bolt 9.8 N·m (1 kgf·m, 87 in•lb)

Crankcase\crankshaft\balance shaft




Crankcase Assembly


◆ Remove oil drain plug 【A】 from oil pan to drain oil in oil pan.




◆ Remove 15 oil pan mounting bolts 【B】 and remove oil pan from crankcase.




- Remove the crankcase oil strainer assembly and drain the oil in the crankcase oil chamber (see lubrication System section)
- Remove the oil pump assembly (refer to lubrication System section)




◆ Remove 2 M6x55 bolts and 13 M6x25 bolts from the upper crankcase cover 【C】 and remove the upper crankcase cover.




◆ Remove 4 through-tubing mounting bolts and remove through-tubing assembly 【D】.




◆ Remove 11pcs M6 bolts and 2pcs M8 bolts from the upper crankcase




◆ Turn the crankcase and remove the 8pcs M10 bolts, 4pcs M8 bolts and 1pcs M6 bolt on the crankcase




◆ Use a rubber hammer to gently knock around the crankcase, the crankcase will be loosened after the lower crankcase up.



◆ Remove 10 bolts 【E】, take lower crankcase cover assembly 【F】.





- Remove crankshaft piston connecting rod (see crankshaft Connecting Rod Piston Assembly section).
- ◆ Remove the upper crankcase.



Remove balance shaft

◆ Slowly turn the balancing shaft 【A】 and remove the balancing shaft from the upper crankcase.






Check balance shaft

- Check whether the balance shaft gear is damaged.
- ◆ Measurement of shaft diameter 【B】, 【C】 size, the measurement of the interval of 90° in two directions. If the journal size exceeds the limit, the balance shaft needs to be replaced.
- ◆ There is journal size group identifier engraved on the balance block plane in the figure. The external test identifier is journal 【C】 size, and the internal test is journal 【B】 size.


Group identification is divided into "I" and "II", size comparison table below. If the measured size exceeds the limit, the balance shaft needs to be replaced.


Balance shaft journal dimensions				
	l II			
Standard	37.992 ~ 37.996 mm	37.996 ~ 38 mm		
values:	(1.4957" ~ 1.4959") (1.4959" ~ 1.4961")			
limit:	37.973 mm(1.495")			





Remove the crankshaft

- ♠ Remove:
- ◆ 【A】 Connecting rod bolts
- ◆ Remove the big end cover of the connecting rod.
- ◆ Carefully remove the crankshaft 【B】 from the upper crankcase.
- ◆ Remove the oil pump chain assembly on the crankshaft 【C】, oil seal 【D】, timing chain assembly 【E】.











Check the crankshaft

- ◆ Check the timing sprocket tooth 【A】, balance driving gear 【B】 and sprocket tooth 【C】 on crankshaft for damage or wear.
- ◆ If the teeth are damaged, the entire crankshaft component needs to be replaced
- ◆ Measure the size of each main shaft journal and connecting rod journal, and choose two directions at each position, 90° apart. If the journal wear exceeds the limit, the crankshaft needs to be replaced
- ◆ There are two lines of marks with a total of 6 characters on the balance block near the output end of the crankshaft. One column is the grouping mark of the main shaft journal, using numbers, and the other column is the grouping mark of the connecting rod journal, using uppercase English letters
- The following table lists the corresponding dimensions for each group. Check whether the dimensions are within the specified range. If the limits are exceeded, the crankshaft parts need to be replaced.

crankshaft journal diameter

	Spindle diameter				
	Standard	46.98-46.987 mm			
1	Statiuatu	(1.8496-1.8499 in.)			
	Limit	46.933 mm(1.8478 in.)			
	04	46.988-46.995 mm			
2	Standard	(1.8499-1.8502 in.)			
	Limit	46.947 mm(1.8483 in.)			
	0, 1, 1	46.996-47.004 mm			
3	Standard	(1.8502-1.8506 in.)			
	Limit 46.963 mm(1.8489 in.)				
	connecting rod journal diameter				
	Standard	40.992-40.997 mm			
Α	Statiuatu	(1.6139-1.6141 in.)			
	Limit	40.963 mm(1.6127 in.)			
	Ct	40.997-41.002 mm			
В	Standard	(1.6141-1.6143 in.)			
Limit		40.968 mm(1.6129 in.)			
	64 1 1	41.002-41.007 mm			
С	Standard	(1.6143-1.6144 in.)			
	Limit	40.965 mm(1.6128 in.)			





Mounting balancing shaft


- According to the grouping mark on the crankcase, select the corresponding balance bearing bush (see the optional bearing bush).
- Clean the surface of the balance shaft hole on the upper crankcase, select the corresponding group of balance shaft bush and install it into the bearing hole.
- ◆ Turn the crankshaft so that the mark 【C】 on the crankshaft gear is facing the side of the balancing shaft.
- ◆ Apply engine oil to the balance shaft journal 【A】.
- ◆ Load the balance shaft, turn it at an appropriate Angle, and align the mark 【B】 on the balance shaft gear with the mark 【C】 on the crankshaft gear.


Install the crankshaft

TIPS

Whether you are reassembling with a new crankshaft or an original crankshaft, refer to the Bush selection section (see "Crankcase Assembly" section) to select the appropriate bush.

- Install the spindle pad and press it into the crankcase main bearing seat.
- ◆ Install the spindle pad and press it into the crankcase main bearing seat.
- ◆ Put the oil pump chain guard plate 【A】 into the crankcase.
- Apply engine oil to the main bearing bush and connecting rod bush.
- ◆ Install the timing chain 【D】 and the oil pump chain【B】 on the crankshaft 【C】 sprocket.
- Place the crankshaft and chain as a whole into the upper crankcase.






◆ Install connecting rod bolts 【E】 and tighten them as required.

The connecting rod bolt


one step: 25 N·m (2.55 kgf·m, 18.4 ft·lb) two step: 45 N·m (4.59 kgf·m, 33 ft·lb) three step:Turning 60 °




Crankcase assembly


Preparation before assembly:


- Remove traces of sealant and gaskets from the crankcase sealing mating surface. Check the surface for scratches or damage.
- 2. Remove impurities such as sealant from the bolt holes.
- Install the positioning pins into the positioning pin holes
- 4. Check the oil channel to ensure that it is clean and free of impurities.







- Install crankshaft, balance shaft (refer to crankshaft connecting rod Piston Assembly, Balance shaft Assembly section)
- Apply sealant to the sealing surface at the bottom of the upper crankcase, and the track of the glue line is as shown in the figure. The glue line should be continuous and uniform.








- ◆ Align the position and load the lower crankcase.
- ◆ The rubber hammer can be gently tapped around the crankcase to ensure that there is no gap on the sealing surface of the upper and lower cases.





A CAUTION

Replace the M10 bolt each time you install the crankcase.

◆ Tighten the bolts in place in sequence.

Bolt M10


one step:: 12 N·m (1.2 kgf·m, 8.6 ft·lb) two step:: 28 N·m (2.8 kgf·m, 20.6 ft·lb) three step: turning 90°




35 N·m (3.5 kgf·m, 26 ft·lb)


Bolt M6

12 N·m (1.2 kgf·m, 106 in·lbs)



◆ Turn the crankcase and screw 2pcs M8 bolts and 11pcs M6 bolts into the upper crankcase.






◆ Tighten the bolts in sequence to the specified torque.


Bolt M8 25 N·m (2.5 kgf·m, 18.4 ft·lb)

Bolt M6

9.8 N·m (1 kgf·m, 89 in·lbs)




◆ Take a new rotary shaft oil seal 【A】 and apply a proper amount of oil to the lip and outer ring surface. With one side of the sealing lip facing inwards, press vertically into the crankcase using the crankshaft oil seal pressing tool 【B】.





- Install the oil pump assembly (see lubrication System section).
- ◆ Take a new oil pan gasket 【C】, put it into the oil pan, tighten the bolts in sequence 【D】.

Bolt [D]

9.8 N·m (1 kgf·m, 89 in·lbs)








Bearing selection

Group identifier


Crankcase grouping

◆ The upper and lower box sub-assembly has two rows of grouping marks at the output end, and one row of grouping marks for the main shaft hole, numbered 1, 2, 3 and 4. Another behavior balance shaft hole group identifier, serial number 5, 6. Mark the axle hole size with color, corresponding to the following table:




	Main shaft hole grouping					
Group NO. size color code						
I	51.007 ~ 51.012 mm	yellow				
П	51.012 ~ 51.017 mm	red				
III	51.018 ~ 51.026 mm	blue				

Balance shaft hole grouping					
Group NO. size color code					
I	41.000 ~ 41.008 mm	yellow			
II	41.008 ~ 41.016 mm	red			



Bearing shell group

- ◆ The bearing bush is grouped according to different thicknesses and the grouping marks are located on the outside of the bearing bush.
- ◆ Main shaft tile has 4 thickness, group color is red, white, blue, green.
- Balance shaft bearing bush has 3 thicknesses, group color is white, blue, green.
- Connecting rod bearing bush has 3 thicknesses, group color is white, blue, green.



Spindle bushing selection

◆ Select the appropriate crankshaft bush according to the grouping marks on the crankcase and crankshaft.

Spindle bushing selection table						
Crankcase	Crankshaft	Crankshaft main diameter grouping				
main shaft hole	1 2 3					
grouping	Correct bearing bush color identification					
yellow	blue blue Greei					
red	white blue Green					
blue	red	white	blue			


◆ The sample

Crankcase grouping 1-red, 2-red, 3-red, 4-red, 5-yellow, 6-yellow


Crankshaft grouping 2-3-3-2-A-A

According to the above table, the selected main shaft tile marks are blue, green, green and blue.

Balancing shaft bearing bush optional




Balanc	ce bearing bush matching table					
Crankcase	Balance shaft diameter grouping					
balance shaft	I	Ш				
hole grouping	Correct bearing bush color identificat					
yellow	white	Green				
red	blue	blue				



Connecting rod bearing bush optional

 According to the group mark on the connecting rod and crankshaft select the appropriate connecting rod bearing.




Connecting rod bearing bush optional form						
Connecting rod	d Crankshaft connecting rod diameter gr					
large aperture	А	A B C				
grouping	Correct bearing bush color identification					
Α	white Green Green					
В	blue	blue	white			


Exploded view	3-5-3
Explosive view of Cylinder head cover sub-assembly	3-5-4
Explosive view of Cylinder head sub-assembly	3-5-5
Explosive view of Cylinder sub-assembly	3-5-7
Explosive view of Valve Mechanism	3-5-8
Explosive view of Piston connecting rod assembly	3-5-9
Technical Parameters	3-5-11
Technical Parameter	3-5-12
Special tools	3-5-13
Cylinder head cover	3-5-14
Remove the cylinder head cover	3-5-14
Install the cylinder head cover	3-5-14
Camshaft cover / camshaft	3-5-15
Remove the tensioner	3-5-15
Install the tensioner	3-5-15
Disassemble camshaft	3-5-16
Camshaft sprocket inspection	3-5-17
Camshaft / camshaft lobe inspection	3-5-17
Install camshaft sprocket	3-5-18
Camshaft installation / timing adjustment	3-5-19
Camshaft installation/timing adjustment	3-5-19
Valve clearance adjustment	3-5-21
Optional tappet specifications	3-5-22
Selection of valve tappet	3-5-22
Intake valve clearance-valve tappet selection matrix	3-5-23
Exhaust valve clearance-valve lifter selection matrix	3-5-24
Cylinder head	3-5-25

	Cylinder head inspection	3-5-25
	Check the cylinder head deformation	3-5-25
	Remove the intake pipe assembly	3-5-26
	Install the intake pipe assembly	3-5-26
	Disassemble the thermostat and water temperature sensor	3-5-26
	Install thermostat and water temperature sensor	3-5-26
	Thermostat check	3-5-27
	Disassemble the spark plug	3-5-27
	Install spark plug	3-5-27
	Remove the valve	3-5-28
	Valve guide / valve inspection	3-5-29
	Combustion chamber cleaning	3-5-30
	Seat ring repair	3-5-31
	Seat ring inspection	3-5-31
	Seat ring repair (valve grinding)	3-5-32
	Cylinder head assembly	3-5-34
C	ylinder block and piston	3-5-35
	Cylinder block removal	3-5-35
	Cylinder block inspection	3-5-35
	Disassemble the piston	3-5-36
	Piston measurement	3-5-37
	Measure the gap of the piston ring groove	3-5-38
	Measure the piston pin	3-5-39
	Measure the closed gap of the piston ring	3-5-39
	Connecting rod measurement	3-5-39
	Piston ring installation	3-5-40
	Piston connecting rod assembly	3-5-40
	Cylinder block assembly	3-5-41
C	ylinder pressure measurement	3-5-42

Exploded view



Explosive view of Cylinder head cover sub-assembly



No.	Fastener	Torque			Remarks
INO.		N·m	kgf∙m	ft·lb	Remarks
1	Hexagon socket pan head stepped bolt	9.8	1.0	87 in•lb	
2	Washer 10.6×18×1				
3	Bolt rubber gasket 10				
4	Cylinder head cover				
5	Fuel filler cap				
6	Fuel filler cap sealing ring				
7	Cylinder head cover sealing ring				

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.

Explosive view of Cylinder head sub-assembly



No.	Fastener -	Torque			Remarks
INO.		N⋅m	kgf∙m	ft·lb	Remarks
1	Bolt M6×25	9.8	1.0	87 in•lb	
2	Type A worm drive hose hoop 70				
3	Intake pipe assembly				
4	Water temperature sensor assembly				
5	Exhaust valve				
6	Intake valve				
7	Thermostat components				
8	bolt M6×135	9.8	1.0	87 in•lb	
9	Bolt M6×20	9.8	1.0	87 in•lb	
10	Thermostat cover				
11	Exhaust port double-ended stud M8×43				
12	Copper washer 6				
13	Bolt M6×16	9.8	1.0	87 in•lb	
14	Exhaust pipe gasket 47×57×5				
15	Cylinder bolt combination M11×1.25×150				S
16	Spark plug	11	1.1	97in•lb	
17	Valve tappet				
18	Cylinder head parts				
19	Chain guide plate assembly II				
20	bolt M6×90	9.8	1.0	87 in•lb	
21	Lock clip				
22	Lock clip seat				
23	Valve spring				
24	valve spring seat				
25	valve oil seal				

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.

Explosive view of Cylinder sub-assembly



No.	Fastener	Torque			Remarks
INO.		N·m	kgf∙m	ft·lb	Remarks
1	Oil Pressure Sensor	15	1.5	11	
2	Cylindrical pin 6×10				
3	Cylinder head gasket assembly				
4	Bolt M6×25	9.8	1.0	87 in•lb	
5	cylinder block				
6	Cylinder block gasket		·		

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.

Explosive view of Valve Mechanism



No	Fastener	Torque			Domorko
No.		N·m	kgf∙m	ft∙lb	Remarks
1	Chain guide plate assembly				
2	Exhaust camshaft combination				
3	Intake camshaft combination				
4	Timing chain assembly				
5	Cylindrical pin 5×8				
6	Hexagon flange bolt M6×12	9.8	1.0	87 in•lb	L
7	Timing chain assembly				
8	Chain tensioner				
9	Tensioner gasket				
10	Tensioner gasket				
11	Bolt M6×25	9.8	1.0	87 in•lb	
12	Hexagon socket pan head stepped bolts				

G: Use grease suitable for oil seals and O-rings


L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.

Explosive view of Piston connecting rod assembly



Na	Fastener -	Torque			Damanka
No.		N·m	kgf∙m	ft·lb	Remarks
1	piston				
2	Piston pin				0
3	Piston pin retaining ring				
4	Connecting rod tile				0
5	Connecting rod bolt				
6	Half-round key				
7	Bolt M12x1.25x30-LH	150	15.3	111	
8	Crankshaft parts				
9	Connecting rod assembly				
10	Balance shaft assembly				
11	Piston ring combination				
12	Piston set				
13	Crankshaft connecting rod assembly				

G: Use grease suitable for oil seals and O-rings

L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.

S: Tighten in order.


Technical Parameters


Item	Standard	Limit
Cylinder head:		
Cylinder pressure value (use range)		
Electric starter	1.1 ~ 1.3 MPa (11~13 kgf/cm², 159~188 psi)	
Deformation of cylinder head		0.1 mm (0.004 in.)
Cylinder head height	120.5 ± 0.03 mm (4.7441" ± 0.0012")	
Seat ring seal width-exhaust	1.5 ~ 1.6 mm (0.0591" ~ 0.0630")	1.9 mm (0.0748")
Seat ring seal width-intake	1.0 ~ 1.1 mm (0.0394" ~ 0.0433")	1.4 mm (0.0551")
Seat angle	30.0° ± 1.5° / 45.0° ± 0.5° / 60.0° ± 1.5°	
Inner diameter of valve guide	5.500 ~ 5.512 mm (0.2165" ~ 0.2170")	
Valve spring:		
Free length of valve spring	42.5 mm (1.6732")	41.4 mm (1.6299")
Valve:		
Valve clearance (cold state):		
exhaust	0.20 ~ 0.25 mm (0.0079" ~ 0.0098")	
Intake	0.10 ~ 0.15 mm (0.0039" ~ 0.0059")	
Bent valve stem		TIR 0.05 mm (0.020")
Valve stem diameter:		
exhaust	5.455 ~ 5.470 mm (0.2147" ~ 0.2153")	
Intake	5.475 ~ 5.490 mm (0.2155" ~ 0.2161")	
Valve stem clearance:		
exhaust	0.030 ~ 0.060 mm (0.0011" ~ 0.0023")	
Intake	0.010 ~ 0.040 mm (0.0003" ~ 0.0015")	
Total length of valve stem:		
exhaust	96.50 mm (3.7835")	
Intake	95.50 mm (3.7598")	
Valve/valve guide clearance (swing method):		
exhaust	0.09 ~ 0.17 mm (0.0035" ~ 0.0067")	0.34 mm (0.0133")
Intake	0.03 ~ 0.11 mm (0.0012" ~ 0.0043")	0.25 mm (0.0110")


Technical Parameter


Item	Standard	Limit
Camshaft:		
Camshaft lobes height:		
exhaust	40.08 ± 0.04 mm (1.5780" ± 0.0015")	39.99 mm (1.5744")
Intake	40.36 ± 0.04 mm (1.5890" ± 0.0015")	40.27 mm (1.5854")
Camshaft journal diameter-all:	22.954 ~ 22.975 mm (0.9036" ~ 0.9045")	22.944 mm (0.9033")
Camshaft bearing bore-all:	23.000 ~ 23.021 mm (0.9055" ~ 0.9063")	23.044 mm (0.9072")
Camshaft oil clearance:	0.025 ~ 0.067 mm (0.0009" ~ 0.0026")	0.1 mm (0.0039")
Camshaft axial clearance:	0.10 ~ 0.25 mm (0.0039" ~ 0.0098")	0.4 mm (0.0157")
Camshaft journal runout	≤ 0.02 mm (0.0008")	TIR 0.1 mm (0.0039")
Piston:		
Piston outer diameter:		
I	92.951 ~ 92.959 mm (3.6594" ~ 3.6597")	92.858 mm (3.6558")
II	92.959 ~ 92.967 mm (3.6597" ~ 3.66")	92.885 mm (3.6569")
Piston pin hole inner diameter	20.009 ~ 20.018 mm(0.7877" ~ 0.7881")	20.05 mm(0.7893")
Piston pin:		
Piston pin outer diameter	20.000 ~ 20.005 mm(0.7873" ~ 0.7875")	19.98 mm(0.7866")
Piston ring		
Installation clearance:		
Top ring	0.20 ~ 0.35 mm (0.0079" ~ 0.0138")	0.5 mm (0.0197")
Second ring	0.35 ~ 0.55 mm (0.0138" ~ 0.0217")	0.7 mm (0.0276")
Oil ring	0.20 ~ 0.70 mm (0.0079" ~ 0.0276")	0.9 mm (0.0354")
Ring/groove gap:		
Top ring	0.020 ~ 0.060 mm (0.0007" ~ 0.0023")	0.12 mm (0.0047")
Second ring	0.020 ~ 0.060 mm (0.0007" ~ 0.0023")	0.12 mm (0.0047")
Piston ring groove width:		
Top ring	1.22 ~ 1.25 mm (0.0480" ~ 0.0492")	1.32 mm (0.0520")
Second ring	1.22 ~ 1.25 mm (0.0480" ~ 0.0492")	1.32 mm (0.0520")
Piston ring thickness:		
Top ring	1.17 ~ 1.19 mm (0.0461" ~ 0.0469")	1.10 mm (0.0433")
Second ring	1.17 ~ 1.19 mm (0.0461" ~ 0.0469")	1.10 mm (0.0433")


Special tools





















Cylinder head cover

Remove the cylinder head cover

- Disassembly:
- [A] Hexagon socket pan head stepped bolt
- 【B】 Washer 10.6×18×1
- 【C】 Rubber gasket 10
- [D] Cylinder head cover
- [E] Cylinder head cover sealing ring




- ◆ If oil leakage occurs, the gasket 【B】 and sealing ring 【E】 should be replaced.
- ◆ Before installing the sealing ring 【E】, apply silicone rubber to the corners of the two raised blocks.
- Sealing agent.
- ◆ Installation
- **[E]** Cylinder head cover sealing ring
- 【D】 Cylinder head cover
- 【C】 Rubber gasket 10
- 【B】 Washer 10.6×18×1
- 【A】 Hexagon socket pan head stepped bolt
- ◆ Tightening torque



Bolt [A]

9.8 N•m (1.0kgf•m, 87in•lb)




Camshaft cover / camshaft

A CAUTION

This is a non-return type timing chain tensioner. Once the push rod of the tensioner extends out of the tensioning chain, it cannot return to the initial position. Observe all the following rules:

When removing the tensioner, do not unscrew only part of the mounting bolts. Retightening the mounting bolts from this position may damage the tensioner and timing chain. After the bolts are loosened, the tensioner must be removed according to the instructions in "Timing Chain Tensioner Installation" and returned to its position.

After the tensioner is removed, do not turn the crankshaft. This may change the timing position and damage the valve




【A】 Bolt M6×25


[B] Tensioner combination

【C】 Tensioner gasket

Install the tensioner

- Remove the tensioner adjusting hole bolt 【D】, remove the O-ring 【E】 and the tension rod spring 【F】.
- ◆ Toggle the locking block 【G】, and press the adjusting rod 【H】 into the tensioner.
- Replace with a new tensioner gasket 【C】.
- ◆ Align the tensioner with the installation hole and install it, and screw in the tensioner bolt 【A】.
- Put 【E】 on the bolt 【D】, and install the spring
 【F】 and bolt 【D】 in sequence.
- ◆ Tightening torque






Chain tensioner mounting bolt

9.8 N·m (1.0 kgf·m, 87 in·lb)

Tensioner adjusting hole bolt

12 N•m(1.2 kgf•m,8.8 ft•lb)




Disassemble camshaft

- Disassembly
- 【A】 Bolt M6×16
- 【B】 Chain guide plate assembly II
- Disassembly
- 【C】Bolt M6×35
- **[D]** Camshaft cover assembly
- **[E]** Cylindrical pin 6×10



Loosen the bolts that secure the camshaft cover evenly, and carefully lift the camshaft cover from the camshaft.




◆ Remove the chain from the camshaft so that the camshaft can be taken out.

TIPS

Be careful when removing the camshaft from the cylinder head


◆ Use a tool similar to an S-shaped hook to hang the timing chain. Prevent the chain from falling into the crankcase.



TIPS

There is an integrated guide block on the crankcase to prevent the chain from falling off the crankshaft.

 Mark the intake camshaft (A) and exhaust camshaft (B) to ensure correct assembly.




Camshaft sprocket inspection

Check whether the camshaft sprocket teeth are worn or damaged. If wear or damage is found, replace the timing chain and sprocket with a new one.

Camshaft / camshaft lobe inspection


- Visually check whether the camshaft lobe is worn or damaged.
- ◆ Use a micrometer to measure the height of the camshaft lobe 【D】.



	Standard	Limit
exhaust	40.08 ± 0.04 mm (1.5780" ± 0.0015")	39.99 mm (1.5744")
intake	40.36 ± 0.04 mm (1.5890" ± 0.0015")	40.27 mm (1.5854")

- Visually inspect each camshaft journal for scratches, wear or damage.
- Measure the journal value of the camshaft with a micrometer and compare with the specification.

Standard	Limit
22.954 ~ 22.975 mm(0.9036" ~ 0.9045")	22.944 mm (0.9033")




TIPS

(D)

If the camshaft is damaged or the amount of wear on any part exceeds the limit, the camshaft should be replaced

 Assemble the camshaft cover separately to measure the bore of the camshaft bearing. Tighten the bolts in the specified order.




Camshaft	cover bolt
10 N•m (1.0	kgf•m, 89 in•lb)

Standard	Limit
23.000 ~ 23.021 mm(0.9055" ~ 0.9063")	23.044 mm (0.9072")

TIPS

If the camshaft bearing bore is damaged or the amount of wear exceeds the limit, please replace the cylinder head assembly




◆ Calculate the clearance value by subtracting the camshaft shaft diameter from the camshaft bearing bore, and compare it with the specification

Standard	Limit
0.025~ 0.067 mm (0.0009" ~ 0.0026")	0.10 mm (0.0039")

A CAUTION

Cylinder head and camshaft cover are combined processing and must be replaced as a set




Install camshaft sprocket

- ◆ Install the cylindrical pin 【C】 into the camshaft 【D】.
- Align the position of the pin hole and install the timing sprocket 【B】, with the symbol on the side facing outward.
- ◆ Apply thread tightening agent to the bolt 【A】, and tighten the bolt according to the torque.
- ◆ Tightening torque

Sprocket bolt

19 N•m (1.9 kgf•m, 14 ft•lb)




A CAUTION

If any parts in the valve train have been replaced, please refer to the valve clearance adjustment procedure sequence.


Camshaft installation / timing adjustment

Camshaft installation/timing adjustment


- Rotate the engine so that the top dead center (TDC) mark of the magneto rotor is aligned or in the center of the crankshaft position sensor (CPS) mounting hole.
- ◆ In accordance with the intake and exhaust camshaft marks made during disassembly. If you install a new camshaft or the camshaft is not marked, you can compare it with the electronic catalog according to the part number on the camshaft.
- ◆ Before installation, lubricate all camshaft tips and journal surfaces with engine oil.
- Put the intake and exhaust camshafts into the corresponding cylinder head bearing seats. Turn the camshaft so that the cam lobe points outwards.
- Installation:





- [A] Cylindrical pin 6×10
- **[B]** Camshaft cover assembly
- 【C】Bolt M6×35
- ◆ Tighten the camshaft cover mounting bolts 【C】 in order.
- Tightening torque




Bolt M6 9.8 N•m (1.0kgf•m, 87in•lb)









- ◆ Insert the camshaft fixing tool 【D】 into the camshaft end groove shown in the figure to fix the intake and exhaust camshafts. If necessary, use an open-end wrench to turn the camshaft.
- ◆ According to the method in the first step, confirm that the top dead center mark has not changed.
- ◆ Lift the timing chain and snap the sprocket into the chain. At the same time, the side of the sprocket marked with "I" and "E" is outside.
- Keep the chain tensioned as shown in the figure, install the sprocket on the camshaft, adjust the sprocket so that the top surface of the cylinder head is flush with the mark on the sprocket

A CAUTION

The "I" mark on the intake camshaft sprocket is aligned with the top surface of the cylinder head, and the "E" mark on the exhaust camshaft sprocket is aligned with the top surface of the cylinder head. Install the exhaust camshaft sprocket first (opposite the cam chain tensioner) to ensure accurate cam timing.

- ◆ Screw a bolt 【E】 into each sprocket and tighten it according to the torque. Apply thread tightening agent to the thread of the bolt 【E】.
- Install the camshaft chain tensioner (see Install the tensioner).
- ◆ Rotate the crankshaft at an appropriate angle, insert the bolt 【E】 into the other bolt hole of the sprocket, and tighten it according to the torque. Apply thread tightening agent to the thread of the bolt 【E】.

Bolt M6

9.8 N•m (1.0kgf•m, 87in•lb)


- Installation
- 【F】 Chain guide plate assembly II

【G】Bolt M6×16

Tightening torque

Bolt M6

9.8 N•m (1.0kgf•m, 87in•lb)



Valve clearance adjustment

▲ CAUTION

Before installing the camshaft or finally assembling the engine, be sure to check the valve clearance


- Camshaft installation (see camshaft installation/ timing adjustment)
- ◆ Camshaft cover installation (see camshaft installation/timing adjustment)
- ◆ Rotate the camshaft so that the lobes 【C】 and
 【D】 of the cam above the valve to be measured face up.
- Use a thickness gauge (feel gauge) to measure the valve clearance 【A】 and 【B】. If the gap exceeds the requirement, record the measurement result.
- ◆ Repeat the above steps until all valves are checked

Valve clearance requirements (cold)								
exhaust:	0.2 ~ 0.25mm (0.0079" ~ 0.0098")							
Air intake:	0.1 ~ 0.15mm (0.0039" ~ 0.0059")							

- ◆ If the valve clearance measurement does not meet the requirements, please remove the camshaft cover and camshaft.
- Remove the valve lifter that does not meet the valve clearance requirements.



In order to ensure that the parts can be installed back to the original position, the matching parts should be put together and arranged according to their position on the cylinder head. The removed parts should be marked or placed on an arranged shelf.



- ◆ Record the 3 digits 【A】 at the bottom of the tappet.
- Refer to the tappet selection matrix on the following page to select a suitable tappet.
- Install the selected tappet.
- ◆ Repeat the above steps until all valve clearances


are adjusted.

- ◆ Reinstall the camshaft and camshaft cover, and tighten the bolts as required.
- ◆ Tightening torque:

Bolt (M6) 9.8 N•m (1.0kgf•m, 87in•lb)

 Measure and confirm that each valve clearance is within the required range.

If the valve clearance is not within the required range, repeat this procedure.



Selection of valve tappet

TIPS

Valve clearance specifications and measured valve clearance are calculated in millimeters (mm). A 480 tappet means that the center thickness of the tappet **[A]** is 4.80mm.

The valve tappet part number is F01A20007XXX, and "XXX" corresponds to the specified tappet thickness. As shown in the following table:

Optional tappet specifications

Part number	F01A20007-	001	002	003	004	005	006	007	800	009	010
3 d	ligits	480	482	484	486	488	490	492	494	496	498
Part number	F01A20007-	011	012	013	014	015	016	017	018	019	020
3 d	ligits	500	502	504	506	508	510	512	514	516	518
Part number	F01A20007-	021	022	023	024	025	026	027	028	029	030
3 d	ligits	520	522	524	526	528	530	532	534	536	538
Part number	F01A20007-	031	032	033	034	035	036	037	038	039	040
3 d	ligits	540	542	544	546	548	550	552	554	556	558
Part number	Part number F01A20007-		042	043	044	045	046	047	048	049	050
3 d	ligits	560	562	564	566	568	570	572	574	576	578

	578 580		568 570	570 572	572 574	574 576																															H				\dashv
	576		566	568	570	572 5		280																				\Box	\dashv								Н			Н	\exists
	574		564	999	268	570		878	580																			Н									Н		Н	П	\exists
	572		295	264	999	268		929	228	580																		Н						Г			М		П	П	
	220		260	299	264	999		574	929	829	580																	П									П			П	
	268		258	260	562	564		572	574	929	578																	П									Г			П	
	266		929	258	260	562		570	572	574	929	580																												П	
	564		554	556	558	260		568	570	572	574	578	580																											П	
	562		552	554	556	558		999	268	929	572	576	578	580																											
	260		920	552	554	556		564	999	268	920	574	929	578	580																										
	558		548	550	552	554		558 560 562	564	999	268	572	574	576	578																										
	556		544 546	548	550	552		260	560 562	564	999	570	572	574	929	280																						L			
	554			546	548	220				562	564	568	220	572	574	578	280																					L			
	552		542	544	546	248		556	558	260	562	566	268	570	572	576	218	280																				L			
	220		540	542	544	546		554	556	558	260	564	999	568	920	574	929	578	280									Ш										L			
	546 548		536 538	540	542	544		552	554	556	258	562	564	566	268	572	574	576	278									Ш								L		L		Ш	_
	546		1 536	538	240	545		9 220	552	554	929	560	562	564	999	9 220	572	574	929	280	L																	L		Ш	_
[544	<u></u>	534	1 536	538	3 540		3 548	548 550) 552	554	558	3 560	562	564	3 568	9 220	572	574	3 578	3 580							Н	_							L		<u> </u>		\square	_
lifte	0 54	lifte	0 53;	530 532 534	534 536	6 538		544 546	6 54	8 550	550 552	4 556	6 558	8 560	560 562	564 566	9 268	8 570	0 572	4 576	6 578	8 580	0					\vdash	_									_	H	\vdash	-
the	8 54	the	8 53	0 53	2 53	4 536			4 546	6 548	8 55	2 554	4 556	6 558	8 26		4 566	9 268	8 570	2 574	4 576	6 578	8 580					\dashv									H	-	H	Н	\dashv
ts or	36 53	ts or	92	528 53	530 532	532 534		540 542	542 544	544 546	546 548	550 552	552 554	554 556	556 558	560 562	562 564	564 566	566 568	570 572	572 574	574 576	576 578	<u> </u>	H			Н	-				_				H	\vdash	H	Н	\dashv
3 dig	34 55	digi	24 52	526 52	528 53	530 53		538 54	540 54	542 54	544 5	548 55	220 26	552 56	554 55	228	260 56	562 56	564 56	568 57	570 57	572 57	574 57	578 580	280			Н									Н		H	Н	-
ns (3	32 5) SL	22 5	524 5	526 5	528 5		536 5:	538 5	540	542 5	546 5	548	550 5	552 5	556 5	558 5	260 5	562 54	566 5	568 5	570 5	572 5	576 5	578 5	280		\dashv	\dashv								Н		\vdash	Н	\dashv
atio	30 5	atio	20 5	522 5	524 5	526 5		534 5	536 5	538 5	540	544 5	546	548 5	220 2	554 5	226 5	228	260 5	564 5	566 5	568 5	570 5	574 5	576 5	578 5	280	\dashv	\dashv								Н		Н	Н	\exists
ecific	528	ecific	518	520 5	522 6	524 5		532 6	534	536	538	542 6	544	546	548	552 6	554 6	929	929	562 5	564	999	568	572 5	574 5	929	578	Н									Н		Н	Н	-
sr sp	979	r spe	516	518	520	522		230	532	534		540	545	544		9 099	552	224	929	9 999	562	564	999	9 220	572	574	929	280									П			П	\neg
iffe	524	lifte	514	516	518	520		528	530	532	534 536	538	240	545	544 546	248	220	299	554	228	260	295	264	268	220	572	574	578	280								П			П	
Existing valve lifter specifications (3 digits on the lifter	516 518 520 522 524 526 528 530 532 534 536 538 540 542	Correct valve lifter specifications (3 digits on the lifter	508 510 512 514 516 518 520 522 524 526 528 530 532	514	516	518		526	528	230	532	536	538	240	542	546	248	220	552	929	228	290	299	299	268	220	572	929	578	280										П	
ting	520	ect \	510	512	514	516		524	526	528	230	534	536	538	240	544	546	248	220	224	929	228	260	264	299	268	220	574	9/9	578	580									П	
Exis	518	Sol		510	512	514		522	524	526	528	532	534	536	538	542	544	546	548	552	554	556	558	562	564	566	568	572	574	576	578										
	516		206	208	510	512		520	522	524	526	530	532	534	536	540	542	544	546	220	552	554	556	260	562	564	999	570	572	574	576	280								Ш	
	514		504	206	208	510		518	520	522	524	528	530	532	534	538	540	545	544	548	220	552	554	228	558 560	560 562	564	268	570	572	574	578	280					L		Ш	
	512		502	504	206	208		516	518	520	522	526	528	530	532	536	538	540	542	546	548	220	552	256	$\overline{}$		299	999	568	570	572	576	578	280	_			L		Ш	_
	3 510		3 200	205	504	1 506		514	1 516	5 18	3 520	524	1 526	3 528	3 230	534	1 536	3 538	3 540	544	1 546	548	3 220	2 554	1 556	3 558	3 560	564	1 566	568	3 570	574	1 576	5 578	3 580					\square	\perp
	9 208		6 498	8 500	0 502	2 504		0 512	2 514	4 516	6 518	0 522	2 524	4 526	6 528	0 532	2 534	4 536	6 538	0 542	2 544	4 546	6 548	0 552	2 554	4 556	6 558	0 562	2 564	4 566	9 268	0 572	2 574	4 576	6 578	-	H	_	Ш	\square	-
	4 506		4 496	6 498	8 500	0 502		8 510	0 512	2 514	4 516	8 520	0 522	2 524	4 526	8 530	0 532	2 534	4 536	8 540	0 542	2 544	4 546	8 550	0 552	2 554	4 556	8 560	0 562	2 564	4 566	8 570	0 572	2 574	4 576	8 580	0	-	H	Н	\dashv
	502 504		92 494	94 496	496 498	498 500		506 508	508 510	510 512	512 514	516 518	518 520	520 522	522 524	526 528	528 530	530 532	532 534	536 538	538 540	540 542	542 544	546 548	548 550	550 552	552 554	556 558	558 560	560 562	562 564	566 568	568 570	570 572	572 574	576 578	578 580	280	Н	H	\dashv
	500 50		490 492	492 494	494 48	496 46		504 50	206 50	508 51	510 51	514 51	516 51	518 52	520 52	524 52	526 52	528 53	530 53	534 53	536 53	538 54	540 54	544 54	546 54	548 55	550 55	554 55			560 56	564 56	566 56	568 57	570 57	574 57	576 57	578 58	580	H	\dashv
	498 5		488 4	490 4	492 4	494		502 5	504 5	506 5	508 5	512 5	514 5	516 5	518 5	522 5	524 5	526 5	528 5	532 5	534 5	536 5	538 5	542 5	544 5	546 5	548 5	552 5	554 5		558 5	562 5	564 5	566 5	568 5	572 5	574 5	576 5	578 5	Н	\dashv
	496		486 4	488 4	490 4	492 4		200	502 5	504 5	506 5	510 5	512 5	514 5	516 5	520 5	522 5	524 5	526 5	530 5	532 5	534 5	536 5	540 5	542 5	544 5	546 5	550 5	552 5	554 5	556 5	560 5	562 5	564 5	566 5	570 5	572 5	574 5	576 5	280	\exists
	494		484	486 4	488 4	490 4			500 5	502 5	504	508 5	510 5	512 5	514 5	518 5	520 5	522 5	524 5	528 5	530 5	532 5	534 5	538 5	540 5	542 5	544 5	548 5	550 5	552 5	554 5	558 5	560 5	562 5	564 5	568 5	570 5	572 5	574 5	578 5	580
	492 4		482 4	484	486 4	488 4		496 498	498	200	502	506	208	510 5	512	516	518	520	522	526	528	530	532	536	538	540	542	546	548	9 220	552	556	558	560	562	566	568	570	572	576	578
	490		480	482	484	486		494	496	498	200	204	909	208	510	514	516	518	520	524	526	528	230	534	536	538	240	544	546	248	220	554	929	228	260	264	999		570	574	929
	488		Ť	480	482	484		492	494	496	498	502	504	909	208	512	514	516	518	525	524	526	528	532	534	536	538	542	544	546	548	552	554	929	258	295	264		268	572	574
	486				480	482		490	492	464	496	200	502	504	909	510	512	514	516	520	522	524	526	530	532	534	536	540	542	544	546	220	552	554	556	260	562	564	566	929	572
	484					480		488	490	492	494	498	200	502	504	508	510	512	514	518	520	522	524	528	530	532	534	538	540	542	544	548	550	552	554	558	260	562	564	568	929
	482		Ŀ	•	•	•	dard)	486	488	490	492	496	498	200	502	909	508	510	512	516	518	520	522	526	528	530	532	536	538	540	542	546	548	220	552	556	558	260	562	999	268
	480				'		(Standard)	484	486	488	490	494	496	498	200	504	909	508	510	514	516	518	520	524	526	528	530	534	536	538	540	544	546	548	220	554	556	558	560	564	999
			0.024	0.049	0.074	0.099	150،150	0.175	0.176-0.200	0.201-0.225	0.250	0.275	0.276-0.300	0.301-0.325	0.350	0.375	0.376-0.400	0.401-0.425	0.450	0.451-0.475	0.476-0.500	0.501-0.525	0.550	0.551-0.575	0.576-0.600	0.601-0.625	0.625-0.650	0.651-0.675	0.676-0.700	0.725	0.750	0.751-0.775	0.800	0.825	0.850	0.851-0.875	0.900	0.925	0.950	0.975	1.000
			0.000-0.024	0.025-0.049	0.050-0.074	0.075-0.099	0.100-0.150	0.151-0.175 484	0.176-	0.201-	0.226-0.250 490	0.251-0.275	0.276-	0.301-	0.326-0.350	0.351-0.375	0.376-	0.401-	0.426-0.450	0.451-	0.476-	0.501-	0.526-0.550	0.551-	0.576-	0.601-	0.625-	0.651-	-929.0	0.701-0.725	0.726-0.750	0.751-	0.776-0.800	0.801-0.825	0.826-0.850	0.851-	0.876-0.900	0.901-0.925	0.926-0.950	0.951-0.975	0.976-1.000
			Ė				ر ر		<u> </u>	<u> </u>						_					_			ore											<u> </u>						\neg
																_		F	-2	2															-			-			
_	_	_				_					_	_					3 –	:1										_								_	_	$\overline{}$			

Intake valve clearance-valve tappet selection matrix

564 566 568 572 574 576

568 570 572 574 576 578 564 566 560 562 564 566 266 568 576 578 578 580 550 552 552 554 226 228 562 564 560 562 576 580 554 558 572 574 578 580 576 540 542 544 5 542 544 546 5 546 548 550 5 550 552 554 5 554 556 536 538 538 540 542 544 548 550 550 552 580 532 534 534 536 538 540 542 544 544 546 546 548 572 528 530 530 532 540 542 534 536 542 544 550 552 554 556 564 566
 520
 522
 524
 526
 55

 522
 524
 526
 528
 5
 570 556 Existing valve lifter specifications (3 digits on the lifter) Correct valve lifter specifications (3 digits on the lifter) 526 528 530 518 520 524 526 530 532
 502
 504
 506
 508
 510
 512
 514
 516


 504
 506
 508
 510
 512
 514
 516
 518
 516 518 510 512 518 520 520 522 538 540 540 542 542 544 544 546 548 550 550 552 552 554 554 556 560 562 562 564 510 512 514 514 516 518 538 540 542 548 504 506 508 510 512 536 538 554 556 532 534 550 552 514 516 518 520 526
 488
 490
 492
 494
 4

 490
 492
 494
 496
 4
 534 536 538 540 5 536 538 540 542 5
 496
 498

 498
 500

 502
 504
 504 506 508 528 530 530 532 534 536 536 538 544 546 0.676-0.800 516 518 520 522 524 526 528 530 532 534 536 538 539 540 542 544 546 548 540 0.001-0.002 518 520 525 524 526 528 520 525 534 536 538 530 540 542 544 546 546 550 266 568 554 556 558 560 492 494 498 500 500 502 502 504 526 528 554 556 494 496 500 502 504 506 508 510 512 524 526 532 534 540 542 550 552 562 564 496 498 544 546 536 538 540 542 544 546 548 488 490 492 494 496 498 500 506 508 510 512 514 516 518 508 510 512 514 516 518 520 520 522 500 502 504 506 508 510 512 514 516 518 520 522 524 528 530 522 524 526 528 530 532 534 528 530 532 534 536 538 550 552 552 554 558 560 510 512 514 526 528 540 542 486 488 490 492 494 510 512 514 516 518 506 508 510 512 514 516 518 520 522 524 526 540 542 544 546 548 548 550 552 554 556 - - 480 544 546 548 550 480 482 484 486 522 524 486 488 516 518 520 534 536 538 546 548 550 552 554 556 488 490 492 540 542 544 546 482 484 484 486 510 512 514 516 518 520 528 530 532 534 536 538 540 542 544 546 496 498 522 524 532 534 536 538 512 514 516 0.251-0.275 | 484 | 486 | 488 | 490 492 494 484 486 498 500 502 504 508 510 514 516 518 520 538 540 544 546 , 504 506 522 524 524 526 534 536 538 540 528 530 544 546 486 488 488 490 492 494 494 496 496 498 498 500 508 510 526 528 530 532 540 542 546 548 0.200-0.250 (Standard) 0.625-0.650 0.676-0.700 0.050-0.074 0.100-0.124 0.125-0.149 0.150-0.174 0.175-0.199 0.301-0.325 0.326-0.350 0.351-0.375 0.376-0.400 0.401-0.425 0.426-0.450 0.451-0.475 0.476-0.500 0.501-0.525 0.526-0.550 0.551-0.575 0.651-0.675 0.701-0.725 0.726-0.750 0.751-0.775 0.776-0.800 0.801-0.825 0.826-0.850 0.851-0.875 0.876-0.900 0.976-1.000 0.025-0.049 0.075-0.099 0.276-0.300 0.901-0.925 valve clearance (mm)before adjustment

Exhaust valve clearance-valve lifter selection matrix




Cylinder head

Remove the cylinder head

TIPS

Maintenance of the cylinder head can be carried out on the entire vehicle.

- Disassembly:
- 【A】 Bolt M6×90
- 【B】 Cylinder bolt M11×1.25×150
- 【C】Bolt M6×16
- ◆ Remove the cylinder head 【D】, if necessary, you can use a plastic hammer to tap the cylinder head lightly to loosen the cylinder head for easy removal.
- ◆ Remove the cylinder head gasket 【E】.





Thoroughly clean the cylinder head gasket material and carbon deposit marks on the bottom surface of the cylinder head.



- ◆ Keep the bottom surface of the cylinder head clean.
- ◆ Place a ruler 【F】 on the bottom surface of the cylinder head.
- Use a feeler gauge to measure the distance between the ruler [F] and the different positions of the cylinder head.

Cylinder head deformation limit: 0.1 mm (0.0039"). If the cylinder head deformation exceeds the limit, replace the cylinder head.






Remove the intake pipe assembly

- ◆ Disassembly:
- 【A】 Bolt M6×25
- 【B】 Intake pipe assembly

Install the intake pipe assembly


- ◆ Install the intake pipe assembly 【B】, and tighten the bolt 【A】.
- ◆ Tightening torque

Intake pipe assembly bolt 9.8 N·m (1.0 kgf·m, 87 in·lb)



Disassemble the thermostat and water temperature sensor

- Disassembly:
- 【A】 Bolt M6×20
- 【B】 Thermostat cover
- [C] Thermostat
- **[D]** Water temperature sensor assembly



Install thermostat and water temperature sensor


- ◆ Install the thermostat 【C】, the vent of the thermostat should be upward when installing, aligned with the notch on the cylinder head.
- ◆ Install the thermostat cover 【B】, and tighten the bolt 【A】.
- Install the water temperature sensor assembly
 [D], and apply thread sealant when installing.
- ◆ Tightening torque

Thermostat cover bolt


9.8 N•m (1.0kgf•m, 87 in•lb)


Water temperature sensor assembly

12 N•m (1.2kgf•m, 107 in•lb)



ABB





Thermostat check

- Remove the thermostat and check the thermostat
 [A] at room temperature.
- ◆ If the thermostat is turned on, please replace it with a new one.
- Check the opening temperature of the thermostat, put the thermostat 【A】 and an accurate thermometer 【B】 into the water, and adjust the temperature sensing part to the same height.
- Gradually increase the temperature of the water while gently stirring the water to make the temperature even.
- lacktriangle Thermostat opening temperature 79 \sim 92 $^{\circ}$ C (174 \sim 197 $^{\circ}$ F)
- ◆ If the measurement is out of range, replace the thermostat.

Disassemble the spark plug

Disassembly:

[A] Spark plug

A CAUTION

Never let the spark plug fall on a hard surface. Such an impact can damage the parts.

TIPS

When removing the spark plug, put a rag on the spark plug hole to prevent anything from falling into the combustion chamber.


Install spark plug

- Apply anti-rust agent to the spark plug thread.
- Install spark plugs.
- Tightening torque:

Spark plug

11 N•m (1.1kgf•m, 97in•lb)

- Spark plug inspection:
- ◆ Spark plug electrode gap: 【H】=0.7 ~ 0.9



▲ WARNING


Remove the valve

When disassembling and assembling the cylinder head or operating the valve spring, you need to wear goggles.

TIPS


In order to ensure that the parts can be installed back to the original position, the matching parts should be put together and arranged according to their position on the cylinder head. The removed parts should be marked or placed on an arranged shelf.

- ◆ Remove the valve lifter 【G】 from the cylinder head.
- ◆ Use the valve spring compressor 【H】 to press down the valve spring.
- Remove the valve lock clamp [I].
- Slowly release the valve spring compressor and remove the compressor.
- Remove the lock clamp seat [J], valve spring [K], valve spring seat [L] and valve oil seal [M].





TIPS

As long as the cylinder head is disassembled, the valve oil seal is replaced. Aging, cracking or abrasion of the valve oil seal will lead to increased oil consumption



- ◆ Lift the cylinder head, take out the valve 【N】, and place it in an orderly manner so that it can be reinstalled in the same valve guide.
- Repeat the previous steps to remove the remaining valves.
- ◆ Clean the combustion chamber of the cylinder head and the bottom surface of the cylinder head.






◆ Free length of valve spring:standard:1.726" (43.85 mm), service limit:1.683" (42.75 mm)


Standard	Limit
42.5 mm (1.6732")	41.4mm (1.6299")

Valve guide / valve inspection

♦ Valve stem clearance measurement:

If there is no small aperture gauge, use the swing method to measure the gap between the valve and the valve guide and check the wear of the valve guide. The method is as follows.







Repeat the measurement in the direction at right angles to the first direction. If the reading exceeds the use limit, replace the cylinder head and camshaft cover assembly.





The reading is not the true gap between the valve and the valve guide, because the measurement position is above the guide.




- Measure the beating, pitting and ablation of the valve stem. Check whether the valve rod is bent, clamp the valve on the machine tool or use a "V" block and measure it with a dial indicator.
- ◆ Check whether there is flaring, pitting, abrasion or damage at the end of the valve stem.
- ◆ Check whether there is flaring or abrasion at the lock clip groove. .












If necessary, the valve can be re-dressed or ground. If it is severely worn, burned, bent or damaged, it must be replaced

◆ Use a micrometer to measure the diameter of the valve stem at three places, and then turn it 90° to measure again (a total of six measurements), and compare with the standard value.

Valve stem diameter:							
	Standard	Limit					
exhaust	5.455 ~ 5.470 mm (0.2147" ~ 0.2153")						
intake	5.475 ~ 5.490 mm (0.2155" ~ 0.2161")						



1	Valve guide	aperture:	
5.500 -	- 5.515 mm(0	0.2165" ~ 0.2171")	_

 Measure each valve and valve guide combination separately.




The valve guide cannot be replaced.



WARNING

Wear protective goggles when cleaning the combustion chamber.

- Clean all carbon deposits in the combustion chamber and valve seat area.
- Visually inspect the surface of the cylinder head gasket and the combustion chamber for cracks or damage. Pay close attention to the spark plug and seat ring area.



A CAUTION

Do not use metal scrapers, thick wire brushes or abrasive cleaners to clean the cylinder head. May cause damage.

Seat ring repair

◆ Seat ring repair should be carried out by professionals who are proficient in cylinder head repair technology. Repair techniques vary, so please follow the valve repair equipment manufacturer's instructions. Do not over-grind the seat ring.

▲ WARNING

When disassembling and reassembling the cylinder head, wear goggles or face shield.

Seat ring inspection

- Remove the valve.
- ◆ Check the contact surface 【A】 between the valve 【B】 and the seat ring 【C】.
- Paint the seat ring.
- Push the valve into the valve guide.
- Use a grinding tool to press and rotate the valve relative to the seat ring.
- ◆ Take out the valve and check the pattern of the contact surface on the seat ring. The width of the entire circle must be appropriate.
- Measure the diameter of the outer ring of the contact surface on the seat ring 【D】.
- If the outer diameter of the seat ring contact surface is too large or too small, repair the seat ring (see seat ring repair).

Outer diameter of seat ring contact surface	
exhaust	31.8 ~ 31.9mm (1.2520" ~ 1.2559")
intake	36.8 ~ 36.9mm (1.4488" ~ 1.4528")


TIPS

The valve stem and valve guide must be good, otherwise the check will be inaccurate.

- ◆ If the seat ring interface shape is not good, repair the seat ring (see seat ring repair).
- Use a vernier caliper to measure the width of the part without carbon deposits (bright part) on the seat ring [E].

Width	of contact surface of seat ring
Exhaust	1.5 ~ 1.6mm (0.0591" ~ 0.0630")
intake	1.0 ~ 1.1mm (0.0394" ~ 0.0433")

If the width is too wide, too narrow or uneven, repair the valve seat (see valve seat repair)



[F] Good

【G】 Too wide

【H】 too narrow

[J] Uneven

Seat ring repair (valve grinding)

- ♦ Insert the guide into the valve guide.
- Apply cutting oil to the seat ring and tool.
- ◆ Place the 46° tool on the guide and perform light cutting.
- ◆ Check the cutting area of the seat ring:

If the contact area is less than 75% of the full circle of the seat ring, turn it 180° and do another light cut.

If the tool touches the uncut part of the seat ring, check the guide. Check for burrs, scratches, or excessive jumps. If the guide is bent, it must be replaced.

If the contact surfaces of the tools are all in the same position, it means that the valve guide has been deformed due to improper installation.

If the initial cutting contact area is greater than 75%, continue cutting the seat ring until all dents are removed and a clear seat ring surface appears.

- ◆ To check the contact area on the valve, apply a thin layer of Prussian Blue™ paint on the valve seat ring. If the interference angle is 46°, paint a black permanent mark 【A】 on the entire valve disc surface.
- ◆ Insert the valve into the catheter and tap the valve into place several times.
- Remove the valve, and use the paint on the valve to confirm where the valve is in contact with the seat ring. The seat ring should touch the middle or slightly higher position of the valve disc surface, and the width should be appropriate

If the contact position is at the top edge of the valve disc surface to the unpainted area [B], it indicates that the contact position between the valve disc surface and the seat ring is too high. At this time, use a 30° tool to lower the seat ring.

If it is too low, use a 60° tool to raise the seat ring. When the contact area is concentrated on the valve surface, measure the width of the valve seat.

If the seat ring contact surface is too wide or uneven, cut the top and bottom to narrow the seat ring.


If the seat ring contact surface is too narrow, use a 45° tool to widen it, and recheck the valve surface and the contact surface width on the seat ring after each cut.


A

Good contact surface

TIPS

If it is an interference angle, under normal circumstances, the contact surface on the valve disc surface will be very narrow. A uniform and continuous contact surface **[A]** can be seen on the valve disc surface.





[A] 30°

[B] 45°

[C] 60°

【D**】** 1.0 ~ 1.1mm (0.0394" ~ 0.0433")

limit: 1.4mm (0.055")

[A] 30°

【B】 45°

[C] 60°

[E] 1.5 ~ 1.6mm (0.0591" ~ 0.0630")

limit: 1.9mm (0.075")

- ◆ Wash all the fillings in the area with hot soapy water, and then blow it off with compressed air.
- ◆ Lubricate the valve guide with clean engine oil, and apply an oil-based or water-based abrasive on the valve disc surface.


TIPS


If the interference angle repair method is used, no grinding is required.


- Use a grinding tool or a section of fuel line connected to the valve stem to insert the valve into the respective guide rail and grind it.
- ◆ Rotate the valve back and forth quickly until the cutting sound is smooth. Lift the valve slightly away from the seat, rotate it 1/4 turn, and repeat the grinding process. Do this 4 to 5 times until the valve is completely seated and the surface of the valve seat is smooth, and then repeat this process for other valves.
- ◆ Thoroughly clean the cylinder head and valve.


CAUTION

Don't grind too much. Excessive grinding will cause the valve to sink into the cylinder head, thereby reducing the valve clearance. If the valve is sunk too deep, the clearance cannot be adjusted and the cylinder head must be replaced.









Cylinder head assembly

▲ WARNING

When disassembling and assembling the cylinder head or operating the valve spring, you need to wear goggles.

- ◆ Install a new valve oil seal 【C】 on the valve guide, and press the valve oil seal into place with a special tool.
- ◆ Apply engine oil to the valve stem, and insert the exhaust valve 【A】 and intake valve 【B】 into the corresponding valve guides.
- ◆ Install the valve spring seat 【D】, valve spring 【E】, lock clip seat 【F】, and lock clip 【G】 in sequence.
- ◆ Use special tools to compress the spring until there is enough space to install the valve lock clip.
- Clamp a pair of valve lock clamps into the valve lock clamp groove.
- ◆ Repeat the above steps to install the remaining valves in place.

A CAUTION

The valve spring is marked with a mark or the end with a larger pitch is facing upwards.

- ◆ To install the valve lifter, refer to the chapters of "Valve Clearance Adjustment" and "Selection of Lifter".
- ◆ Align the positioning pins on the cylinder block and place the cylinder head gasket 【Ⅰ】. The gasket should be clean and free of grease.
- Align the position of the positioning pin, and place the cylinder head 【J】. Install new cylinder head bolts 【L】 and tighten them in order.
- ◆ Install the bolts 【K】 and 【M】 at both ends and tighten them according to the torque.


Cylinder head bolt [L]

first step: 12N·m(1.2 kgf·m, 8.8 ft·lb)
Second step: 35N·m(3.57 kgf·m, 25.8 ft·lb)
Step 3: Rotate 180°


◆ Bolt 【K】 and 【M】 tightening torque:


Bolt [K], [M]

9.8 N·m (1.0 kgf·m, 87 in·lb)



B





Cylinder block and piston

Cylinder block removal


- Remove the cylinder head gasket 【A】.
- Remove the two M6 connecting bolts 【B】.
- ◆ Disassemble the crankshaft (see the chapter of crankshaft connecting rod piston assembly).
- ◆ Take out the cylinder block and piston as a whole from the crankcase, and remove the cylinder block gasket 【C】.
- Remove the piston and connecting rod assembly from the cylinder block.


TIPS

If the piston will continue to be used, please make a mark according to the installation position during disassembly, so that the same cylinder position can be installed in the next assembly.

Cylinder block inspection


- ★ Keep the top surface of the cylinder block clean, place a ruler 【A】 on the top surface of the cylinder block, and measure the distance between the ruler 【A】 and different positions of the cylinder block with a feeler gauge. Cylinder head deformation limit: 0.05 mm (0.002"). If the cylinder head deformation exceeds the limit, replace the cylinder block.
- Check the cylinder bore for wear, scratches or damage.
- Measure the inner diameter of the cylinder hole according to the three heights shown in the figure (【B】 is 15mm from the top surface, 【C】 is in the middle, and 【D】 is 15mm from the bottom),






Cylinder hole grouping marks (I or II) are marked on the steps on the intake side of each cylinder of the cylinder block. According to the cylinder hole measurement results and the corresponding group size comparison, if the measured value of any cylinder hole exceeds the use limit, please replace it cylinder block.





Cylinder hole diameter:		
standard:	Ι	92.992 ~ 93.000 mm (3.6611" ~ 3.6614")
	П	93.000 ~ 93.008 mm (3.6614" ~ 3.6617")
Limit:	Ι	92.927 mm (3.6585")
	Ш	99.935 mm (3.6589")

Roundness limit:	0.025(0.001")
Cylindricity limit:	0.025(0.001")




Disassemble the piston


- Disassemble the cylinder block (see Cylinder Block Disassembly), and remove the piston connecting rod assembly.
- ◆ Put a clean cloth under the piston and remove the piston pin circlip 【A】 from the piston.

A CAUTION

Do not reuse the circlip, because disassembly will weaken and deform the elastic force of the circlip. They may fall off and damage the cylinder bore wall.




- ◆ Remove the piston pin 【B】.
- Remove the piston.




- ◆ Use your fingers to carefully open the opening of the piston ring 【C】, then lift the piston ring up and remove it from the piston.
- ♦ Remove the remaining piston ring in the same way.

A CAUTION

When disassembling the piston ring, do not open it too much, so as not to damage the piston ring or reduce the tension of the piston ring.




◆ The oil ring assembly 【D】 is composed of two upper and lower blade rings and an intermediate liner ring. When disassembling, first remove the upper blade ring, then the lower blade ring, and finally the intermediate liner ring.




Piston measurement

◆ Measure the diameter of the piston pin hole in two directions (90° apart). If the limit is exceeded, the piston needs to be replaced.

Piston pin hole diameter	
standard value:	20.009 ~ 20.018 mm(0.7877" ~ 0.7881")
Limit:	20.05 mm(0.7893")



 Measure the diameter of the large-diameter detection area on the piston, and record the measurement result.



Check the grouping mark on the top surface of the piston, and compare the measurement result with the grouping value of the outer diameter of the piston. If it exceeds the limit, it needs to be replaced.

Piston diam	eter	
	standard	Limit
group I:	92.951 ~ 92.959 mm (3.6594" ~ 3.6597")	92.858 mm (3.6558")
group II:	92.959 ~ 92.967 mm (3.6597" ~ 3.66")	92.885 mm (3.6569")

Measure the gap of the piston ring groove

- ◆ The piston ring should be parallel to the surface of the piston ring groove. If not, you need to replace the piston and piston ring.
- ◆ The piston ring is placed in the piston ring groove, and the feeler gauge is used for multiple measurements to determine the piston ring/groove gap.

Piston ring groove clearance:	
Top ring:	0.020 ~ 0.060 mm (0.0007" ~ 0.0023")
second ring:	0.020 ~ 0.060 mm (0.0007" ~ 0.0023")
limit:	0.12 mm (0.0047")

If the piston ring groove gap is greater than the use limit, measure the thickness of the piston ring and the width of the ring groove according to the following methods to determine whether to replace the piston ring or the piston or at the same time.


Piston ring groove width


 Measure multiple positions on the piston with a caliper.


Piston ring groove width		
	standard	Limit
Top ring:	1.22 ~ 1.24 mm	1.31mm
second ring:	(0.0480" ~ 0.0489")	(0.0516")


- ◆ If the width of any ring groove exceeds the limit, the piston needs to be replaced. Piston ring thickness
- Use a micrometer to measure multiple positions on the piston ring.


·	_	
	Piston ring thickness	
	standard	Limit
Top ring:	1.17 ~ 1.19 mm	1.10mm
second ring:	(0.0461" ~ 0.0469")	(0.0433")











Measure the piston pin

◆ Measure the diameter of the piston pin in three positions and two directions (90° apart). If the limit is exceeded, the piston pin needs to be replaced.

	Piston pin diameter
standard:	20.000 ~ 20.005 mm(0.7873" ~ 0.7875")
limit:	19.98 mm(0.7866")

Measure the closed gap of the piston ring

- ◆ Use the piston to push the piston ring 【B】 into the cylinder bore 【A】.
- Use a feeler gauge to measure the closed gap
 when the piston ring is at the top and bottom of the cylinder bore.

TIPS

After the cylinder bore is worn and deformed, there will be a difference between the closed gap of the piston ring at the top and bottom of the cylinder bore. At this time, the cylindricity and roundness of the cylinder bore should be measured to determine whether the cylinder can continue to be used.

If the closed gap of the piston ring exceeds the limit, a new piston ring needs to be replaced.

Piston ring closed gap		
	standard	limit
first air ring:	0.25 ~ 0.35 mm(0.01" ~ 0.014")	0.5 mm(0.02")
The second air ring:	0.35 ~ 0.5 mm(0.014" ~ 0.02")	0.7 mm(0.028")
Oil ring	0.2 ~ 0.7 mm(0.008" ~ 0.028")	0.9 mm(0.035")


Connecting rod measurement


Measure the inner diameter of the small end hole of the connecting rod. If the limit is exceeded, the connecting rod needs to be replaced.

Connecting rod small head aperture	
standard:	20.015 ~ 20.030 mm(0.7879" ~ 0.7885")
limit:	20.06 mm(0.7897")

- Install the corresponding connecting rod cover (without bearing bushes), and screw in the connecting rod bolts.
- ◆ Tighten the connecting rod bolts to 25Nm (2.5 kgf·m, 18.4 ft·lb).
- Measure the diameter of the big end of the connecting rod. If it exceeds the limit, the connecting rod needs to be replaced.

Big head aperture of connecting rod			
standard:	44 ~ 44.016 mm(1.7323" ~ 1.7329")		
Limit::	43.96 mm(1.7307")		






Piston ring installation

TIPS

When installing the piston ring, apply clean engine oil to the surface. Check the clearance of the piston ring groove (see "Measuring the clearance of the piston ring groove"). If assembling a used piston, the carbon deposits in the piston ring groove and the oil hole of the oil ring groove should be cleaned first

- ◆ Install the oil ring backing ring 【B】 in the bottom piston ring groove so that the two ends are butt (not overlapping), and turn the backing ring so that the opening faces the engine output end.
- ◆ Install the bottom wiper ring 【A】 and turn it so that the ring port faces the intake side of the piston.
- ◆ Install the upper wiper ring 【C】 and turn it so that the ring opening faces the exhaust side of the piston.
- Install the second air ring, the side with the mark on the ring faces upwards, and turn it so that the ring opening faces the air inlet side.
- ◆ Install the first air ring, the side with the mark on the ring faces upwards, and turn it so that the ring opening faces the exhaust side.




Piston connecting rod assembly


- Piston pin hole, connecting rod small end hole, and piston pin are smeared with clean engine oil.
- Insert the piston pin and install the new piston pin retaining ring. Turn the retaining ring so that the opening faces upward or downward.

A CAUTION

Do not reuse the piston pin retaining ring, as the retaining ring will be deformed during disassembly.

Do not over-compress the retaining ring during installation, so as not to reduce the radial elastic force of the retaining ring





Cylinder block assembly

- ◆ According to the grouping mark of cylinder bore and piston, select the combination of piston and cylinder block in the same group. For example, the pistons of group "I" correspond to the cylinder bores of group "I", and the pistons of group "II" correspond to the cylinder bores of group "II".
- After the piston connecting rod assembly is installed, press the piston ring with your fingers, and carefully insert the piston into the cylinder hole from the bottom of the cylinder block.

A CAUTION

There is a triangle mark on the top surface of the piston, and the arrow points toward the exhaust side during installation.

- ◆ Keep the sealing surface clean, align the position of the positioning pin, and install a new cylinder block gasket 【A】.
- ◆ Install the assembled piston and cylinder block assembly 【C】 into the upper crankcase.
- Screw in the bolt 【B】 and tighten it according to the torque.

Bolt (B)

9.8 N·m (1.0 kgf·m, 87 in·lb)

Cylinder pressure measurement

TIPS

Fully charge the battery before measuring

- ◆ Warm up the engine completely, then stop it.
- Disassemble the spark plug (refer to the spark plug chapter).
- ◆ Connect the cylinder pressure gauge and the connector firmly to the spark plug hole.
- ◆ Special tools-cylinder pressure gauge, cylinder pressure gauge connector.
- ♦ Keep the throttle fully open and use the starter motor to drive the engine several times.
- ♦ When the pressure gauge stops rising, stop rotating and read the pressure value.

Cylinder pressure (reasonable range)				
Electric starter:	1.1 ~ 1.3 MPa (11~13 kgf/cm², 159~188 psi)			


If the pressure value obtained is not within a reasonable range, you should refer to the following table.


problem	diagnosis	Measures (actions)		
Cylinder pressure value is out of	Due to the valve oil seal and/or piston oil ring damage, the piston, cylinder head and combustion chamber produce carbon deposits (can be determined by the white smoke exhaust).	Remove carbon deposits and replace damaged parts if necessary.		
reasonable range	The thickness of the cylinder head gasket is incorrect.	Replace with standard gaskets.		
	the valve spring is damaged or the elastic force fails,	replace the spring.		
	Air leakage around the cylinder head	Replace the damaged cylinder head gasket and check for deformation of the cylinder head.		
Cylinder pressure value is lower than the reasonable	Bad valve seat condition	Repair if necessary.		
	Incorrect valve clearance	Adjust the valve clearance.		
range	Piston/cylinder hole clearance is unreasonable.	Check the cylinder block and replace/repair if necessary		
	Bad condition of piston ring and/or piston ring groove	Replace the piston and/or piston ring.		

CVT SYSTEM

Exploded view	3-6-2
Special tools	3-6-5
disassemble the CVT cover	3-6-6
Install the CVT cover	3-6-6
disassemble the CVT inner cover	3-6-7
Install the CVT inner cover	3-6-7
Transmission belt	3-6-8
Disassemble the drive belt	3-6-8
Check the drive belt	3-6-8
Install the drive belt	3-6-8
Disassemble the drive pulley and the driven pulley	3-6-9
Install drive pulley and driven pulley	3-6-10

Exploded view





No.	Contanor	Torque			Domonico
	Fastener		kgf∙m	ft∙lb	Remarks
1	CVT drive pulley assembly				
2	bolt M12				
3	Washer 12×28×6				
4	CVT driven pulley bolt M10×1.25×80				
5	SPACER 10.5×36×8				
6	CVT driven pulley assembly				
7	Ball (Hongzheng)				
8	Adjustment mats				
9	Transmission belt				


G: Grease the oil seal and o-ring.

L: Use a non-permanent locking agent.

Lh:Left-hand thread

R: Replacement spare parts

CVT SYSTEM



No.	Fastener	Torque			Domorko
		N·m	kgf∙m	ft·lb	Remarks
1	cvt inner cover seal				
2	cvt inner cover seal II				
3	cvt inner cover				
4	o-ring 8×2				
5	CVT temperature sensor plug assembly				
6	Bolt M6×20	9.8	1.0	87 in•lb	
7	Plug				
8	cvt cover plug seal				
9	Bolt M6×28	6	0.6	53 in•lb	
10	CVT cover seal				
11	Baffle				
12	Bolt M8×30	26	2.7	20	
13	CVT outer cover				
14	cvt cover plug				

G: Use grease suitable for oil seals and O-rings

L: Use fastening agent.


O: Apply oil.

SS: Use silicone sealant.


S: Tighten in order.

R: Spare parts

Special tools








CVT box


WARNING

Excessive imbalance or excessive speed may cause the failure of the CVT pulley, resulting in serious injury or death. The CVT pulley is a precisely balanced component designed to operate within a specific speed range. The disassembly/assembly and maintenance procedures of the pulley assembly must be strictly followed. Modifying the engine or pulley to increase the speed may cause malfunctions.



disassemble the CVT cover

- ◆ Turn off the ignition switch.
- disassemble the CVT cover bolts [A], disassemble the CVT cover [B], and the CVT cover seal [C].




Install the CVT cover

- ◆ Check the CVT cover sealing ring 【C】. If it is damaged, replace it with a new one.
- ◆ Install the CVT cover sealing ring 【C】 into the sealing groove of the CVT outer cover 【B】.
- ◆ Tighten the outer cover bolts according to the tightening sequence shown in the figure.
- ◆ Tightening torque


CVT outer cover bolt

6 N•m (0.6 kgf•m, 53 in•lb)




disassemble the CVT inner cover

 Disassemble the CVT drive pulley and driven pulley (refer to the drive pulley and driven pulley section)



disassemble the CVT inner cover mounting bolts 【A】, remove the baffle 【B】, CVT inner cover 【C】, CVT inner cover sealing ring I 【E】, CVT inner cover sealing ring II 【D】.




Install the CVT inner cover:

TIPS


If there is water leakage in the CVT box, please replace the CVT cover sealing ring, CVT inner cover sealing ring I, CVT inner cover sealing ring II.


- Remove impurities on the sealing surface of the CVT inner cover and keep it clean.
- ◆ Assemble the baffle and the seal ring of the CVT inner cover to the CVT inner cover.



- ◆ Tighten the CVT inner cover bolts according to the tightening sequence shown in the figure.
- ◆ Tightening torque

bolt 9.8 N•m (1.0kgf•m, 87 in•lb)





Transmission belt

Disassemble the drive belt

- ◆ Remove the CVT cover.
- ◆ Remove the handle on the CVT belt replacement tool 【B】, and manually screw the CVT belt replacement tool 【B】 into the thread of the CVT driven pulley 【A】.
- Insert the handle 【C】 and move the handle outward to open the CVT driven pulley.
- Remove the drive belt from the CVT driven pulley and CVT drive pulley.

TIPS


The rotation direction of the drive belt after reinstallation should be the same as the original one. When disassembling, please pay attention to the identification information on the surface of the belt, or make a mark to distinguish it when reinstalling.

Check the drive belt


Check the transmission belt for wear, missing teeth, cracks, etc. Compare the belt with the new one and replace it if necessary.


Install the drive belt

- The installation steps are basically the reverse of the removal.
- Wrap the drive belt around the CVT drive pulley.
- Use the CVT belt replacement tool to open the CVT driven pulley and wind the drive belt into the CVT driven pulley.



D





Drive pulley and driven pulley assembly


Disassemble the drive pulley and the driven pulley


- disassemble the CVT cover (see CVT cover chapter).
- ◆ Use the CVT anti-rotation tool 【A】 to fix the driving wheel 【B】, and turn it counterclockwise to unscrew the driving wheel bolt 【C】.


TIPS

The drive pulley bolt is a left-handed thread, and the bolt should be rotated in a clockwise direction when loosening the bolt.

- ◆ Screw the CVT drive pulley ejector rod 【D】 into the CVT drive pulley, and disengage the CVT drive pulley from the crankshaft.
- Remove the drive pulley from the crankshaft.
- ◆ Use the CVT anti-rotation tool 【A】 to fix the driven pulley 【E】, and loosen the driven pulley bolt 【F】.
- Remove the driven pulley.







Install drive pulley and driven pulley

- ◆ Install the CVT driven pulley 【B】 on the gearbox shaft, and lock the CVT driven pulley 【B】 with the CVT stop tool 【A】.
- ◆ Install the washer 【C】 and the driven pulley bolt 【D】, and tighten the driven pulley bolt 【D】 according to the torque.
- Tightening torque

Driven pulley bolt

80 N·m (8.2 kgf·m, 59 ft·lb)

Use oil-free cleaning fluids such as trichloroethylene or acetone to clean the following parts:

Crankshaft cone [E]

Cone surface of driving wheel [F]

▲ WARNING

These cleaning fluids are usually highly flammable, and long-term inhalation is harmful to the body. Make sure to follow the safety warnings of the cleaning fluid manufacturer.


- ◆ Install the CVT driving pulley 【G】, install the washer 【H】 and the driving pulley bolt 【Ⅰ】.
- Use the CVT anti-rotation tool to fix the CVT drive pulley, tighten the drive pulley bolt 【I】 to the specified torque, and tighten the drive pulley bolt counterclockwise.
- Tightening torque


Drive pulley bolt

120 N•m (12.2 kgf•m, 88.5 ft•lb)

Exploded view	3-1-2
Special tools	3-1-4
Water pump assembly	3-1-5
Disassemble the water pump	3-1-5
Install the water pump	3-1-6

Exploded view





Na	Factorian		Remarks		
No.	Fastener	N·m	kgf∙m	ft·lb	Remarks
1	Water pump cover				
2	Bolt M6×30	9.8	1.0	87 in•lb	
3	Bolt M6×95	9.8	1.0	87 in•lb	
4	Bolt M6×12	9.8	1.0	87 in•lb	
5	Aluminum washer 6				
6	Steel belt elastic hose clamp 30				
7	Small circulating water pipe				
8	Water pump cover sealing ring				
9	Bolt M6×16	9.8	1.0	87 in•lb	
10	Disc spring 12.5×6.4×1				
11	Combination washer				
12	Water pump impeller				
13	Oil seal 15×30×5				
14	Bushing				
15	Oil seal 15×28×5				
16	OO-ring seal 8×2				
17	Flat washer 13.1×25×1				
18	Water pump shaft				

G: Use grease suitable for oil seals and O-rings

L: Use fastening agent.

O: Apply oil.

SS: Use silicone sealant.


S: Tighten in order.

R: Spare parts

Special Tools








Water pump assembly

Disassemble the water pump

▲ WARNING


Make sure that the engine has cooled down before disassembly. Hot coolant and steam can cause serious injury.

◆ Disassemble the two clamps and remove the small circulating water pipe 【A】.




◆ Disassemble two M6×95 bolts 【B】, three M6×30 bolts 【C】, and remove the water pump cover.

 Remove the left crankcase cover sub-assembly (see the section of crankcase assembly).



Unscrew the bolt 【D】, take off the stack spring
 【E】, combined washer 【F】, and water pump
 impeller 【G】 in sequence.

♠ Remove the water pump shaft 【N】 and O-ring 【M】, and then remove the bushing 【H】, oil seal 【I】, flat washer 【J】, oil seal 【K】, and flat washer 【L】 in turn.



Install the water pump

- ◆ Insert the water pump shaft 【A】 into the left crankcase cover, and install the flat washer 【B】.
- ◆ Take a new O-ring 【C】, apply appropriate amount of engine oil on the surface, and install it into the O-ring groove of the water pump shaft.

TIPS


A new O-ring should be replaced every time the pump is disassembled and assembled. After the O-ring is installed, check whether the O-ring is intact and not twisted.

◆ Install washer 【B】, bushing 【D】 in sequence, use oil seal press tool 15-28-5 to press in new oil 【E】, install washer 【F】, use oil seal press tool 15-30-5 to press in the new oil seal 【G】.




The sealing lip of the oil seal **[E]** faces the inside when installed, and the sealing lip of the oil seal **[G]** faces the outside.

- ◆ Install the water pump impeller 【H】, install the combined washer 【I】, and the disc spring 【J】 in sequence.
- ◆ Apply thread fastening glue to the bolt 【K】, and screw in the bolt.



Bolt [K]

9.8 N·m (1 kgf·m, 87 in•lb)



Put the new seal ring 【L】 into the seal ring groove of the water pump cover 【M】, install the water pump cover, and screw in the bolts 【N】 and 【O】.


Bolt [K]

9.8 N·m (1 kgf·m, 87 in•lb)

Exploded view of front axle	3
Special tools	6
Replacement of front axle gear oil	7
Drain the old gear oil	7
Add new gear oil	7
Inspection of parts wear	8
Disassemble	8
Install	8
Adjustment of gear clearance	.9
Disassemble	9
Install	.9
Exploded view of rear gearbox	10
Replacement of gearbox gear oil	13
Drain the gearbox oil	13
Add gearbox oil	13
Dismantling the gearbox	14
Gear setting	14
Dismantling the driven bevel gear cover assembly	14
Dismantling the driving bevel gear	14
Dismantling the shift shaft cover assembly	14
Dismantling the shift mechanism	15
Dismantling the oil pump components	15
Dismantling the connecting nut between the shaft and the box body	15
Dismantling the right gearbox connector	16
Dismantling the right gearbox assembly	16
Dismantling the reverse gear idler shaft assembly and main shaft assembly	16
Dismantling the Gear positioning bolt	16
Dismantling the shifting system	17
Dismantling the gear transmission parts	17
Dismantling the box connector	17
Dismantling the parking mechanism	17
Dismantling the countershaft assembly	18
Assemble the gearbox	19
Install the left box bearing	19

Install the right gearbox combined bearing	19
Install the parking mechanism	20
Install the bearing plate of the left box body	20
Install the countershaft assembly	21
Assemble the rear axle output gear assembly	21
Install the left box connector	21
Install the gear set	22
Assemble the HR shift fork shaft assembly	22
Assemble the L gear shift fork shaft assembly	22
Install the HR shift fork shaft assembly	23
Install the L gear shift fork shaft assembly	23
Install the parking shaft and shift drum assembly	24
Assemble the reverse gear idler shaft assembly	24
Install the main shaft assembly	25
Install the gear assembly	25
Install the right box body combination	25
Install the countershaft low-speed gear	26
Install the driven bevel gear shaft	26
Install the driven bevel gear shaft	27
Install the driven bevel gear cover oil seal	27
Install the driven bevel gear cover	27
Install the gear sensor and rotary shaft oil seal	28
Install the gear set nut	28
Assemble the oil pump components	29
Install the oil pump assembly	29
Install the rear axle output shaft oil seal	29
Install the needle bearing and locating pin	30
Install the shift mechanism	30
Install the needle bearing and locating pin	30

Exploded view of front axle



No.	Fastener		Remarks		
INO.	rasteriei	N·m	kgf∙m	ft·lb	Remarks
1	Hexagon flange bolt m8×25	24	2.4	17	
2	Oil seal 30×55×7				G
3	Breathing joint	15	1.53	11.1	L
4	Front axle end cover				
5	Rectangular gasket				
6	Deep groove ball bearings 16010				
7	Limiting liner				
8	Hexagon flange bolt m10×1.0×18	70	6.8	49	L
9	Differential cover				0
10	Axle bevel gasket				0
11	Axle bevel gear i assembly				0
12	Differential planetary gear shaft v				
13	Planetary gear liner				0
14	Planetary gear				0
15	Axle bevel gear ii				0
16	Differential housing				
17	Driven bevel gear				
18	Axle shaft assy				0
19	Spacer 40.2×50×3				
20	Spacer 40.2×50×3				
21	Bushing i (φ97)				0

No.	Fastener		Remarks		
INO.	Fasterier	N·m	kgf∙m	ft·lb	Remarks
22	Deep groove ball bearings 16008				
23	Front axle housing				
24	Bushing ii (φ15)				0
25	Drive bevel gear shims				
26	Bearing 3306				
27	Circlip 30				
28	Round nut m75×1.5×6-Lh	70	6.8	49	L
29	Oil seal 30×78×7				G
30	Bolt m6×16	10	1	7	
31	Vehicle speed sensor assembly				
32	O-ring 12×2				0
33	Screw plug m14	18	1.8	13	
34	O-ring 13.8×2.5				0
35	Screw plug m14 assembly	18	1.8	13	
36	O-ring 67.9×2.2				0
37	Front axle shift motor assembly				
38	Shift fork				
39	Sliding rack				
40	Fork shaft 5×65				
41	Hexagon screw m8×8	12	1.2	9	L
42	Driving bevel gear				

G: Apply grease for oil seal and O-ring.

L: Apply a non-permanent locking agent.

O: Apply gear oil(SAE 80W/90/GL-5).

SS: Apply silicone sealant.


R: Replacement Parts.

Technical specifications


Item	Standard	Service limit
Front axle:		
Туре	Sae 80w/90/gl-5	
Fill position	Side of the box (screw plug m14)	
Drain position	Bottom of the box (screw plug m14 assembly)	
Volume	180 ml (0.19 Us qt) (when there is no oil stains after	
	internal cleaning)	
	160 ml (0.17 Us qt) (only when changing gear oil)	
Bevel gear backlash	0.15~0.25 Mm(0.06~0.10 In.)	
Gearbox assembly:		
Туре	Sae 80w/90 gl-5	
Fill position	Side (oil dipstick)	
Drain position	Bottom (m14 screw plug)	
Volume	1500 MI (1.35 Us qt) (refill gear oil for the first time)	
	1400 MI (1.26 Us qt) (change gear oil)	
Bevel gear backlash	0.15~0.25 Mm(0.06~0.10 In.)	

Special tools


ALLEN WRENCH 8mm / 12mm:




SILICONE RUBBER FLAT SEALANT:



EXTERNAL CIRCLIP PLIERS



SCREWDRIVER




ROUND NUT M75 \times 1.5 \times 6-LH SLEEVE T-SLEEVE 10mm





Replacement of front axle gear oil



MARNING

Vehicle operation with insufficient, deteriorated, or contaminated gear oil will cause accelerated wear and may result in Gearbox Damage, accident, and injury.


[A] o-ring 13.8×2.5

【B】 screw plug m14 assembly

【C】 screw plug m14



◆ Tools: 8mm Allen key



 Please dispose of waste gear oil in an environmentally friendly manner, please take care of the environment



◆ Tools: 8mm Allen key


Rotate C counterclockwise to unscrew it, add a certain amount of new gear oil, and then tighten the threaded end of sleeve A and C clockwise to wipe clean the gear oil spilled around.



A CAUTION

Pay attention to check the O-ring during installation. If it is damaged, it will lead to poor sealing and leakage of gear oil, which will aggravate the internal wear of the gearbox and eventually cause damage to the gearbox. Please replace the damaged O-ring in time.


Inspection of parts wear



▲ WARNING

If it is not replaced in time, it will cause abnormal wear of other parts, and the overall temperature of the gearbox will increase, which will shorten its service life.

- 【A】 Hexagon flange bolt m8×25
- 【B】 Front axle end cover
- **[C]** Limiting liner
- 【D】 Rectangular gasket
- **[E]** Front axle end cover assembly




DISASSEMBLE

- ◆ Tool: 10mm t-sleeve (air trigger gun)
- ◆ Rotate c (7 pcs) counterclockwise to unscrew, pry b (three points) to take out e
- ◆ Take out c and measure the thickness. If the thickness is less than 6.85Mm, a new limit gasket a needs to be replaced.

Install


- ◆ Tool: 10mm T-sleeve (air trigger gun)
- Install C in B, pay attention that the boss of C corresponds to the groove of B
- Check D, there must be no distortion or damage, if any, please replace it in time
- ◆ Then assemble E as a whole back to the front axle housing, and tighten bolt A diagonally.



WARNING

If the oil leaks during the replacement, please make up the oil and check whether the oil seal and sealing ring on B are damaged. If there is any damage, please replace it in time.

Adjustment of gear clearance



WARNING

If the gear gap is not adjusted well, it will aggravate the wear of gear parts, resulting in abnormal gear transmission noise, gear surface pitting, reduced transmission efficiency, and shortened overall life.

- [A] Oil seal 30×78×7
- 【B】 Round nut m75×1.5×6-Lh
- [C] Driving bevel gear assembly
- [D] Drive bevel gear shims
- **[E]** Front axle box assembly

Disassemble

- ◆ Tool: round nut M75×1.5×6-LH sleeve;
- ◆ Destroy and remove A from E, then use a round nut sleeve to turn B clockwise out, take out C, and then take out D from the inner hole of E.


Install

- ◆ Tool: round nut M75×1.5×6-LH sleeve;
- ◆ Take the corresponding thickness of D according to the gear gap value, put D into the inner hole of E, put C into the inner hole of E, apply tightening thread glue on B, and then use the round nut M75×1.5×6-LH sleeve Rotate B counterclockwise, tighten it, reconfirm the gear gap, install new A on E after it is accurate (note that the oil seal lip cannot be scratched, and the oil seal as a whole cannot be deformed), and wipe clean the gear oil spilled around it.

▲ CAUTION

Pay attention to the scratch and damage of the oil seal during installation. If damaged, it will cause the gearbox to leak gear oil, which will accelerate the internal wear of the gearbox and eventually cause damage to the gearbox. Please replace the damaged oil seal in time.

Exploded view of rear gearbox



No.	Fastener	Torque	Domorko		
INO.	rasierier	N⋅m	kgf∙m	ft·lb	Remarks
1	Bolt m10x1.25X45	45	4. 59	33.3	
2	Bolt m8×125	25	2. 55	18. 5	
3	Bolt m8×40	25	2. 55	18. 5	
4	Right gearbox assembly machining parts				SS
5	Oil seal 42×55×8				G
6	Oil seal 27×60×7				G
7	Deep groove ball bearings 6206				
8	Nut m33×1.5	240	24.49	177.12	L
9	Driven bevel gear shaft enclosure				
10	Deep groove ball bearings 6207				
11	Driven bevel gear shaft adjustment pad 35×48×0.4				
12	Driven bevel gear shaft				
13	Bolt m8×60	25	2. 55	18. 5	
14	Nut m30×1.5-Lh	210	21.43	154.98	L
15	Deep groove ball bearings 6307				
16	Driving bevel gear				
17	Drive bevel gear shaft adjustment pad 42×48×0.6				
18	Bolt m8×20	25	2. 55	18. 5	
19	Gear Sensor Assembly		<u> </u>		

	Torque			_	
No.	Fastener	N⋅m	kgf·m	ft·lb	Remarks
20	Shift drum				
21	Spacer 15×28×1				
22	Needle roller bearing hk1516				
23	Circlip 12				
24	Shift fork spring seat				
25	Shift fork spring				
26	Hr gear shift fork assembly				
27	Hr gear shift fork shaft				
28	Parking guide shaft				
29	Push rod seat assembly				
30	Scroll wheel				
31	Washer with split 4				
32	Push rod assembly				
33	L gear shift fork assembly				
34	L gear shift fork shaft				
35	Washer 26×44×3				
36	Reverse gear idler				
37	Needle bearing k30×35×17				
38	Reverse gear idler shaft				
39	Cylindrical pin 6×10				
40	Deep groove ball bearings 6211				
41	Rear axle output gear				
42	Hexagon socket pan head stepped bolts				
43	Parking arm return torsion spring				
44	Push rod guide seat				
45	Parking brake arm				
46	Parking arm shaft				
	<u>~</u>				
47	Fourth axis assembly	40	4.00	0.00	
48	Bolt m6×16	12	1.22	8.86	
49	Triaxial bearing press plate	040	04.40	454.00	
50	Nut m30×1.5-Lh	210	21.43	154.98	L
51	Deep groove ball bearings 6305				
52	Third axis assembly				
53	Needle roller p4×29.8				
54	Nut m33×1.5				
55	Circlip 28×2.5				
56	Washer 28×40×2.5				
57	L gear driven bevel				
58	Needle roller bearing k28×33×17				
59	RI gear coupling sleeve				
60	Circlip 35×2.5				
61	Washer 32×42×1.5				
62	R gear driven bevel				
63	Needle roller bearing k35×40×13				
64	Countershaft				
65	H gear engagement sleeve				
66	Washer 30×40×1.5				
67	H gear driven gear				
68	Parking gear				
69	Countershaft bearing press plate				
70	Hex flange nut m22×1	145	14.8	107	L

		Torque			Torque			
No.	Fastener	N⋅m	kgf∙m	ft∙lb	Remarks			
71	Deep groove ball bearings 6207							
72	Hexagon socket large pan head bolt m6×16	12	1.22	8.86				
73	Main shaft							
74	Shift positioning wheel							
75	Bushing							
76	Shift driven gear							
77	Shift torsion spring							
78	Spacer 6.5×22×2							
79	Hexagon head bolt m6×40	15	1.53	11.1				
80	Shift positioning plate spring							
81	Positioning plate							
82	Positioning plate bolt m6×21	15	1.53	11.1				
83	Shift shaft assembly							
84	Shift shaft cover gasket							
85	Shiftshaft cover							
86	Oil seal 15×25×5				G			
87	Oil pump cover							
88	O-ring 52×2							
89	Oil pump shaft							
90	Needle roller p4×15.8							
91	Oil pump inner rotor							
92	Outer rotor of oil pump							
93	Flow orifice φ1	2.5	0.26	1.85	L			
94	Bolt m6×25	12	1.22	8.86				
95	Breathing joint	15	1.53	11.1	L			
96	Oil pump assembly				SS			
97	Oil dipstick							
98	O-ring 18×3.5							
99	Oil filter							
100	Gear positioning bolt	20	2.04	14.8				
101	Gear positioning spring							
	Gear positioning spring							
103	Steel ball 9.5							
104	Oil seal 38×55×7				G			
105	Left gearbox assembly				SS			
106	O-ring 13.8×2.5							
107	Screw plug m14 assembly	15	1.53	11.1				


G: Use grease suitable for oil seals and O-rings

L: Use thread glue

O: Use gear oil (SAE 75W/90/GL-5, AGL80W/90/GL-5)

SS: Use silicone sealant

R: Spare parts
LH: Left-hand thread



Replacement of gearbox gear oil

▲ WARNING

Vehicle operation with insufficient, deteriorated, or contaminated speed gearbox oil will cause accelerated wear and may result in Gearbox Damage, accident, and injury.

- [A] O-ring seal 13.8×2.5
- [B] Screw plug m14 assembly
- 【C】Oil dipstick
- 【D】O-ring seal 18×3.5

Drain the gearbox oil

- Tools: 8mm Allen key.
- ◆ Unscrew 【B】 counterclockwise, remove 【A】 and 【B】, let the gearbox oil flow out, and keep it for 10 minutes. Then put 【A】 on the bottom of the thread of 【B】, tighten it clockwise, and wipe clean the surrounding oil. Waste oil should be poured into a special container to avoid environmental pollution.

Tightening torque of screw plug M14 assembly


15N·m(1.53kgf·m,11.1ft·lb)

Add gearbox oil

- ◆ Turn on the oil dipstick
- ◆ Unscrew 【C】 counterclockwise, remove 【D】 and 【C】 and add new gearbox oil. Put 【D】 on the bottom of 【C】 thread. Tighten 【C】 and wipe off the surrounding oil.

A CAUTION


During installation, check whether the O-ring is intact and not twisted. If the O-ring is damaged, it will cause gearbox oil leakage, which may cause abnormal wear of the internal parts of the gearbox or even damage the gearbox. Please replace the O-ring with a new one in time.



Dismantling the gearbox


Gear setting

- ◆ Tool: gear wrench
- Hang the gear counterclockwise to the end as P gear.




Dismantling the driven bevel gear cover assembly

- 【A】Bolt M8×40
- 【B】 Bolt M10X1.25X45
- [C] Bolt M8×125
- 【D】Driven bevel gear cover assembly
- ◆ Tools: 10mm sleeve, 13mm sleeve.
- Unscrew [A] [B] [C] counterclockwise, remove the driven bevel gear cover assembly, if necessary, use a rubber hammer to hit the joint surface around the box.




Dismantling the driving bevel gear

- 【A】 Oil seal 27×60×7
- 【B】 Driven bevel gear shaft assembly
- 【C】Driving bevel gear shaft adjustment pad
- 【D】 Driving bevel gear
- **(E)** Deep groove ball bearing 6307
- 【F】 Nut M30×1.5-LH
- ◆ Tool: 46mm sleeve
- ◆ Pry open [F] locking card, unscrew it clockwise, and remove [A], [B], [C], [D], [E].



Dismantling the shift shaft cover assembly

- [A] Shift shaft cover assembly
- 【B】 Bolt M6×20
- 【C】 Shift shaft cover gasket
- ◆ Tool: 8mm sleeve.
- Unscrew the bolt 【A】 counterclockwise, and remove 【B】 and 【C】.



Dismantling the shift mechanism

[A] Shift positioning wheel

[B] Bushing

【C】 Shift driven gear

【D】 Shift torsion spring

[E] Washer 6.5×22×2

[F] Hexagon head bolt M6×40

【G】 Shift positioning plate spring


【H】 positioning plate

【J】 positioning plate bolt M6×21

[K] Shift shaft assembly

◆ Tool: 10mm sleeve.

◆ Remove 【K】, unscrew the bolt 【F】 counterclockwise, remove 【E】, 【D】, 【C】, 【B】, unscrew the bolt 【J】 counterclockwise, and remove 【J】, 【H】, 【G】, remove 【A】.




Dismantling the oil pump components

[A] Oil pump assembly

【B】 Bolt M6×25

◆ Tool: 8mm sleeve.

 Unscrew the bolt [B] counterclockwise, and remove [A]



Dismantling the connecting nut between the shaft and the box body

[A] Hex flange nut M22×1

【B】Needle roller P4×29.8


【C】Nut M33×1.5

[D] Nut M30×1.5

【E】Oil filter


Tools: 27mm sleeve, 46mm sleeve.

◆ Pry open the 【A】, 【C】, and 【D】 locking pieces, unscrew the nuts 【A】, 【B】, 【C】 counterclockwise, and remove 【B】【E】.




Dismantling the right gearbox connector

- [A] Gear sensor assembly
- 【B】 Bolt M6×16
- 【C】 Circlip 30×2.5
- **[D]** Washer 30×40×1.5
- 【E】L gear driven gear
- **[F]** Needle roller bearing K28×33×17
- ◆ Tools: 8mm sleeve, external circlip pliers.
- Unscrew the bolt [B] counterclockwise, remove
 [A], and use circlip pliers to remove Next [C],
 remove [D] and [E] in turn.




Dismantling the right gearbox assembly

- 【A】 Bolt M8×40
- 【B】Right gearbox assembly
- 【C】Bolt M8×60
- ◆ Tool: 10mm sleeve.
- Unscrew the bolts (A) and (C) counterclockwise, and remove (B).
- Separate the right box assembly, if necessary, use a rubber hammer to hit the joint surface around the box.




Dismantling the reverse gear idler shaft assembly and main shaft assembly

- [A] Reverse gear idler shaft assembly
- **【B】** Spindle assembly
- ◆ Remove 【A】, then remove 【B】.




Dismantling the Gear positioning bolt

- [A] Gear positioning bolt
- **【B】** Aluminum washer 14×21×1.5
- [C] Gear positioning spring
- 【D】 Steel ball 9.5
- ◆ Tool: 14mm sleeve.
- ◆ Use a sleeve to unscrew the bolt 【A】 counterclockwise, and take out 【B】, 【C】, and 【D】.




Dismantling the shifting system

- [A] Parking guide shaft
- 【B】HR gear shift fork shaft assembly
- 【C】 L gear shift fork shaft assembly
- [D] Push rod seat assembly
- **[E]** Shift drum assembly
- [F] Washer 15×28×1
- ◆ Take down 【A】, 【B】, 【C】, 【D】, 【E】, 【F】 in sequence.




Dismantling the gear transmission parts

- 【A】 Rear axle output gear assembly
- **[B]** Countershaft assembly
- 【C】 Third axis assembly assembly
- [D] Fourth axis assembly
- ◆ Take out 【A】 first, then take out 【B】 and 【C】 together, and finally take out 【D】.




Dismantling the box connector

- [A] Countershaft bearing pressure plate
- **[B]** Triaxial bearing press plate
- 【C】Bolt M6×16
- ◆ Tool: 8mm sleeve.
- ◆ Unscrew the bolt 【C】 counterclockwise, and remove 【A】 and 【B】.




Dismantling the parking mechanism

- [A] Hexagon socket pan head stepped bolt
- 【B】Parking arm return torsion spring
- [C] Parking arm
- 【D】Push rod guide seat
- [E] Parking arm shaft
- ◆ Tool: inner spline sleeve.
- ◆ Unscrew the bolt 【A】 counterclockwise, and remove 【B】, 【C】, 【D】, and 【E】 in sequence.



Dismantling the countershaft assembly


- [A] RL gear engagement sleeve
- 【B】 Circlip 35×2.5
- 【C】 Washer 32×42×1.5
- 【D】R gear driven gear
- **[E]** Needle roller bearing K35×40×13
- [F] Parking gear
- 【G】 H gear driven gear
- [H] Needle roller bearing K28×33×17
- [I] Washer 30×40×1.5
- 【J】H gear engagement sleeve
- [K] Countershaft
- ◆ Tools: external circlip pliers.
- ◆ Remove 【A】, use external circlip pliers to remove 【B】, then take out 【C】, 【D】, and 【E】, and take the other end 【F】【G】【H】【I】【J】 【K】 Take out one by one.



Assemble the gearbox

Install the left box bearing

- [A] Left gearbox body
- 【B】 Deep groove ball bearing 6305
- 【C】 Deep groove ball bearing 6307
- 【D】Needle roller bearing HK1516
- ◆ Tools: bearing tooling 6305, bearing tooling 6307, needle bearing indenter HK121612.
- ◆ Lay the box 【A】 flat, with the inner cavity facing up, press into the bearing 【B】 【C】, and then press the inner cavity down to press into the bearing 【D】.




Install the right gearbox combined bearing:

Dismantling

- [A] Driven bevel gear cover
- 【B】Bolt M8×40
- 【C】 Bolt M10X1.25X45
- ◆ Tools: 10mm sleeve, 13mm sleeve.
- ◆ Unscrew the bolts 【B】 and 【C】 counterclockwise, and remove 【A】.


Installation

- [A] Hexagon socket large pan head bolt m6×16
- 【B】 Deep groove ball bearing 6207
- 【C】 Deep groove ball bearing 6305
- [D] Driven bevel gear cover
- ◆ Tools: bearing tooling 6207, bearing indenter 6305, bearing tooling 6305, 5mm hexagon socket.
- ◆ Lay the case cover 【D】 flat with the inner cavity facing upwards, press into the bearing 【B】【C】, apply thread glue to the connecting surface of the driven bevel gear cover and bolt 【A】, and then tighten the bolt 【A】.



Hexagon socket large pan head bolt m6×16

12N·m(1.22kgf·m,8.86ft·lb)



Installation

- [A] Right gearbox
- 【B】 Deep groove ball bearing 6305
- ◆ Tools: Bearing tooling 6305.
- ◆ Lay the box 【A】 flat, with the inner cavity facing upwards, and press into the bearing 【B】.



- [A] Push rod guide seat
- [B] Parking arm return torsion spring
- 【C】 Hexagon socket pan head stepped bolt
- 【D】Parking arm
- [E] Parking arm shaft
- [F] Left box
- ◆ Tool: T40 inner plum blossom sleeve.
- ◆ Put 【A】 into the left box 【F】, 【B】 install it as shown by the dotted line in the figure, apply thread glue to the bolt 【C】 and lock it, install it into the shaft 【E】 and then install 【D】, The torsion spring 【B】 the moment arm snaps into the dotted



After installation, check that the parking arm 【D】 can be flexibly moved without jamming and rebounding.



Install the bearing plate of the left box body


[A] Countershaft bearing pressure plate

【B】 Triaxial bearing press plate

【C】Bolt M6×16


[D] Left box


- Tool: 8mm sleeve.
- ◆ Apply thread glue to the connecting surface of the left box 【D】 and bolt 【C】, and lock the pressure plates 【A】 and 【B】 in the direction shown in Figure B.




Bolt M6×16

 $12N \cdot m(1.22kgf \cdot m, 8.86ft \cdot lb)$







Install the countershaft assembly

- **[A]** RL GEAR COUPLING SLEEVE
- 【B】 Circlip 35×2.5
- [C] Washer 32×42×1.5
- 【D】R gear driven gear
- **[E]** Needle roller bearing K35×40×13
- [F] Parking gear
- 【G】 H gear driven gear
- 【H】 Needle roller bearing K28×33×17
- [1] Washer 30×40×1.5
- [J] H GEAR COUPLING SLEEVE
- [K] Countershaft
- ◆ Tools: external circlip pliers.
- ◆ Load [E], [D], [C], [B], and [A] into [K] in sequence, and then [J], [I], [H], [G], [F], Also load [K] in sequence.

Assemble the rear axle output gear assembly

- [A] Deep groove ball bearing 6211
- 【B】Rear axle output gear
- ◆ Tool: Bearing tool 6211.
- Assemble and press the bearings 【A】 to 【B】 respectively.


Install the left box connector


- [A] Cylindrical pin 6×10
- 【B】 Screw plug M14
- 【C】 O-ring 13.8×2.5
- ▶ Tools: brass hammer, 8mm hexagon wrench.
- ◆ Knock 【A】 into the left box, put 【C】 on the bottom of the thread of 【B】, and tighten 【B】.


screw plug M14 component 15N·m(1.53kgf·m,11.1ft·lb)

A CAUTION

During installation, check whether the O-ring is intact and not twisted. If the O-ring is damaged, it will cause transmission oil leakage, which may cause abnormal wear of the internal parts of the gearbox or even damage the gearbox. Please replace the O-ring with a new one in time.







Install the gear set

- [A] Countershaft assembly
- 【B】 Third axis assembly
- 【C】 Fourth axis assembly
- ◆ After putting 【C】 into the left box body first, install 【A】 and 【B】 into the left box body together as shown in the figure.

Assemble the HR shift fork shaft assembly


- 【A】 HR gear shift fork shaft
- 【B】 Retaining ring for shaft 12
- 【C】 HR gear shift fork assembly
- [D] shift fork spring
- **(E)** shift fork spring seat
- [F] Circlip 12
- 【G】 HR gear shift fork assembly
- 【H】 shift fork spring
- [1] shift fork spring seat
- 【J】 Circlip 12
- ◆ Tools: external circlip pliers.
- ◆ Load 【B】, 【C】, 【D】, 【E】, 【F】, 【G】, 【H】, 【I】, 【J】 into 【A】 in the order shown in the figure.


Assemble the L gear shift fork shaft assembly

- [A] L gear shift fork shaft
- 【B】 Circlip 12
- 【C】 shift fork spring seat
- 【D】 shift fork spring
- [E] L gear shift fork assembly
- 【F】 Circlip 12
- ◆ Tools: external circlip pliers.
- ◆ Load 【B】, 【C】, 【D】, 【E】, and 【F】 into 【A】 in the order shown in the figure.

Assemble the L gear shift fork shaft assembly

- [A] Washer with split 4
- 【B】 scroll wheel
- 【C】Push rod seat assembly
- [D] Push rod assembly
- ◆ Load 【A】 and 【B】 into 【C】 in the order shown in the figure, and then 【D】 into 【C】.






Install the HR shift fork shaft assembly:


【A**】** HR gear shift fork shaft assembly Push rod assembly

【B】 Countershaft assembly

[C] Countershaft assembly

◆ Assemble 【A】【C】 as shown in the figure, then put it into the left box and connect with 【B】.







Install the L gear shift fork shaft assembly


[A] L gear shift fork shaft assembly


【B】 Countershaft assembly

◆ Assemble according to the figure, put 【A】 into the left box and connect with 【B】.









Install the parking shaft and shift drum assembly

- 【A】 Washer 15×28×1
- 【B】 shift drum
- 【C】Parking guide shaft
- ◆ Assemble 【A】 【B】 as shown in the figure and install it into the left box body, and then put 【C】 into the left box body.

A CAUTION


When installing, check that the roller part of the HR gear shift fork, L gear shift fork, and push rod seat assembly should be in the guide groove of the red-painted part of the shift drum.


Install the parking shaft and shift drum assembly

- 【A】 Steel ball 9.5
- [B] Gear positioning spring
- [C] Aluminum washer 14×21×1.5
- 【D】 Gear positioning bolt
- ◆ Tool: 14mm sleeve.
- ◆ Put 【A】, 【B】, and 【C】 into 【D】 in the order shown in the figure, and then into the left box.


Assemble the reverse gear idler shaft assembly

- 【A】 Cylindrical pin 6×10
- 【B】 Reverse gear idler shaft
- 【C】 Needle roller bearing K30×35×17
- [D] Reverse gear idler
- [E] Washer 26×44×3
- ◆ Tools: copper hammer.
- ◆ After typing 【A】 into 【B】, load 【C】, 【D】, and 【E】 in the order shown in the figure.









Install the main shaft assembly

[A] Bushing

【B】 Main shaft

- Tools: copper hammer.
- ◆ Press 【A】 into 【B】 according to the icon.

Install the gear assembly

[A] Reverse gear idler shaft assembly

【B】 Main shaft assembly

[C] Rear axle output gear assembly

◆ First put 【A】 into the left box body according to the figure, then put 【B】 into the left box body, and finally put 【C】 into the left box body.

A CAUTION

When installing the **[C]** rear axle output gear, pay attention to the gap between the gear and the box body to prevent fingers from being pinched.

Install the right box body combination

[A] Right gearbox

【B】 Bolt M8×40

【C】Bolt M8×60


- ◆ Tool: 10mm sleeve.
- Apply sealant according to the gluing track as shown in the figure. The glue application should be uniform and continuous, and the glue line width should be about 1.5-2mm.
- ◆ Align with the positioning pin hole of the left box body, install 【A】, and tighten the bolts in sequence.

Bolt M8×40

 $12N \cdot m(1.22kgf \cdot m, 8.86ft \cdot lb)$


Bolt M8×60

12N·m(1.22kgf·m,8.86ft·lb)




Install the countershaft low-speed gear:

- **[**A**]** Washer 30×40×1.5
- **[B]** Needle roller bearing K28×33×17
- 【C】L gear driven gear
- **[D]** Washer 30×40×1.5
- [E] Circlip 30×2.5
- ◆ Tools: external circlip pliers.
- ◆ Load 【A】, 【B】, 【C】, 【D】, and 【E】 into the countershaft in the order shown in the figure.



Install the driven bevel gear shaft:

- [A] Driven bevel gear shaft
- 【B】 Deep groove ball bearing 6207
- 【C】 Driven bevel gear shaft spacer
- **[D]** Nut M33×1.5
- **[E]** Deep groove ball bearing 6206
- ◆ Tools: 46mm sleeve, 32mm sleeve, driven bevel gear shaft tooling seat, driven bevel gear shaft spline sleeve.
- ◆ Install 【B】 and 【C】 into 【A】 in the order shown in the figure, lock 【D】 clockwise to a torque of 240N·m, and then install 【E】 into 【A】.




Install the driven bevel gear shaft

- 【A】 Oil seal 27×60×7
- 【B】 Driven bevel gear shaft
- 【C】 Cylindrical pin 6×10
- 【D】 Driving bevel gear shaft adjustment pad 42×48×0.6
- **[E]** Driving bevel gear
- **(F)** Deep groove ball bearing 6307
- 【G】 Nut M30×1.5-LH
- ◆ Tools: 46mm sleeve, copper hammer.
- ◆ Put 【A】 into 【B】 and then into the box, knock in the cylindrical pin 【C】, install 【G】, 【F】, 【E】 in the order shown in the figure, and lock 【D】 counterclockwise.



210N·m(21.4kgf·m,155ft·lb)



Install the driven bevel gear cover oil seal


- [A] Driven bevel gear cover
- 【B】 Oil seal 42×55×8
- ◆ Tools: oil seal 42×55×8 punch.
- ◆ Install the oil seal in place using an oil seal press tool.



Install the driven bevel gear cover

- [A] Driven bevel gear cover
- 【B】 Bolt M8×40
- 【C】 Bolt M10X1.25X45
- **[D]** Bolt M8×125
- ◆ Tools: 10mm sleeve, 13mm sleeve.
- Align the positioning pin holes of the box body, install
 [A], and tighten the bolts [B], [C], and [D]

 in order.



Bolt $M8 \times 40$


25N·m(2.55kgf·m,18.5ft·lb)

Bolt $M10 \times 1.25 \times 45$

45N·m(4.59kgf·m,33.3ft·lb)

Bolt $M8 \times 125$

25N·m(2.55kgf·m,18.5ft·lb)



Install the gear sensor and rotary shaft oil seal


- 【A】Bolt M6×20
- 【B】 Gear sensor assembly
- 【C】 O-ring 29.6×2.4
- 【D】 Oil seal 38×55×7
- **[E]** CVT driven wheel bushing
- **[F]** O-ring 31×2.5
- ◆ Tools: 38×55×7, 10mm sleeve with oil seal guide punch at the output end.
- ◆ Put 【C】 into 【B】 and then into the box body and tighten the bolt 【A】, install 【F】 into 【E】, first install 【G】 and then 【E】, the oil seal is press-fitted with an oil seal Tool to install the oil seal in place.

Nut M6×20

12N·m(1.22kgf·m,8.86ft·lb)

Install the gear set nut

- 【A】 Hex flange nut M22×1
- 【B】 Needle roller P4×29.8
- 【C】 Nut M33×1.5
- **[D]** Nut M30×1.5
- ◆ Tools: 27mm sleeve, 46mm sleeve.
- ◆ After applying thread glue to the nut 【A】, tighten it clockwise, insert 【B】 into the needle hole of the four-axis assembly, apply thread glue to the nut 【C】 and tighten it clockwise, and apply thread glue to the nut 【D】, clockwise Tighten.



hex flange nut m22×1


145N·m(14.8kgf·m,107ft·lb)


Nut m33×1.5


240N·m(24.5kgf·m,177ft·lb)

Nut M30×1.5-LH

210N·m(21.4kgf·m,155ft·lb)







Assemble the oil pump components

[B] Flow orifice φ 1 **[H]** Needle roller P4×15.8

[C] Oil seal 15×25×5 [I] O-ring 52×2

【D】 Cylindrical pin 6×10 【J】 Oil pump cover

[E] Outer rotor of oil pump [K] Bolt M6×16

(F) Oil pump inner rotor **(L)** Breathing connector

Tools: 10 m m sleeve, 1 2 m m sleeve, shift chamber cover oil seal 15×25×, copper hammer.

◆ Install 【H】 into 【A】 as shown in the figure and tighten it clockwise, screw 【B】 and 【L】 clockwise into 【A】, use an oil seal press tool to install the oil seal, and first set the cylindrical pin 【D】 in order 】 Knock in 【A】, put the needle 【H】 into 【G】, put the O-ring【I】 into 【J】, into 【E】, 【G】, 【J】 in order, finally lock Tighten the bolt 【K】.

Nut M6×16

 $12N \cdot m(1.22kgf \cdot m, 8.86ft \cdot lb)$

Install the oil pump assembly

【A】 Cylindrical pin 6×10

[B] Oil pump assembly

[C] Oil dipstick

[D] O-ring 18×3.5

【E】Bolt M6×25

[F] Oil filter

Tools: 8mm sleeve, copper hammer.

- Put two cylindrical pins (A) into the box, and (F) into the box.
- Align the positioning pin holes of the box body, install
 【B】, and tighten the bolts in sequence.
- ◆ Put 【D】 into 【C】 and screw in 【B】.

Nut M6×25


12N·m(1.22kgf·m,8.86ft·lb)

Install the rear axle output shaft oil seal


【A】 Oil seal 38×55×7

Tools: output end oil seal guide punch 38×55×7.

 Use an oil seal press tool to install the oil seal in place.







Install the needle bearing and locating pin

【A】 Needle roller bearing HK121612

【B】 Cylindrical pin 6×10

Tools: Needle bearing indenter-HK121612, copper hammer.

 Press [A] into the box, and put two cylindrical pins [B] into the box.

Install the shift mechanism

【A】Shift positioning wheel 【F】Hexagon head bolt M6×40

【B】Bushing

[G] Shift shaft assembly

【C】Shift driven gear 【H】Positioning plate bolt m6×21

[D] Shift torsion spring [I] Positioning plate

[E] Washer 6.5×22×2 **[J]** Shift positioning plate spring **Tool:** 10mm sleeve.

- ◆ Put 【J】 into the box, then put 【I】 and 【H】 into the box, and then put 【A】 into the box and jam with 【I】 as shown in the figure.
- ◆ Install [B], [C], [D], [E], and [F] in sequence.
- ◆ Put the installed 【B】, 【C】, 【D】, 【E】, and 【F】 into the box and tighten.
- ◆ Finally, install 【G】 as shown in the figure to align the points.

Hexagon head bolt M6×40

15N·m(1.53kgf·m,11.1ft·lb)

Positioning plate bolt M6×21

 $15N \cdot m(1.53kgf \cdot m, 11.1ft \cdot lb)$

Install the needle bearing and locating pin

[A] Shift shaft cover gasket [C] Bolt M6×20

【B】 Shift shaft cover 【D】 Oil seal 15×25×5

- ◆ Tools: 15×25×, 8mm sleeve for the oil seal pressure head of the shift chamber cover.
- Press [D] into [B], then install [A] according
 to the position of the locating pin, then install [B]
 in sequence, and tighten the bolts in sequence.


Bolt M6×20

12N·m(1.22kgf·m,8.86ft·lb)


FUEL SYSTEM


EXPLODED VIEW OF FUEL SYSTEM	5-2
FUEL TANK	5-3
Disassembly	5 - 3
Assembly	5 - 3
FUEL PUMP	5-4
Disassembly	5-4
Inspection	5 - 4
Assembly	5 - 5
FUEL FILTER	5-6
Disassembly	5-6
Assembly	5-6

EXPLODED VIEW OF FUEL SYSTEM



No	Contanar		Torqu	Damadra	
No. Fastener		N·m	kgf∙m	ft·lb	Remarks
1	Bolt M6×35	8~12	0.8~1.2	69~103.6 in·lb	
2	Install screw cap on oil pump	75	7. 5	55	





FUEL TANK

WARNING

- Whenever the gasoline line is removed, the battery must be disconnected to prevent accidental starting of the fuel pump.
- Fuel leakage may occur whenever any repair or inspection is carried out on the fuel system, and welding, smoking, open fires, etc., shall not be allowed in the area.

Disassembly

- [A] Fuel pump cable plug
- 【B】High-pressure tubing plug
- 【C】Carbon canister adsorption tube
- **[D]** Fuel tank breather
- **[E]** Negative pressure pump oil outlet hose
- [F] Fuel tank
- ◆ Remove the plastic parts of the body, the seat and the seat bracket (see the body part for details)
- Disconnect the battery cable
- ◆ Disconnect the fuel pump cable plug 【A】 and the high-pressure fuel pipe plug 【B】
- Remove the carbon canister adsorption pipe [C], fuel tank vent pipe [D] and negative pressure pump oil outlet hose [E]
- Remove the fuel tank

CAUTION


During the process of disassembling any part of the fuel system, fuel leakage may occur. Wipe off the residual oil with a cloth.


Assembly


When assembling, please reverse assembling in the order of disassembly.

When assembling the high pressure oil pipe plug, please confirm that the assembly is correct and reliable.

5 - 3







FUEL PUMP

⚠ WARN I NG

Whenever any maintenance or inspection of the fuel system is carried out, fuel leakage may occur, and there must be no welding, smoke, open flames, etc. in this area.

Disassembly

- [A] Oil pump installation screw cap
- [B] Fuel Pump
- [C] Sealing ring
- ◆ Remove the oil pump installation screw cap counterclockwise 【A】.
- Mark the direction of the fuel pump on the fuel tank, and remove the fuel pump 【B】.
- ◆ Keep the sealing ring 【C】 to prevent loss.

⚠ CAUTION

After removing the fuel pump, please protect the fuel tank port effectively to prevent debris from falling into the fuel tank and damage the fuel pump.

Inspection

- [A] Cable plug
- **[B]** Full position
- [C] Empty position
- 【D】Pressure gauge
- Move the floating rod to check if it can move freely. The float assembly should be able to return to a lower position freely. If not, please replace the fuel pump.
- Connect the multimeter to the middle two pins of the cable plug 【A】 to test the fuel position sensor. When measuring with a multimeter in the full oil position, the resistance value shows 160 ± 5Ω, and when measuring with a multimeter in the empty position, the resistance value shows 40 ± 5Ω.

◆ Test the pressure of the fuel pump supply port through the pressure gauge 【D】, and the test pressure value is 330±20Kpa under the power-on state.

A CAUTION

- ◆ If the resistance reading shows unstable, please clean the resistance wiper with alcohol and retest. If it is still incorrect, please replace the fuel pump.
- ◆ If the fuel pump supply pressure test fails, please replace the fuel pump.


Assembly


- ◆ Confirm that the sealing ring is installed on the fuel tank port.
- ◆ Confirm the orientation of the fuel pump and install it on the fuel tank.
- ◆ Tighten the oil pump installation screw cap clockwise


Oil pump installation screw cap

 $75N \cdot m$

FUEL SYSTEM







FUEL FILTER

⚠ WARN I NG

- Whenever the gasoline pipeline is removed, the battery must be disconnected to prevent the fuel pump from starting accidentally.
- Whenever any maintenance or inspection of the fuel system is carried out, fuel leakage may occur, and there shall be no welding, smoke, open flames, etc. in the area

Disassembly

The fuel filter is behind the air filter service cover behind the passenger seat

[A] Passenger seat

【B】Seat cover

- Remove the passenger seat and the lower seat cover (see the vehicle body section for details);
- ◆ Use a suitable tool to remove the clamp 【C】 and take out the fuel filter 【D】

A CAUTION

During the process of disassembling any part of the fuel system, fuel leakage may occur. Wipe off the residual oil with a cloth.

Assembly

【C】Single ear stepless clamp 16.5


【D】Fuel Filter

- ♦ When assembling the fuel filter, please make sure that the arrow is facing the direction of the fuel filter (as shown on the left).
- ◆ Replace with a new clamp 【D】, use professional tools to clamp;
- Assemble the remaining parts, please reverse the assembly in the order of disassembly

COOLING SYSTEM

E	XPLODED VIEW OF COOLING SYSTEM	6 - 2
С	OOLANT FLOW	6 - 3
T	ECHNICAL PARAMETER	6 - 5
S	PECIAL TOOLS AND SEALANTS	6 - 6
С	OOLANT	6 - 7
	Coolant deterioration inspection	6 - 7
	Coolant level check	6 - 7
	Pressure test	6 - 8
R	ADIATOR REMOVAL	6 - 9
	Remove the oil radiator	.6 - 9
	Remove the engine raditor	.6 - 9
	Radiator fan removal	6-10
	Radiator fan installation	.6-10
	Radiator Inspection	6-11
	Radiator Cleaning	6-11
	Radiator Can Inspection	6_11

EXPLODED VIEW OF COOLING SYSTEM



No.	Fastanav		Torqu	Remarks	
INO.	Fastener	N · m	kgf • m	ft·lb	Remarks
1	Radiator mounting bolt M6X30	8~12	0.8~1.2	69~103.6in.l	
2	Radiator fan assembly bolt M6	8~12	0.8~1.2	69~103.6in.l	

COOLANT FLOW

Choose permanent antifreeze as the coolant to prevent rust and corrosion of the cooling system. When the engine starts, the water pump rotates and the coolant circulates.

The thermostat is a type of wax pellets, which opens or closes as the temperature of the coolant changes. The thermostat continuously changes its valve opening to keep the coolant temperature at an appropriate level. When the coolant temperature is lower than $79 \sim 82^{\circ}\mathbb{C}$ ($174.2 \sim 179.6^{\circ}\mathbb{F}$), the thermostat is closed. Therefore, the flow of coolant through the exhaust hole is restricted, which makes the engine warm up faster. When the coolant temperature exceeds $79 \sim 82^{\circ}\mathbb{C}$ ($174.2 \sim 1179.6^{\circ}\mathbb{F}$), the thermostat will open and the coolant will flow. When the coolant temperature reaches $88^{\circ}\mathbb{C}$ ($190.4^{\circ}\mathbb{F}$), the radiator fan switch is turned on,

The radiator fan is working. When there is not enough airflow (for example, at low speeds). The radiator fan draws in air through the radiator core. This increases the cooling effect of the radiator. When the temperature is lower than 83 °C(181.4°F), the fan switch is turned off and the radiator fan stops working.


In this way, the system controls the engine temperature within the narrow range of engine operation. Even if the engine load changes, the engine has the highest operating efficiency.

The system is pressurized through the radiator cap to suppress boiling and the resulting bubbles that may cause the engine to overheat. When the engine warms up, the coolant in the radiator and water circuit expands. The excess coolant flows into the water storage tank through the radiator cover and hoses. Conversely, when the engine cools, the coolant in the radiator and water circuit shrinks, and the stored coolant flows from the water tank back to the radiator.

The radiator cap has two valves. One is a pressure valve, which maintains the pressure in the system when the engine is running. When the pressure exceeds $93 \sim 123$ kPa ($0.95 \sim 1.25$ kgf/cm², $14 \sim 18$ psi), the pressure valve opens and releases the pressure to the water storage tank. Once the pressure overflows, the valve is closed and the pressure is maintained at $93 \sim 123$ kPa ($0.95 \sim 1.25$ kgf/cm², $14 \sim 18$ psi). After the engine has cooled down, another small valve (vacuum valve) on the cover opens. When the coolant cools, the coolant shrinks, creating a vacuum in the system. The vacuum valve opens and allows the coolant to enter the radiator from the storage tank.

COOLING SYSTEM

COOLANT FLOW



- 1. Engine radiator
- 4. Water storage tank
- 7. Engine radiator fan
- 10. Radiator fan switch

Black arrow: hot coolant White arrow: cold coolant


- 2. Water pump
- 5. Oil radiator
- 8. Cylinder & Cylinder head
- 3. Oil radiator cover
- 6. Radiator air duct
- 9. Thermostat

TECHNICAL PARAMETER

Item	Standard	Service Limit
Coolant provided during		
transportation:		
Туре	Permanent antifreeze (soft water and glycol for	
	aluminum engines and radiators plus corrosion	
	inhibitors and rust inhibitor chemicals)	
Color	Green	
Mixing ratio	Soft water 50%, cooling water 50%	
Total	9.5 L(8.63 qt)(Full level of the water storage	
	tank, including radiator and engine)	
Radiator cover		
Pressure relief	93~123 kPa(0.95~1.25 kgf/cm², 14~18psi)	
Thermostat		
Valve opening temperature	79~82°C(174.2~179.6°F)	
Valve fully open lift	8~12mm or over 85°C (185°F)	
Coolant filter/valve		
Cooling valve closing	83°C(181.4°F)or over 24.5kPa(0.25kgf/cm²,	
temperature (For reference)	3.6 psi)	


SPECIAL TOOLS AND SEALANTS

Silicone Sealant:





Special tools and sealants:





A B C





COOLANT

Coolant deterioration inspection

[A] Water storage tank

Visually inspect the coolant in the water storage tank **【A】**. If whitish cotton-like fluff is observed, the aluminum parts in the cooling system are corroded. If the coolant is brown, the iron or steel parts are rusty. In either case, flush the cooling system. If the coolant emits a strange smell, check the cooling system for leaks.

Coolant level check

CAUTION

Check the liquid level when the engine is cold (room temperature or ambient temperature)

- ◆ Check the coolant level in the water storage tank (keep the water storage tank vertical)
- [A] Water storage tank
- **[B]** Max mark
- 【C】Min mark
- 【D】Water storage tank cover

If the coolant level is lower than the MIN mark, remove the front access cover and the cover of the water storage tank 【D】, and then add coolant to the MAX mark 【B】.

WARNING

When refilling, add the specified mixture of coolant and soft water. Adding water alone will dilute the coolant and reduce its corrosion resistance. The diluted coolant will adhere to aluminum engine parts. In an emergency, soft water can be added, but the diluted coolant must be restored to the correct mixing ratio within a few days. If coolant must be added frequently, or the water storage tank is completely dry, there may be a leak in the cooling system. Please check the system for leaks.

Pressure test

 Remove the front access cover and the radiator cover, and install the cooling system pressure tester on the radiator filler pipe.

▲ CAUTION


Wet the sealing surface of the cover with water or coolant to prevent pressure leakage.

Slowly pressurize until the pressure rises to 123kPa (1.25 kgf/cm², 18psi).

MARN I NG

During the pressure test, do not exceed the design pressure of the system. The maximum pressure is 123kPa (1.25 kgf/cm², 18psi).


- ◆ Observe the pressure gauge for at least 6 seconds.
- ◆ If the pressure remains stable, the system is normal. If the pressure drops quickly, check for leaks.



RADIATOR REMOVAL

WARNING

- ◆ The start and stop of the radiator fan are controlled by the vehicle ECU. When the water temperature of the engine cylinder head reaches 88°C, the fan automatically starts; until the water temperature of the cylinder head drops below 83°C, the radiator fan automatically stops. Do not touch the radiator fan when it is rotating, as this may cause injury.
- When disassembling the radiator, it must be done in a low temperature vehicle and in a flameout state.



Remove the oil radiator

- [A] Oil radiator mounting bracket bolt M6X30
- [B] Water inlet connecting hose clamp
- [C] Oil radiator inlet and outlet hose clamps

【D】Oil radiator

- Disassemble the plastic parts of the rear car body and the oil radiator guard (see the car body part for details)
- ◆ Use a suitable tool to remove the water filler connection hose clamp [B] and the oil radiator water inlet and outlet hose clamp [C], pull out the water filler connection hose and the oil radiator water inlet and outlet hoses.
- ◆ Remove the mounting bolts of the radiator
- ◆ Remove the oil radiator

Remove the engine raditor

- [A] Mounting bracket bolt on engine radiator M6X25
- [B] Radiator vent pipe clamp
- [C] Engine radiator inlet and outlet hose clamp
- **[D]** Engine radiator
- **[E]** Upper bracket of radiator
- Disassemble the front plastic part of the vehicle head
- Use a suitable tool to remove the clamp [B] of the engine breather pipe and the clamp [C] of the engine radiator water inlet and outlet hoses, and pull out the


COOLING SYSTEM

breather pipe and the engine radiator water inlet and outlet hoses.

- Remove the mounting bolts of the upper bracket of the radiator, and remove the upper bracket of the radiator.
- ◆ Remove the engine radiator.

⚠ WARN I NG


Do not touch the radiator core. This may damage the radiator, resulting in reduced cooling efficiency.



Radiator fan removal

Radiator (see radiator removal)

- ◆ Radiator fan assembly bolt 【A】
- ◆ Fan assembly 【B】



- ◆ Radiator fan mounting nut 【A】
- ◆ Radiator fan 【B】


Radiator fan installation

- Radiator fan
- Radiator fan assembly
- ◆ Tighten

Radiator fan assembly bolt torque

8. 8N. m (0.9 kgf·m, 6.5 ft·lbs)

COOLING SYSTEM



Radiator Inspection

- Check the radiator core.
- ◆ If there are obstructions to air flow, remove the radiator and remove obstructions.
- ◆ If the corrugated fins [A] are deformed, carefully straighten them.
- If the air passages of the radiator core are blocked more than 20% by unremovable obstructions or irreparably deformed fins, replace the radiator with a new one.

Radiator Cleaning

 Refer to the Cooling System in the Periodic Maintenance chapter.



 Check the condition of the top and bottom valve seals of the radiator cap.


If any one of them shows visible damage, replace the cap.

[A] Bottom Valve Seal

【B】Top Valve Seal

【C】 Valve Spring

Install the cap (A) on a cooling system pressure tester (B).



▲ CAUTION


Wet the cap sealing surfaces with water or coolant to prevent pressure leakage.

- Watching the pressure gauge, slowly pump the pressure tester to build up the pressure. The relief valve opens,indicated by the gauge hand flicks downward.
- ◆ The relief valve must open within the relief pressure range in the table below and the gauge hand must remain within the specified range at least 6 second.

Radiator Cap Relief Pressure


Standard: 93~123 kPa (0.95~1.25 kgf /cm², 14~18psi)

If the cap cannot hold the specified pressure, or if it holds too much pressure, replace it with a new one.





EXPLODED VIEW OF INTAKE SYSTEM	7-2
Air filter element replacement	7-3
AIR INLET FILTER DISASSEMBLY	7-3
Air cleaner disassembly	7-4
EXPLODED VIEW OF EXHAUST SYSTEM	7-5
Disassemble	7-6
Rubber buffer sleeve disassembly	7-6
MUFFLER	7-6
Air exhaust disassembly	7-7
Air exhaust system inspection	7-8

EXPLODED VIEW OF INTAKE SYSTEM



No.	Fastener		Torque	Remarks	
i asterier	N·m	kgf∙m	ft·lbs	Nemarks	
1	Bolt M6×30	10	1	7. 5	
2	Bolt M6×30	10	1	7. 5	
3	Bolt M6×30	10	1	7. 5	
4	Clamp				









Place the vehicle in a fl at road

- [A] Cargo box hand shank
- 【B】Air inlet fi Iter
- ◆ Rotate handle shank 【A】 in the right to overturn the cargo box.
- ◆ Take out air inlet fi Iter screen 【B】.
- ◆ Check if any debris or dust on the fi Iter screen 【B】 regularly, if yes, clean it to keep air inlet clear.




AIR FILTER ELEMENT REPLACEMENT

- [A] Clamp
- 【B】End cover
- 【C】Air fi Iter bracket
- [D] Air fi Iter
- ◆ Press clamp 【A】.



◆ Meanwhile, push out end cover 【B】 upwards.



- ◆ Take out air fi Iter bracket 【C】
- ◆ Replace air fi tler 【D】


⚠ WARNING

Make sure air filter and end cover clamp are assembled in right position or it will cause engine failure or reduce lifetime.

Please shorten interval to check air filter if the vehicle is working in heavy dust environment.


If air filter is soaked or filter element is wet, please discharge water and replace air filter

AIR CLEANER DISASSEMBLY




- [A] Bolt
- [B] Clamp
- [C] Rubber hose
- [D] Air cleaner
- ◆ Disassemble bolt 【A】.
- ◆ Disassemble clamp 【B】.
- Disassemble rubber hose 【C】.
- ◆ Take out air cleaner 【D】 in the arrow direction.

排气系统爆炸图



Na	Fastener		Torque	Damada	
No.	o. Fasiener		kgf∙m	ft·lbs	Remarks
1	Cap Nut M8	25	2.6	18	
2	Oxygen sensor				
3	Spring				
4	Exhaust pipe connection bolt				
5	Hexagon flat round head assembly screw M6×14	10	1	7. 5	
6	Hexagon flat round head screw M6×20	10	1	7. 5	
7	Hexagon flange bolt M8x16	35	3.6	26	
8	Hexagon flange bolt M8x40	35	3.6	26	
9	Nut M8	35	3.6	26	






WARNING

Do not perform maintenance immediately after use as the exhaust components become very hot and can cause serious burns and injury.

【A】Bolt

[B] Spring


◆ Disassemble bolt 【A】 and remove spring 【B】



【C】Nut M8

【D】Hexagon flange bolt M8x40

 Remove the fastening bolt [D] and bolt under the muffler cylinder body with a tool [C];



[E] Hexagon flange bolt M8x16

[F] Mount bracket under engine shock absorber sleeve

- Remove the fastening bolts on the left and right sides of the muffler cylinder body respectively with tools [E]
- Remove the installation bracket under the engine shock absorber sleeve
- ◆ At this time, the muffler cylinder body parts can be removed as a whole


Air exhaust disassembly




When you check or maintain parts of air exhaust system, you must check if the part is overheat in case of scald.




- ◆ Remove the air filter (see 7-4)
- Disconnect two oxygen sensor wire harness plugs [A];



- Remove 5 pieces of cap nuts with tools [B];
- Remove the exhaust pipe.






AIR EXHAUST SYSTEM INSPECTION

- Check externally if any crack, hole or damage in the muffler then replace related parts. This will affect engine performance and emmission.
- 2. Shake the muffler then replace related parts to check if any looseness, noise or debris inside.
- 3. Check if air exhaust pipe is disconnected with cylinder end. If yes, fasten nut or replace seal gasket.
- Check if air exhaust pipe is disconnected with muffler then replace related parts. If yes, fasten nut or replace muffler then replace related parts spring and seal sleeve.
- Check if any carbon deposition in the filter screen of muffler then replace related parts 【A】. If yes, clean it by proper brush. If screen or seal gasket is broken, please replace them.

DRIVE SYSTEM


EXPLODED VIEW OF DRIVE SYSTEM8	3-2
DISASSEMBLY OF THE REAR SECTION OF THE DRIVE SHAFT	8-3
DISASSEMBLY OF THE FRONT SECTION OF THE DRIVE SHAFT	8-4
DISASSEMBLY OF THE MIDDLE SECTION OF THE DRIVE SHAFT8	8-6
BEARING REPLACEMENT8	3-7
FRONT DRIVE SHAFT REMOVAL8	8-8
DRIVE SHAFT EXPLODED VIEW	8-9
DRIVE SHAFT REMOVAL8-	·10
NSTALLATION OF DRIVE SHAFT8-	-12
NBOARD CV JOINT DRIVE SHAFT REPAIR8-	-13

EXPLODED VIEW OF DRIVE SYSTEM



NIa	No. Fastener				
INO.		N·m	kgf∙m	ft·lbs	Remarks
1	Bolts M8×35	35	3. 6	26	
2	Bolts M10×1. 25×20	70	7. 1	52	L


L: Apply Impermanent Locking Agent.




DISASSEMBLY OF THE REAR SECTION OF THE DRIVE SHAFT

Put the vehicle in a horizontal position first


- [A] Right rear wheel assembly
- 【B】 Right rear rocker arm assembly
- 【C】 bolt
- **[D]** the rear segment of the drive shaft




- From the right side of the vehicle, first remove the right rear wheel assembly 【A】, continue to remove the right rear rocker arm assembly 【B】, remove the engine end drive shaft fixing bolts 【C】;
- ◆ Rotary drive shaft 180°, remove another fixed bolt;



Move forward the rear section of the drive shaft
 【D】 to separate it from the output end of the engine;




Then the whole back exit drive shaft after section
 (D), and the middle drive shaft separation;



DISASSEMBLY OF THE FRONT SECTION OF THE DRIVE SHAFT


- 【A】 plastic parts
- 【B】 Bearing seat bolt
- 【C】 bearing seat
- **【D】** the middle part of the drive shaft
- Disassemble the plastic part [A]
- ◆ Disassemble the middle part of the drive shaft Bearing seat bolt 【B】

◆ Take out both ends of bearing seat 【C】




Then the whole back exit the middle part of the drive shaft 【D】, so as to separate from the front drive shaft;


DRIVE SYSTEM




- [A] Front right wheel assembly
- **【B】** Drive shaft mounting bolt
- **[C]** the front section of the drive shaft
- ◆ Removal of front right wheel Assembly 【A】;



 Remove the installation bolt of the drive shaft and the front axle end 【B】 rotate the drive shaft 180°, remove another fixing bolt;



 Move the front section of the drive shaft 【C】 back to separate from the output end of the front axle;




And then the whole back exit drive shaft rear section【C】;

DISASSEMBLY OF THE MIDDLE SECTION OF THE DRIVE SHAFT

[E] Bearing seat


[F] Butter nozzle



◆ Remove bearing seat [E]


A CAUTION

Need to check whether the bearing has abnormal noise or large gap or excessive wear, if any defects need to replace the bearing seat as a whole.




DRIVE SHAFT MAINTENANCE

- ◆ Filling with grease
- When the inspection finds that the grease in the drive shaft is reduced, or every time the vehicle drives, After 2000Km, it needs to be lubricated by the grease zerk [F] using grease gun tool.




BEARING REPLACEMENT


- [A] Retaining ring for hole
- 【B】Spline fork
- [C] Bearing
- [D] Welding fork
- ◆ Retaining ring for disassembly hole 【A】



 Fix the welding fork [D] on the clamp, hit the spline fork [B], and take out the roller needle bearing group to separate the spline fork from the ten-byte bearing;




- ◆ Fix the ten-byte bearing on the clamp, hit the welding fork 【D】, and take out the roller needle bearing set to separate the welding fork from the ten-byte bearing
- Replace the cross shaft bearing and assemble it in reverse according to the disassembly procedure above.



FRONT DRIVE SHAFT REMOVAL

- [A] Split pin
- 【B】Nut
- [C] Washer
- [D] Bolt
- [E] Wheel hub mount
- Park the vehicle in a horizontal position and use a jack or support frame to support the vehicle so that the wheels do not touch the ground, and then remove the front tires
- ◆ Disassemble the split pin 【A】 and nut 【B】, remove the washer 【C】;




Nut 【B】Torque

300 N·m (30.6 kgf·m, 220ft·lbs)


◆ Remove the brake caliper mounting bolt 【D】, and remove the brake caliper;

Bolt [D] Torque


70 N·m (7.1 kgf·m, 52ft·lbs)



◆ Take out the rim mount in the direction of the arrow 【E】




	Fastener	Torque			-
No.		N·m	kgf∙m	ft·lbs	Remarks
1	Retaining ring				
2	Rear left/right inner ball cage assembly				
3	Retaining ring				
4	Rear axle corrugated sleeve repair kit				
4a	large clamp				
4b	small clamp				
5	Intermediate shaft				
6	Outer cage components				



DRIVE SHAFT REMOVAL

- The removal method of the front and back constant speed drive shaft is the same;
- [A] cotter
- 【B】 nut
- 【C】 gasket
- 【D】 bolt
- **[E]** Hub mounting seat




- Park the vehicle in the horizontal position, with a jack or support frame to raise the vehicle, so that the wheels do not touch the ground, and then remove the front tire;
- Remove the split pin 【A】 and nut 【B】, remove the washer 【C】;


Bolt [B] Torque 300 N·m (30.6 kgf·m, 220ft·lbs)


Remove the brake caliper mounting bolt [D], remove the brake caliper;


> Bolt [B] Torque 70 N·m (7.1 kgf·m, 52ft·lbs)



Take out the rim mounting seat along the arrow direction [E];









【B】 Slotted nut

[C] front knuckle


【D】 bolt

[E] Constant speed drive shaft

- ◆ Remove the fixed bolts of the upper and lower kingpin 【A】, so that the upper and lower rocker arm is separated from the steering knuckle;
- ◆ Remove the steering rod slotted nut 【B】, so that the steering rod and steering knuckle separation;


Bolt [B] Torque 70 N·m (7.1 kgf·m, 52ft·lbs)

◆ Remove steering knuckle in the direction of arrow [C];



◆ Remove the lower mounting bolt of shock absorber [D];

> Bolt [D] Torque 70 N·m (7.1 kgf·m, 52ft·lbs)




◆ The drive shaft 【E】 placed horizontally, along the direction of the horizontal arrow with a short and short force, pull out the drive shaft, if not out, please try several times;

DRIVE SYSTEM



INSTALLATION OF DRIVE SHAFT

Install a new retaining ring in the spline groove
 [A] , apply anti-biting agent on the spline;




- ◆ The spline of the driving shaft is aligned with the differential spline, push inward along the horizontal arrow direction, and load the driving shaft;
- If necessary, use a rubber mallet to hit the outer end of the drive shaft, into the drive shaft;
- Steering knuckle, rocker arm, steering rod, shock absorber, etc., should be assembled in reverse according to the above disassembly sequence.

INBOARD CV JOINT DRIVE SHAFT REPAIR




A CAUTION

The drive shaft is a precision component. It is necessary to ensure cleanliness when replacing and installing, and operate in strict accordance with the instructions. Do not use a hammer or sharp objects for disassembly and installation, which will affect the performance and service life of the half shaft



Use clamp pliers to clamp the clamp, and then use a small screwdriver to place it on the clamp at the end, while lifting the clamp upwards, loosen the clamp clamp and remove the clamp



 Remove the clamps at both ends of the dust cover, and pull the dust cover out a distance along the middle axis

 Use a sharper tool to remove the retaining ring in the universal joint



INBOARD CV JOINT DRIVE SHAFT REPAIR

After removing the retaining ring, you can directly pull out the intermediate shaft, pay attention to the steel ball on the cage and star sleeve not to fall, and clean the grease in the universal joint and the dust cover

CAUTION

If you only replace the grease, you need to clean the remaining grease inside the universal joint, and it is forbidden to mix different greases or use other greases instead

 Use retaining ring pliers to remove the retaining ring of the star sleeve, after replacing the universal joint or dust cover, install the star sleeve in place, and finally install the retaining ring



CAUTION

The inside of the star sleeve is a precision component. It is not recommended to disassemble and repair separately. If it is damaged or the internal grease is contaminated or liquefied, the universal joint needs to be replaced as a whole

Pour grease into the universal joint and the dust cover, and then install the star sleeve assembly into the universal joint. Pay attention to the number of steel balls in the star sleeve. If the number is wrong, installation is not allowed


▲ CAUTION

If you only replace the grease, you need to clean the remaining grease inside the universal joint, and it is forbidden to mix different greases or use other greases instead

DRIVE SYSTEM




◆ First install the small clamp, adjust the position of the dust cover to ensure that the dust cover is stuck in the groove of the intermediate shaft, and then use clamp pliers to clamp the small clamp



- When installing the large clamp, first clip the dust cover into the groove of the universal joint, and then exhaust the gas in the dust cover. Use a screwdriver to lift up a corner of the dust cover, being careful not to puncture the dust cover, and then go back and forth. Push and pull the universal joint, you can hear the sound of gas flowing, stay the universal joint in the middle position, take out the screwdriver and clamp the big clamp
- ◆ Wipe clean the grease on the universal joint and the intermediate shaft and then use it
- ◆ The above maintenance procedures are applicable to the inner ball cage of the front drive shaft

EXPLODED VIEW OF FRONT SUSPENSION9 -	· 2
EXPLODED VIEW OF REAR SUSPENSION9 -	· 4
TECHNICAL PARAMETER9 -	- 6
DEDICATED TOOLS9 -	. 7
SHOCK ABSORBER9 -	. 8
Absorber inspection9 -	. 8
Measure the free length of the spr	, i
ng 9 -	8
absorber preloading adjustm	е
nt9 -	8
absorber damping adjustm	е
nt9-1	0
Compression damping adjustm	е
n t	0
Reset damping adjustm	е
nt9-1	0
Absorber disassem	b
ly9-1	11
Assembly absorber installat	i
o n	11
Check the adjustable pneumatic shock a	b
s o r b e r	1
Absorber scrapped9-	12
FRONT SUSPENSION 9-	12

EXPLODED VIEW OF FRONT SUSPENSION




No.	Fastener		Domorko		
INO.	rastener	N·m	kgf∙m	ft·lbs	Remarks
1	Hexagon socket screws with cylindrical head M8×25	22 ~ 28	2.2~2.8		
2	Shock absorber mounting bolt M12×1.25×95	112~128	11.2~12.8	82.6~94.4	
3	Shock absorber mounting nut M12x1.25	112~128	11.2~12.8	82.6~94.4	
4	Shock absorber mounting nut M12x1.25	8~12	0.8~1.2		
5	balance bar Mounting bolt M8x35	22 ~ 28	2.2~2.8		
6	Bolt M10×1.25	40 ~ 50	4.0~5.0		
7	Steering knuckle mounting bolts M10×1.25×45	40 ∼ 50	4.0~5.0		
8	Upper rocker arm bolt M12×1.25×320	112~128	11.2~12.8	82.6~94.4	
9	Upper rocker arm bolt M12×1.25×320	112~128	11.2~12.8	82.6~94.4	

Remark:

D----- Fill grease through oil cup nozzle (1000Km/ time)

EXPLODED VIEW OF REAR SUSPENSION



No.	Fastener		Remarks		
INO.		N·m	kgf∙m	ft·lbs	Remarks
1	Hexagon socket screws with cylindrical head M8×25	22 ~ 28	2.2~2.8	16.2~20.7	
2	mounting	112~128	11.2~12.8	82.6~94.4	
3	Shock absorber mounting bolt M12×1.25×95	112~128	11.2~12.8	82.6~94.4	
4	balance bar Mounting bolt M8x35	22 ~ 28	2.2~2.8	16.2~20.7	
5	Bolt M12×1.25×75	112~128	11.2~12.8	82.6~94.4	
6	Bolt M12×1.25×65	112~128	11.2~12.8	82.6~94.4	


Remark:


E----- Add grease through oil cup nozzle (1000Km/ time)

TECHNICAL PARAMETER


Item	Setting	Available range	
Front absorber: • Preloading setting position of normal hydraulic	64": 35mm(1.4in.)	$20\sim$ 45mm (0.8 \sim 1.8in.)	
damping absorber spring (From the bottom of the upper mounting seat to the position of the adjusting nut)	72": 85mm(3.34in.)	$65\sim 95$ mm $(2.6\sim 3.74$ in.)	
Rear absorber: • Preloading setting position of normal hydraulic		120 \sim 150mm (4.73 \sim 5.9in.)	
damping absorber spring (From the bottom of the upper mounting seat to the position of the adjusting nut)		170 \sim 210mm (6.7 \sim 8.37in.)	
High speed compression damping adjustment (clockwise adjustment)	3 gear	1gear \sim 9 gear	
Low speed compression damping adjustment (clockwise adjustment)	1 turn	0 \sim 2.5 turn	
Restore damping adjustment (from clockwise adjustment)	1 gear	1gear \sim 14 gear	
gaseous tension	1Мра		


DEDICATED TOOLS



















SHOCK ABSORBER

Absorber inspection

Because the front shock absorber is a sealed unit, it cannot be disassembled, only external inspection is required. If one unit is damaged, replace two shock absorbers together as a set. If only one unit is replaced, when the two shock absorbers are out of balance, it may cause the vehicle to become unstable at high speeds or deteriorate the overall comfort.

Measure the free length of the spring

[A] lock nut

【B】 adjustment nut

[C] Spring preload position

 Screw the lock nut 【A】 to the required position, and then unscrew the adjustment nut 【B】, adjust the position of the nut 【C】

Spring preload position **[C]** setting standard: Narrow front Absorber 35mm(1.4in.), usable range $20mm(0.8in.) \sim 45mm(1.8in.)$

Narrow rear Absorber 130mm(5.1in.) , usable range 120mm(4.73in.) \sim 150mm(5.9in.)

Wide front Absorber 85mm(3.34in.) , usable range 65mm(2.6in.) \sim 95mm(3.74in.)


Wide rear Absorber 170mm(6.7in.), usable range 170mm(6.7in.)~210mm(8.37in.)





absorber preloading adjustment

[A] crescent wrench

- ◆ The spring adjusting nut of the air pressure damping shock absorber is at the upper end of the spring, and the locking nut is loosened with the tool 【A】. Then turn the adjusting nut to loosen it.
- Adjust the nut position according to the range in the above table to achieve the desired comfort.









If the spring action feels too soft or too hard, set it to:

Position	Spring	Environment	Load	Terrain	Speed
↑	Soft	Soft	Light	Flat	Low
standard	1	↑	↑	↑	1
position	\downarrow	\downarrow	\downarrow	\downarrow	\downarrow
\downarrow	Hard	Hard	Heavy	Bumpy	High



absorber damping adjustment


To accommodate a variety of riding conditions, the spring preload can be adjusted for shock absorbers or spring replacements. The damping force can also be easily adjusted without changing the oil viscosity.



Compression damping adjustment

- With 16mm sleeve to rotate the compression damping regulator 【A】 at the upper part of the cylinder seat, can adjust the compression resistance under high speed vibration frequency, clockwise direction (H) damping to increase, counterclockwise direction (S) damping to reduce.
- ◆ Use a flat-head screwdriver to rotate the compression damping regulator 【B】 at the upper part of the cylinder seat to adjust the compression resistance under low speed vibration frequency. Clockwise (H) damping is increased, and counterclockwise (S) damping is decreased.

The compression damping regulator has 8 gears, and the factory set gear is the first gear.




Reset damping adjustment

Turn the damping regulator at the bottom with a flathead screwdriver to increase the damping in the needle direction (H) and decrease the damping in the counterclockwise direction (S).

The restoration damping regulator has a total of 12 gears, and the factory set gear is the sixth gear.

Tool: [C] flat-head screwdriver



Absorber disassembly


- [A] Airbag mounting bolt M8x25
- 【B】 Shock absorber mounting bolt
- ◆ Raise a vehicle with a jack or support frame so that the wheels do not touch the ground.
- ◆ Remove the upper and lower installation bolts of the shock absorber with A tool 【A】 and 【B】
- ◆ Take out the front shock absorber

Assembly absorber installation

- Put the upper end of the front shock absorber into the frame mounting seat, and set the bolts and nuts
 [B]
- ◆ The lower end of the front shock absorber is installed on the front rocker arm mounting seat, and the bolts and nuts are covered 【B】
- ◆ Install the shock absorber air bag on the frame mounting seat, and set the bolt 【A】
- ◆ Tighten the upper and lower mounting bolts and nuts with tools.
- Front and rear shock absorbers are disassembled in the same way.


Shock absorber fixed nut torque

115 N·m (11.5kgf·m, 83ft·lb)



Check the adjustable pneumatic shock absorber

- ◆ Check the upper and lower mounting seat
- ◆ If the joint bearing combination is damaged, replace them.
- [A] wire retainer
- 【B】 Plain bearing combination



Absorber scrapped

▲ WARNING


As the oil container of the rear shock absorber contains nitrogen, do not incinerate the gas that has not been released in the container, otherwise it may explode.


[A] valve cover

- Remove the shock absorber (see shock absorber removal)
- ◆ Remove the screw 【A】 and release nitrogen
- Remove the valve

▲ WARNING

Do not point the valve at your face or body because high pressure gas is dangerous.








Front Rocker arm disassembly


- 【A】 front brake calipers
- 【B】 Front knuckle assembly
- 【C】 Brake hose fixing bolt
- **[D]** Steering pull rod nut
- **[E]** Ball pin connecting rod bolt
- **[F]** Rocker arm mounting bolt
- ◆ Remove the brake caliper 【A】, remove the pipe fixing bolt 【C】
- Remove steering knuckle component 【B】
- Remove the brake hose fixing bolt [A]



- Remove steering pull rod nut 【D】(front rocker arm)
- ◆ Remove stabilizer bar connecting rod 【E】
- ◆ Remove rocker arm mounting bolt 【F】

Torque of steering rod nut 【D】


45 N·m (4.6 kgf·m, 33ft·lbs)




REAR SUSPENSION


Rear Rocker arm disassembly


- [A] rear brake calipers
- [B] Rear axle support assembly
- 【C】 Brake hose fixing bolt
- **[D]** Axle support mounting bolt
- [E] Rear stabilizer bar ball pin connecting rod
- **[F]** Rocker arm mounting bolt
- 【G】 Rocker arm tie rod
- ◆ Remove the brake caliper 【A】, remove the pipe fixing bolt 【C】
- ◆ Remove axle support mounting bolt 【D】, remove rear axle support assembly 【B】



- ◆ Remove rocker arm pull rod 【G】
- ◆ Remove rear stabilizer bar ball pin connecting rod【E】
- ◆ Remove rocker arm mounting bolt 【F】







Front Rocker arm disassembly

【C】 dust cover

[D] oil cup

[E] on the kingpin

[F] Under the kingpin

【G】 Retainer ring for shaft

◆ Removal of Dust Cover from both ends 【A】;

◆ Pressure out of Rocker arm liner 【B】;

Pressure out of the two ends of the rocker arm buffer sleeve 【C】:

◆ Removal of oil cup 【D】;


- ◆ Disassembly of shaft with retaining ring 【E】;
- Using a bearing driver, pressing out the kingpin component through a press [E] [F];
- -- Special equipment: clamp clamp, bearing driver

Rocker arm assembly mounting bolts/ steering rod end nuts

45 N·m (4.5 kgf·m, 33ft·lb)

Mounting bolts for stabilizer bar assembly

25N·m (2.5kgf·m, 18 ft·lb)




Rear Rocker arm disassembly

【A】 Steel wire retainer for hole

【B】 Plain bearings


- Steel wire retaining ring for holes 【A】
- Use the bearing driver, press out the plain bearing【B】
- -- Special equipment: clamp clamp, bearing driver




- The rocker maintenance
- Add grease
- When it is found that the lubricating grease in the shaft sleeve of the suspension rocker arm and the bearing sleeve of the wheel axle is reduced, or every 1000Km of the vehicle, it is necessary to fill the grease through the butter nozzle in the suspension system 【A】 using the tool.
- ◆ Dedicated tool: oiling gun

⚠ WARN I NG


When there is no proper lubrication for the suspension joints, it needs to be filled with grease and maintained regularly to avoid excessive wear of shaft sleeve.





- [A] split ring
- 【B】hub bearing
- [C] Front knuckle
- [D] Rear axle mount
- ◆ Take out the split ring 【A】 with the circlip pliers
- ◆ From the three openings opposite the bearing, use the bearing driver to press out the hub bearing 【B】 on the press and replace it

Dedicated tool: Circlip plier, Bearing drive kit





Disassembly of rear axle support assembly

- **[E]** Rear axle support
- **[F]** Plain bearing
- **[G]** Steel wire retainer for hole Dedicated tool: Circlip plier, Bearing drive kit



Check the buffer sleeve **[F]**, If the inner hole is seriously worn, it needs to be replaced, and the grease should be refilled after assembly.






FRONT / REAR STABILIZER BAR DISASSEMBLY

Front stabilizer bar disassembly

- [A] fixed bolt
- **【B】** Mounting seat for stabilizer bar
- 【C】 buffer sleeve for front stabilizer bar
- 【D】 front stabilizer bar
- **(E)** Mounting nut for front connecting rod assembly
- **[F]** Front stabilizer bar connecting rod assembly




Rear stabilizer bar disassembly

- 【G】Rear stabilizer bar
- 【H】 Rear connecting rod assembly mounting nut
- [1] Mounting bolts for rear connecting rod assembly
- [J] Rear connecting rod assembly
- [K] Rear stabilizer bar buffer sleeve

Mounting seat retaining bolt Torque

25N·m (2.6kgf·m, 18 ft·lbs)



Stabilizer bar Maintenance

[L] Straight-through oil cup


The buffer sleeve should be installed on the stabilizer bar every 1000KM

Fill an appropriate amount of grease through the straightthrough oil cup 【L】.

Special tool: oiling gun

EXPLODED VIEW OF WHEELS AND TIRES	10-2
TECHNICAL PARAMETERS	10-4
SPECIAL TOOLS	10-5
WHEEL ALIGNMENT	10-6
Front beam inspection	10-6
Front bundle adjustment	10-7
WHEEL (RIM)	10-8
Wheel Disassembly	10-8
Wheel Assembly	10-8
Wheel check	10-8
The replacement of the wheel	10-9
Tire Disassembly	10-10
Tire Assembly	10-10
TIRE	10-10
Tire Disassembly (for anti-drop rims)	10-12
Tire Assembly	10-12
Tyre mounting (for anti-drop rims)	10-13
Tire check	10-14
WHEEL HUB	10-15
Wheel hub assembly	10-15
Wheel hub disassembly/assembly	10-15

EXPLODED VIEW OF WHEELS AND TIRES



No	Fastener		Remarks		
No.		N·m	kgf∙m	ft·lb	Remarks
1	Shaft nut M24X2	300	30	221.	
2	Wheel nut M12X1.25	70 ~ 80	7.0 ~ 8.0	51.6 ∼ 59	
3	Cross tie rod end nut M10	50 ~ 60	5.0 ~ 6.0	36.9 ∼ 44.3	
4	Cross tie rod adjustment lock nut M12	50 ~ 60	5.0 ~ 6.0	36.9 ∼ 44.3	
5	Anti-slip mounting bolt M8	35 ~ 45	3.5 ~ 4.5	25.8 ~ 33.2	
6	Detachable spiral shell M12	22 ~ 25	2.2 ~ 2.5	16.2 ~ 18.4	_


W: Water or soapy water


R: Replace parts

TECHNICAL PARAMETERS

Item	Standard	Use Limit
Wheel positioning:		
Front wheel and front bundle:	10±10 mm (0.39±0.39 inch)	
Tires:		
Standard tire:		
(1) SGW1000F-S1/		
SGW1000F-S3/SGW1000F-S5:		
front	29×9.00R14 Tubeless Nylon	
rear	29×11.00R14 Tubeless Nylon	
(2) SGW1000F-S2/		
SGW1000F-S4/SGW1000F-S6:		
front/rea	30×10.00R14 Tubeless Nylon	
Tire pressure (in cold state) :		
front	120kPa (1.2 kgf/cm², 18psi)	
rear	120kPa (1.2kgf/cm², 18psi)	
Maximum tire pressure		
(In cold state)	250 kPa (2.5 kgf/cm², 36 psi)	
Tread height of tire: front		3mm (0.12inch)
rear		3mm (0.12inch)

SPECIAL TOOLS








Front beam inspection


- ◆ The front beam is the distance between the front wheels at axle height and the rear. The difference in distance is called the anterior beam value. When there is A front beam, viewed from the top of the car, the distance A (rear) is greater than B (front), as shown in the figure.
- The function of the front beam is to prevent the front wheel from running off at any time and reduce the sliding friction between the tire and the ground. If the front beam is not correct, the front wheels will rub against the ground, causing tread damage or abnormal wear.



A (rear) - B (front) =toe value


(The distances A and B are measured at the height of the axle when the vehicle is parked on a flat surface.)


- Apply thick chalk or paint line near the center of the front tire.
- When turning a wheel, make a small mark near the center of the chalk coating with a needle marker.



- Place the front wheel on the ground and fix the handlebars.
- ◆ At axle height, measure the distance between front tire front and rear marking or paint line.
- ◆ The front beam is obtained by subtracting the measured value at the rear from the measured value at the front. If the forebeam is not within the specified range, continue the forebeam adjustment procedure.

Standard: 10±10 mm (0.39±0.39 inch)





[A] lock nut [B] lock nut

- ◆ 【C】Pull rod
- ◆ Loosen the lock nut [A] [B] and adjust the pull rod [C] the same number of turns on both sides to reach the specified front bundle.


TIPS

- Lock nut [A] on tie rod is left screw thread. Loosen the lock nut by turning it clockwise.
- If the front bundle reaches the specified value, the length of each tie rod
- (1) SGW1000F-S1/SGW1000F-S3/SGW1000F-S5:

(512~542) mm (20~21inch)

(2) SGW1000F-S2/SGW1000F-S4/SGW1000F-S6:

(593~623) mm (23~24.5inch)




WARNING

Adjust the length of the tie rod so that the visible thread length at both ends of the tie rod 【E】 is even, Uneven thread length can cause damage to the end of the tie rod.

- ◆ Check the front bundle.
- ◆ Tighten:

The tie rod adjusts the torque of the locking nut $$50 \sim 60~{\rm N.\ m}$$

Test drive vehicle.



WHEEL (RIM)

Wheel Disassembly


[A] Wheel nut

- ◆ Loosen the wheel nut 【A】
- Support the vehicle with a bracket or jack to lift the wheels off the ground.

Special tool: Jack.


Tear down:

- ♦ Wheel nut
- ♦ wheel




Wheel Assembly

- ◆ Position the wheels so that the air valve 【A】 faces the outside of the vehicle
- ◆ Tighten the wheel nuts in a cross way




100~120N.m (74~88ft·lb)



Wheel check


 Check whether there are depressions on both sides of the rim 【A】. If there are depressions, please replace them.




Remove the tire and check the air sealing surface [A] of the rim for scratches or scratches. If necessary, use a fine emery cloth to polish the air sealing surface.



- Shake the wheel with both hands for excessive or abnormal movement, check whether the hub bearing is loose or damaged, if necessary, please replace the hub bearing.
- ◆ Remove the wheel (see Wheel removal).
- ◆ Remove tire from rim (see Tire removal).
- Remove the valve mouth assembly and throw away.



- [A] Plastic cover
- [B] Spool
- 【C】Stem seal
- [D] Stem
- 【E】 Seat





- Install new air valve on new rim.
- ◆ Remove bonnet, moisten stem with soap solution, and pull stem 【A】 from inside out through rim until it gets stuck in place.

A CAUTION

Do not use oil or petroleum distillate to moisten the stem as it degrades rubber.

- Install the tire on the new rim (see Tire installation).
- Wheel mounting (please refer to wheel mounting)





TIRE

Tire Disassembly

- ◆ Remove the Tire
- ◆ Loosen the valve to deflate the tire.

Use the appropriate spool tool [A]

◆ Lubricate the tires and rims on both sides of the wheel with soap solution or water 【B】.This helps the tires slide off the rim flange.

A CAUTION

Do not lubricate rim and tire rims with oil or petroleum fractions as they can spoil the tire.

 Remove the tire from the rim using a suitable commercial tire changer.

TIPS

Tires cannot be removed manually because they fit tightly to the rim.

Tire Assembly

- Check rim (refer to wheel check).
- ◆ Replace the new air valve.

▲ WARNING


Whenever you change a tire, change the air valve.Do not reuse the air valve.


- Whenever you change a tire, change the air valve.
 Do not reuse the air valve.
- Lubricate the tire rim and tire rim with soap solution or water.

A CAUTION

Do not use lubricants other than aqueous soap and water.

WHEELS AND TIRES





- ◆ Support the rim 【A】 on a suitable bracket 【B】 to prevent the tire from slipping off.
- Inflate the tire until the rim is fixed to the tire rim.

Maximum air pressure of tire (fixed on wheel when cold)

front and rear: 250 kPa (2.5 kgf/cm², 36 psi)

WARNING

Do not inflate the tire above the maximum tire pressure. Overinflated air can cause a tire to explode, potentially causing injury and death.

- Check whether the rim lines [A] on both sides of the tire are parallel to the rim flange [B].
- If the rim lines are not parallel to the rim flange, bleed the tire, moisten the sealing surface again, and inflate it again.
- ◆ Check whether there is air leak after the tire is in place correctly.
- Apply soap solution around the tire tire rim, and then check for air bubbles.
- Bleed the tire to the specified pressure...

TIPS

Segway offers tire pressure gauges and user kits.

Tire pressure (in cold state)

Front: 120Pa (1.2kgf/cm², 18psi) Rear: 120kPa (1.2kgf/cm², 18psi)


Wheel mounting (see Wheel mounting).


• Wipe the soap and water solution from the tire and dry the tire before operation.

▲ WARNING

Do not operate the vehicle while soap and water are still around the wheel rim, it can cause tyre separation and can lead to dangerous conditions.

- Tire Inspection
- ◆ Refer to the "Wheels/Tires" section of the Regular Maintenance section.





Tire Disassembly (for anti-drop rims))

[A] detachable ring fastening bolts

【B】 detachable coil

- Take off the wheel.
- Remove all detachable ring fastening bolts 【A】.
- ◆ Remove the detachable coil 【B】.
- ◆ Lubricate tires and rims on both sides of the wheel with soap solution or water 【C】. This helps the tires slide off the rim flange.

A CAUTION

Do not lubricate rim and tire rims with oil or petroleum ingredients as they can spoil the tire.

 Remove the tire from the rim using a suitable commercial tire changer.

TIPS

Tires cannot be removed manually because they fit tightly to the rim.

Tire Assembly

- ◆ Check rim (refer to wheel check)
- ◆ Replace the valve mouth with a new one.

MARNING


Whenever you change a tire, change the valve port. Do not reuse valve mouth.

- ◆ Check the tire for wear and damage (refer to tire inspection).
- Lubricate the tire rim and tire rim with soap solution or water.

A CAUTION

Do not use lubricants other than aqueous soap and water.

WHEELS AND TIRES



Tyre mounting (for anti-drop rims)

[A] Rim

【B】Bracket


- ◆ Support the rim 【A】 on A suitable bracket 【B】 to prevent the tire from slipping off.
- ◆ Tighten the detachable ring fastening bolts in a cross way.



◆ Inflate the tire until the rim is fixed to the tire rim.

Maximum tire inflation pressure (can be fixed to rim when cold)

Front and rear: 250 kPa (2.5 KGF/cm², 36 psi)




▲ WARNING

Do not inflate the tire above the maximum tire pressure. Overinflated air can cause a tire to explode, potentially causing injury and death.

[C] Rim

[D] Screw sleeve

◆ If the anti-drop ring screw sleeve 【D】 is damaged, please replace the anti-drop ring screw sleeve





screw sleeve torque

22~25N.m (2.2~2.5kgf·m, 16.2~18.4ft·lb)

◆ If necessary, replace rim 【B】 and screw sleeve【D】 as a whole.

WHEELS AND TIRES





Check whether the rim lines 【A】 on both sides
 of the tire are parallel to the anti-slip rim/rim flange
 (B) and the surrounding relative clearance is
 uniform.

If the rim line and the rims/rim flange are not parallel or the relative gap around the tire is uneven, bleed the tire, re-lubricate the sealing surface, and then re-inflate the tire

- Check whether there is air leak after the tire is in place correctly.
- Apply soap solution to the tire rim, and check whether there is air bubble.
- ♦ Bleed the tire to the specified pressure.
- Check the tire pressure with the barometer.

TIPS

Segway offers tire pressure gauges and user kits..

Tire pressure (in cold state)

Front: 120Pa (1.2kgf/cm², 18psi) Rear: 120kPa (1.2kgf/cm², 18psi)

- Wheel mounting (see Wheel mounting).
- Wipe the soap and water solution from the tire and dry the tire before operation.


MARNING

Do not operate the vehicle with soap and water around the wheel rim.

It can cause tyre separation and can lead to dangerous conditions.

Tire check

◆ Refer to the "Wheels/Tires" section of the Regular Maintenance section.




A B



Remove rim mounting seat assembly

- ◆ Remove the wheel (see wheel removal).
- Unplug: split pin [A]
- ◆ Loosen half axle nut [B]
- Unscrew the mounting bolt, remove the caliper [D], and let the caliper hang freely Hang up.
- ◆ Remove axle nut [B], remove washer [E] and pull down hub Install seat assembly [C] and brake disc.
- Separate the brake disc from the hub



Wheel hub assembly


Installing a brake disc (see "Braking" chapter)

Tighten axle nut torque	
300 N.m(30.6kgf·m,221ft·lb)	

◆ Insert the new cotter 【A】 and bend it to the nut 【B】.

A CAUTION

- When inserting the cotter, if the slotted nut does not align with the open pin hole in the half shaft, tighten the nut clockwise until the next hole is aligned.
- ◆ Loosen once and tighten again as the slot passes through the nearest hole.




Wheel hub disassembly/assembly

- No need to press out hub bolts [A].
- If any hub bolts are damaged, please replace hub mounting seat 【B】 and bolt 【A】 totally.

BRAKE SYSTEM

E	XPLODED VIEW OF BRAKE SYSTEM	10-2
E	XPLODED VIEW OF PARKING BRAKE	10-3
SI	PECIFICATIONS	10-4
SI	PECIAL TOOLS	10-4
BI	RAKE FLUID	10-5
C	ALIPER	10-6
C	ALIPER INSTALLATION	10-6
	Caliper Disassembly	10-7
	Caliper Assembly	10-7
	Piston and Cylinder Damage	10-8
	Caliper Holder Shaft Wear Inspection	10-8
	Brake Pad Removal	10-9
	Brake Pad Installation	10-9
	Brake Pad Wear Inspection	10-9
ВІ	RAKE PADS	10-9
ВІ	RAKE DISCS	10-10
	Disc Cleaning	10-10
	Disc Removal	10-10
	Disc Installation	10-10
	Disc Wear	10-10
	Brake Hose Inspection	10-11
ВІ	RAKE PEDAL	10-11
	Brake Pedal Position Adjustment	10-11
PÆ	ARKING CABLE	10-11
	Parking cable removal	10-11
	Installation of parking cable	10-11


EXPLODED VIEW OF BRAKE SYSTEM



No.	Fastener		Torque		Remarks
140.	i asteriei	N·m	kgf∙m	ft·lb	Remarks
1	Disc Mounting Bolts	37	3.8	27in·lb	
2	Brake fastening bolt	45	4.5	33in·lb	
3	Brake Hose Banjo Bolts	25	2.5	18in·lb	

- 1. Brake disc bolts, brake main pump bolts, and brake fastening bolts need to be inspected and tightened regularly;
- 2. The brake sliding rod dust cover needs to be coated with silicone oil to ensure flexible movement.

驻车制动爆炸图



No.	Fastener		Torque		Remarks
140.	i asterier	N·m	kgf∙m	ft∙lb	rtemarks
1	Parking Brake Lever Screw	8. 8	0.9	78in.lb	
2	Parking handle fastening bolt	8.8	0.9	78in.lb	


Specifications

Item	Standard	Service Limit
Brake Fluid:		
Туре	DOT 4	
Front Disc Brake:		
Pad lining thickness	4.0 mm (0.16 in.)	1 mm (0.04 in.)
Disc thickness	4.8~5.2mm (0.19~ 0.205 in.)	4 mm (0.16 in.)
Disc runout	TIR 0.08 mm (0.003 in.) or less	TIR 0.1 mm (0.004 in.)
Rear Brake Lever, Pedal and Cables:		
Rear brake pedal position	$35 \sim 40 \text{ mm } (1.38 \sim 1.57 \text{ in.})$	
Working stroke of parking handle	60~80 mm (2.4~ 3.14in.)	
Working stroke of rear brake pedal	25~30 mm (1.0~1.2in.)	

---- 11 - 3 --

BRAKE SYSTEM

SPECIAL TOOLS



BRAKE FLUID

WARNING

When working with the disc brake, observe the precautions listed below.

- 1. Never reuse old brake fluid.
- 2. Do not use fluid from a container that has been left unsealed or that has been open for a long time.
- 3. Do not mix two types and brands of fluid for use in the brake. This lowers the brake fluid boiling point and could cause the brake to be ineffective. It may also cause the rubber brake parts to deteriorate.
- 4. Don't leave the reservoir cap off for any length of time to avoid moisture contamination of the fluid.
- 5. Don't change the fluid in the rain or when a strong wind is blowing.
- 6. Except for the disc pads and disc, use only disc brake fluid, isopropyl alcohol, or ethyl alcohol for cleaning brake parts. Do not use any other fluid for cleaning of

these parts. Gasoline, engine oil, or any other petroleum distillate will cause deterioration of the rubber parts. Oil spilled on any part will be difficult to wash

off completely and will eventually deteriorate the rubber used in the disc brake.

- 7. When handling the disc pads or disc, be careful that no disc brake fluid or any oil gets on them. Clean off any fluid or oil that inadvertently gets on the pads or disc with a high flash-point solvent. Do not use one which will leave an oily residue. Replace the pads with new ones if they cannot be cleaned satisfactorily.
- 8. Brake fluid quickly ruins painted surfaces; any spilled fluid should be completely washed away immediately.
- 9. If any of the brake line fittings or the bleed valve is opened at any time, the AIR MUST BE BLED FROM THE BRAKE LINE.

Brake Fluid Recommendation

Use extra heavy-duty brake fluid only from a container marked DOT4.

Recommended Disc Brake Fluid

Type: DOT 4

Brake Fluid Level Inspection

•Refer to the Brakes in the Periodic Maintenance chapter.

Brake Fluid Change

•Refer to the Brakes in the Periodic Maintenance chapter.

Brake Line Air Bleeding

•Refer to the Brakes in the Periodic Maintenance chapter.



CALIPER

- ◆ Remove the front wheel (see Wheels/Tires chapter).
- ◆ Loosen the banjo bolt 【A】 at the brake hose lower end, and tighten it loosely.
- Unscrew the caliper mounting bolts 【B】.
- ◆ Detach the caliper 【C】 from the disc.
- Unscrew the banjo bolt and remove the brake hose[D] from the caliper.

WARNING

Immediately wash away any brake fluid that spills.

▲ CAUTION

If the caliper is to be disassembled after removal and if compressed air is not available, disassemble the caliper before the brake hose is removed (see Caliper Disassembly).

Caliper Installation

- ◆ Install the caliper and brake hose lower end.
- Replace the washers that are on each side of hose fitting with new ones.
- ◆ Tighten:


Torque Caliper Mounting Bolts: Brake Hose Banjo Bolt

25N·m(2.5kgf·m,18 ft·lb)

- Check the fluid level in the brake reservoir.
- Bleed the brake line .
- Check the brake for good braking power, no brake drag, and no fluid leakage.

▲ WARNING

Do not attempt to drive the vehicle until a firm brake lever can be obtained by pumping the brake lever until the pads are against each disc. The brakes will not function on the first application of the lever if this is not done.



Caliper Disassembly

◆ Remove:

Caliper (see Caliper Removal)

Pads (see Brake Pad Removal)

Anti-rattle Spring

Using compressed air, remove the piston.

Cover the caliper opening with a clean, heavy cloth 【A】. Remove the piston by lightly applying compressed air 【B】 to where the brake line fits into the caliper.

To avoid serious injury, never place your fingers or palm inside the caliper opening. If you apply compressed air into the caliper, the piston may crush your hand or fingers.

- •If compressed air is not available, do as follows with the brake hose connected to the caliper.
- •Prepare a container for brake fluid.
- •Remove the pads and spring (see Brake Pad Removal).
- •Pump the brake lever to remove the caliper piston.


♦ Remove:

Dust Seal [A]

Fluid Seal [B]


Bleed Valve [C] and Rubber Cap [D]


Boots [E] and Caliper Holder [F]




Caliper Assembly

- ◆ Replace the fluid seal 【A】 with a new one.
- Apply brake fluid to the fluid seal, and install it into the cylinder by hand.
- ◆ Replace the dust seal 【B】 with a new one if it is damaged.
- Apply brake fluid to the dust seal, and install it into the cylinder by hand.









- Apply brake fluid to the outside of the pistons 【A】, and push them into the cylinder by hand. Take care that neither the cylinder nor the piston skirt gets scratched.
- ◆ Replace the rubber boots 【B】 if they are damaged.
- Apply a thin coat of silicone grease to the caliper holder shafts 【C】 and holder holes 【D】 (Silicone grease is a special high temperature, water-resistant grease).
- ♦ Install:

Caliper Holder [E]

Bleed Valve 【F】 and Rubber Cap

Torque-Bleed Valve 7.9N·m (0.7 kgf·m,5.9 ft·lb)

- ◆ Install the anti-rattle spring 【A】 in the caliper as shown.
- ◆ Install the pads (see Brake Pad Installation).


Piston and Cylinder Damage


- ◆ Visually inspect the pistons 【A】 and cylinder surfaces.
- ◆ Replace the caliper if the cylinder and piston are badly scored or rusty.


Caliper Holder Shaft Wear Inspection

The caliper body must slide smoothly on the caliper holder shafts 【B】. If the body does not slide smoothly, one pad will wear more than the other, pad wear will increase, and constant drag on the disc will raise brake and brake fluid temperature.

- Check to see that the caliper holder shafts are not badly worn or stepped, and that the rubber friction boots are not damaged.
- ◆ If the rubber friction boot is damaged, replace the rubber friction boot.
- If caliper holder shaft is damaged, replace the caliper holder shaft and rubber friction boot as a unit.







BRAKE PADS

Brake Pad Removal

- ◆ Remove the front rim assembly or the rear rim assembly.
- ◆ Loosen the fastening bolt 【D】 from the guide rod of the brake assembly 【C】. In the process of loosening the bolt 【D】, the head of 【C】 must always be in close contact with the brake caliper body 【B】 and limit. Otherwise, it will follow 【D】 because 【C】 is not in position, and 【D】 cannot be disassembled.
- ◆ Rotate the brake caliper body at least 90 degrees so that the brake pad 【A】 can be easily removed from the spring holder 【E】 on the inner and outer sides of the brake disc.

Brake Pad Installation

- Push the caliper piston in by hand as far as it will go.
- Be sure that the anti-rattle spring is in place.
- ◆ Install:
- Install the brake pads in the upper and lower spring holders [E] on the inner (or outer) side and fit the brake discs respectively
- Rotate the brake caliper down so that the mounting hole position coincides with the hole position of the brake assembly guide rod [C], and the brake assembly guide rod [C] must be confined to the brake caliper [B] and be in contact with the brake Calipers [B] fit.
- 3. Apply thread glue to the tightening bolt **[D]** that has just been loosened.

Tighten the fastening bolt [D]


25N·m(2.5kgf·m,18 ft·lb)

WARNING

Do not attempt to drive the vehicle until a firm brake lever can be obtained by pumping the brake lever until the pads are against each disc. The brake will not function on the first application if this is not done.

Brake Pad Wear Inspection

 Refer to the Brakes in the Periodic Maintenance chapter.



Brake Discs

Disc Cleaning

Poor braking can be caused by oil on a disc. Oil on a disc must be cleaned off with an oilless cleaning fluid such as trichloroethylene or acetone.

WARNING

These cleaning fluids are usually highly flammable and harmful if breathed for prolonged periods. Be sure to heed the fluid manufacturer's warnings.

Disc Removal

Remove:

Front Hub (see Wheels/Tires chapter)

Brake Disc Mounting Bolts [A]

Brake Disc [B]



- ◆ The disc must be installed with the marked side 【A】 facing toward the steering knuckle.
- Apply a non-permanent locking agent:

Disc Mounting Bolts

◆ Tighten:



After installing the discs, check the disc runout. Completely clean off any grease that has gotten on either side of the disc with a high flash-point solvent. Do not use one which will leave an oily residue.





- Measure the thickness of each disc at the point
 (A) where it has worn the most.
- Replace the disc if it has worn past the service limit.

Disc Thickness

Standard: 4.8 \sim 5.2mm (0.19 \sim 0.205 in.)

Service Limit: 4 mm (0.16 in.)





Brake Hoses

Brake Hose Inspection


- ◆ Refer to the Brakes in the Periodic Maintenance chapter.
- ◆ Brake Hose Replacement
- Refer to the Brakes in the Periodic Maintenance chapter.



BRAKE PEDAL

Brake Pedal Position Adjustment

- Loosen the locknut 【A】, and turn the adjusting bolt
 【B】 until the brake pedal is correctly positioned.
- ◆ Tighten the locknut.
- Check the brake pedal free play .



D E F

PARKING CABLE

Parking cable removal

- ◆ Take the head of the parking cable 【C】 out of the rotating arm 【B】 in the rear brake
- Disassemble 2 pieces of M8 nuts 【A】
- ◆ Remove the middle guard plate, loosen the corresponding 2 pieces of M8 nuts 【D】 on the parking cable to be dismantled, and then take the corresponding parking cable head 【E】 out of the splitter plate 【F】.


Installation of parking cable

The installation of the parking cable can be completed according to the reverse order of the above-mentioned "parking cable removal".

STEERING SYSTEM


EXPLODED DIAGRAMS (EPS MODELS)	12-2
STEERING WHEEL DISASSEMBLY	12-3
STEERING SHAFT DISASSEMBLY	12-4
BEARING REPLACEMENT	12-6
EPS DISASSEMBLY	12-7
STEERING MACHINE DISASSEMBLY	12-8
STEERING SYSTEM INSTALLATION	12-9

EXPLODED VIEW OF STEERING SYSTEM (NON-EPS MODELS)



No.	Fastener		Torque		Remarks
INO.	i asteriei	N·m	kgf∙m	ft·lbs	i vernarks
1	Nut M14×1.5	70	7.1	52	
2	Step bolt M8	25	2.5	18	Thread fastening glue
3	Step boltM6	10	1	7.5	
4	Bolt M8×35	35	3.6	26	
5	Bolt M8×16	35	3.6	26	Thread fastening glue
6	Bolt M8×25	35	3.6	26	
7	Bolt M10×1.25×105	70	7.1	52	
8	Bolt M10×1.25×25	70	7.1	52	
9	Slotted nut m12	45	4.6	33	


STEERING WHEEL REMOVAL (NON-EPS MODELS)




▲ CAUTION

This procedure is suitable for non-EPS models, using this procedure to operate the EPS models vehicle may cause damage to the EPS or power steering system.


- [A] Steering wheel cover
- 【B】Nut
- 【C】Steering wheel
- ◆ Remove the steering wheel cover 【A】 in the direction of the arrow



◆ Remove the steering wheel fixing nut 【B】




- ◆ Remove the steering wheel in the direction of the arrow 【C】
- If the steering wheel cannot be removed, please continue to follow this procedure to remove the steering shaft



STEERING SHAFT DISASSEMBLY (EPS MODELS)


- [A] Display instrument assembly
- **[B]** Direction stud
- 【C】Gas spring bolt
- 【D】 Steering upper shaft bolt nut
- **[E]** Steering shaft
- **[F]** Steering wheel
- Disassemble interior parts such as instrument panel,
 see [xx-xx];
- ◆ Disassemble the display instrument assembly 【A】;



- ◆ Remove the bolts on both sides of the direction column 【B】;
- Remove the gas spring bolt 【C】;
- Remove the upper steering shaft bolt and nut 【D】,
 and remove the steering column assembly;

▲ WARNING

Since the gas spring contains high-pressure gas, please do not burn it or dismantle it privately, otherwise it may explode.




Fix the steering wheel on the vise, hit the steering shaft with a hammer [E], Separate the steering wheel [F] from the conical surface of the steering shaft;

A CAUTION

Be careful not to damage the threaded when hitting the steering shaft.

STEERING SYSTEM



STEERING SHAFT REMOVAL (NON-EPS MODELS)


[A] Circlip for shaft

【B】Upper section of steering shaft

[C] Bolt


【D】Lower section of steering shaft

◆ Remove the circlip for the shaft 【A】, and remove the upper section of the steering shaft 【B】



◆ Remove the fixing bolt 【C】, and remove the lower part of the steering shaft 【D】


STEERING SYSTEM




[A] Bolt

【B】EPS motor

- ◆ Remove the fixing bolt 【A】;
- If you need to replace the EPS motor, remove the fixing bolt 【A】;



- ◆ Disassemble the wiring harness connector of the EPS motor;
- ◆ Remove the EPS motor in the direction of the arrow
 【E】:




BEARING REPLACEMENT

[A] Steering column

[B] Steering


 Clamp the steering column 【A】 with a vise, use a suitable crowbar to go deep into the steering column, and knock out the bearings 【B】 at both ends;



 Using a bearing driver, press the bearings (B) at both ends into the steering column on the pressure equipment (B)


A CAUTION

Before installing the bearing, make sure that the bearing is intact without scratches and corrosion. The bearing and the hole are cleaned and free of impurities. The bearing can be flexibly rotated by hand after pressing.



STEERING MACHINE DISASSEMBLY (EPS MODELS)


- 【A】Nut
- 【B】Steering rod
- [C] Bolt
- [D] Direction machine
- Remove the nuts on both sides of the steering rod wheel 【A】, and knock the steering rod in the direction of the arrow with a hammer to separate the steering rod from the cone of the steering knuckle;



A CAUTION

Be careful not to damage the threaded part when knocking on the steering rod.

Remove the steering gear end nut 【A】 of the steering tie rod, and knock the steering tie rod in the direction of the arrow with a hammer to separate the steering tie rod from the cone of the steering wheel;



▲ CAUTION

Be careful not to damage the threaded part when knocking on the steering rod.

◆ Remove the 5 fixing bolts 【C】, and remove the steering wheel 【D】;


INSTALLATION OF STEERING SYSTEM

- Reverse install steering machine according to removal procedure
- Install the steering rod in the reverse direction of the removal procedure, and check the left and right steering rods to be the same length before installation
- Before installing the steering shaft or EPS, it is necessary to ensure that the two front wheels are facing straight ahead, and the steering shaft is not rotated during the assembly process
- ◆ Connect the power and signal wiring harness of the EPS motor
- After the installationd, the toe parameters of the front wheels need to be adjusted (see"wheel" for details) to ensure that the vehicle can drive in a straight line

Adjust the installation angle of the steering wheel so that the turns of left and right turning is the same, and the steering wheel is centered when driving in a straight line


- Tighten the steering wheel nut according to the torque requirement, and install the steering wheel cover
- ♦ Check function of each switch and test EPS.

EXPLODED VIEW OF CAR BODY	13-2
Seat removal	13-11
Front shelf cover	13-12
Brake fluid sight hole cover	13-12
Power switch	13-12
Electrical repair cover	13-13
Foot pedal drain cover	13-13
Battery repair cover	13-13
Gasoline pump repair cover	13-14
Regular engine maintenance	13-14
EXPLODED VIEW OF ROLL CAGE	13-15
Roll cage removal	13-16
EXPLODED VIEW OF FRAME ACCESSORIES	13-17
Frame attachment removal	13-18
FRONT BUMPER EXPLODED VIEW	13-21
Front bumper removal	13-22
EXPLODED VIEW OF REAR BUMPER ASSEMBLY	13-24
Removal of rear bumper assembly	13-25
EXPLODED VIEW OF FRONT AXLE DISASSEMBLY	13-26
Front axle disassembly	13-27
ENGINE ASSEMBLY EXPLODED VIEW	13-29
Engine disassembly	13-30




No	Factorer	Torque		Remarks	
No.	Fastener	N·m	kgf∙m	ft·lb	Remarks
1	Front panel				
2	Front refill cap				
3	Front lampshade				
4	Front ventilation grille				
5	Front left mudguard				
6	Front right mudguard				
7	Right front headlight tail cover				
8	Front right air deflector				
9	Power-off switch cover				
10	Front right mudguard rubber				
11	Right door front cover				

12 Right car door inner front cover 13 Brake fluid sight hole cover 14 Front left mudguard rubber 15 Inner front cover of left door 16 Left door front cover 17 Front left bezel 18 Front center baffle 19 Front right bezel 20 front bezel 21 Left front headlight tail cover 22 Front left air deflector 23 Large pan head hexagon socket bolt M6×16 8~12 0.8~1.2 69~103.6 in·lb	
14 Front left mudguard rubber 15 Inner front cover of left door 16 Left door front cover 17 Front left bezel 18 Front center baffle 19 Front right bezel 20 front bezel 21 Left front headlight tail cover 22 Front left air deflector	
15 Inner front cover of left door 16 Left door front cover 17 Front left bezel 18 Front center baffle 19 Front right bezel 20 front bezel 21 Left front headlight tail cover 22 Front left air deflector	
16 Left door front cover 17 Front left bezel 18 Front center baffle 19 Front right bezel 20 front bezel 21 Left front headlight tail cover 22 Front left air deflector	
17 Front left bezel 18 Front center baffle 19 Front right bezel 20 front bezel 21 Left front headlight tail cover 22 Front left air deflector	
18 Front center baffle 19 Front right bezel 20 front bezel 21 Left front headlight tail cover 22 Front left air deflector	
19 Front right bezel 20 front bezel 21 Left front headlight tail cover 22 Front left air deflector	
20 front bezel 21 Left front headlight tail cover 22 Front left air deflector	
21 Left front headlight tail cover 22 Front left air deflector	\Box
22 Front left air deflector	
	\Box
23 Large pan head hexagon socket bolt M6×16 8~12 0.8~1.2 69~103.6 in·lb	
1 = 1 = 1 = 1 = 1 = 1 = 1 = 1 = 1 = 1 =	
24 M6 nut clamp	
25 Expansion buckle assembly	
Cross recessed round head tapping screws	
ST4.2×13	
27 Waist I-shaped rubber ring	
28 Hexagon flange bolt M6×12 8~12 0.8~1.2 69~103.6 in·lb	
29 Front panel cushion	
30 large washers A grade 5	\neg
31 Circular reflector (amber)	




No.	Fastener	Torque			Remarks
		N·m	kgf∙m	ft·lb	
1	Dashboard				
2	Instrument panel right lower cover				
3	Upper right decorative strip				
4	Storage box				
5	Storage box sealing strip				
6	Storage box cover				
7	Instrument panel left lower cover				
8	Upper left decorative strip				
9	Instrument cable guard				
10	Instrument cover trim strip				
11	Mobile phone switch cover				
12	Phone cover				

13	Glove box sealing strip				
14	Mobile phone sealing strip				
15	Blank cover				
16	Box cover pin				
17	mobile phone cushion				
18	Electrical repair cover				
19	Glove box cover				
20	12V power output socket				
21	Large pan head hexagon socket bolt M6×16	8~12	0.8~1.2	69~103.6 in·lb	
22	M6 nut clamp				
23	Waist I-shaped rubber ring				
24	spring buckle				
25	4.2 Self-tapping nail splint				
26	Expansion buckle assembly				
27	Storage box drawstring				
28	glove box				
29	Lower left decorative strip				
30	Lower right decorative strip				




No.	Fastener		Domarko		
	Fasteriei	N·m	kgf∙m	ft·lb	- Remarks
1	Middle guard plate				
2	Left back panel				
3	Charging port mudguard				
4	Left guard plate				
5	Left guard plate decoration board				
6	Charging base cover				
7	Cargo box front cover				
8	B-pillar upper left lining height				
9	B-pillar lower lining height				
10	Large pan head hexagon socket bolt M6×16	8~12	0.8~1.2	69~103.6 in·lb	
11	M6 nut clamp				
12	Cross recessed pan head tapping screws ST4.2×13				
13	Transmission shaft left cover	_			


14	Front bottom plate		
15	Foot pedal left drain cover		
16	Left foot pedal		
17	Foot pedal cap		
18	Right foot pedal		
19	Right guard plate		
20	Right guard plate lining		
21	Drive shaft right cover		
22	Gasoline pump maintenance cover		
23	Foot pedal drain cover		
24	Fuel filler fender		
25	Right guard plate decoration board		
26	Seat belt rubber cover		
27	Battery buffer block		
28	Waist I-shaped rubber ring		
29	Rectangular magnet 20×10×5		
30	Cross recessed countersunk head tapping screws ST2.9×13		
31	M6 nut clamp		
32	Large Pan Head Hexagon Bolt M6×16		
33	Expansion buckle assembly		
34	Foot pedal connection		
35	Fuel tank decorative cover		
36	Cross recessed round head tapping screws ST4.2×13		
37	Large washers A grade 5		
38	Rectangular magnet N 20×10×5		
39	Battery foam pad		
40	Battery repair cover		



No.	Fastener		Remarks		
		N·m	kgf∙m	ft·lb	Remarks
1	Top beam upper cover				
2	Top beam upper lining				
3	Roof				
4	B-pillar lower left lining				
5	B-pillar upper left lining				
6	B-pillar left outer guard plate				
7	B pillar right outer guard plate (high)				
8	B pillar right upper lining (high)				
9	B pillar right lower lining (high)				
10	Large pan head hexagon socket bolt m6×16	8~12	0.8~1.2	69~103.6 in·lb	
11	Nut clamp m6				
12	Cross recessed pan head tapping screw ST 4.2×13				




No.	Fastener		Remarks		
		N·m	kgf∙m	ft·lb	Remarks
1	Rear cargo box				
2	Decorative cover under the cargo box				
3	Rear lamp cover				
4	Left rear guard plate				
5	Right rear guard plate				
6	Right rear mudguard				
7	Left rear mudguard				
8	Taillight upper left baffle				
9	Left front cover of tail light cover				
10	Tail light upper right baffle				
11	Tail lamp cover right front cover				
12	Rear storage box sealing ring				
13	Rear storage box				
14	Capping the storage box				
15	M6 nut clamp				
16	Large Pan Head Hexagon Bolt M6×16	8~12	0.8~1.2	69~103.6 in·lb	
17	Expansion buckle assembly				
18	Hexagon flange bolt M8×25	30 ~ 40	3.0~4.0	22.1~29.5	
19	Waist I-shaped rubber ring				




No.	Fastener		Remarks		
	Fasteriei	N·m	kgf∙m	ft∙lb	Nemans
1	Main driver's seat assembly				
2	Seat mounting bracket assembly				
3	Driver buckle assembly				
4	Driver lock assembly				
5	Passenger buckle assembly				
6	Passenger lock assembly				
7	Hexagon flange bolt m10×25	40~50	4.0~5.0	29.5~36.9	
8	Hexagon flange bolt m10×50	40~50	4.0~5.0	29.5~36.9	
9	304蝶形螺母M8				
10	Flat washer a grade 10				
11	Hexagon flange bolt m12×20	110~120	11.2~12.2	81~88	
12	Co-driver's seat				

Seat removal




[A] Driver Seat

Move the seat forward through the seat adjustment lever




【B】Hexagon flange bolts M10×25

- Remove the fixing bolts under the seat belt [B]
- Remove the seat belt from the seat




- [C] Dish-shaped round wing screw M8×20
- 【D】T type screw sleeve M8-φ20×17
- 【E】Flat padφ8
- ◆ Remove 【C】 【D】 【E】
- Pull out the harness connector under the seat
- ◆ Take off the seat



Front ventilation grille

Put the car body in a horizontal position first


- Remove the front bumper first
- ◆ Remove three M6 fixing bolts with a suitable tool [B]
- Remove the front ventilation grille [A]



Brake fluid sight hole cover

Put the car body in a horizontal position first

- Remove two M6 fixing bolts with a suitable tool [B]
- Remove the brake fluid sight hole cover 【A】




Power switch

[A] Power-off switch cover

Put the car body in a horizontal position first


- ◆ Remove two M6 fixing bolts with a suitable tool [B]
- ◆ Remove the power-off switch cover 【A】



Electrical repair cover

Adopt pin and hook and mushroom head installation method:


- ◆ Reach out to the arrow and pull out forcefully;
- ◆ Take out the electrical repair cover 【A】



Foot pedal drain cover

There is a water drain cover on the sides of the left and right footboards of the vehicle, which are installed by pins and hooks;


- Press the button down;
- Remove the foot pedal drain cover [A];
- The removal method of the right foot pedal drain cover is the same for left and right



Battery repair cover

Adopt pin mushroom head installation method;


- Remove the driver's seat;
- Reach out to the depression and pull out [A];
- Remove the battery repair cover



Gasoline pump repair cover

[A] Gasoline pump repair cover

- Use suitable tools to take out 4 expansion buckle components [B];
- Take out the gasoline pump repair cover [A]




Regular engine maintenance


【A】 Hand clasp position of rear storage box

- Use mushroom head installation method;
- Extend your hand to the clasp position and pull out forcefully in the direction of movement;
- ◆ Storage box after removal

EXPLODED VIEW OF ROLL CAGE




No.	Fastener	Torque		Remarks	
140.		N·m	kgf∙m	ft·lb	Remarks
1	Hexagon socket head screw M8×12	20~26	2.0~2.6	14.7~19	
2	Hexagon flange bolt M8×16	20~26	2.0~2.6	14.7~19	
3	Hexagon flange bolt M12×1.25×75	50~60	5. 0~6.0	37~45	
4	Hexagon flange bolt M12×1.25×30	50~60	5.0~6.0	37~45	
5	Hexagon flange face lock nut M12×1.25	50~60	5.0~6.0	37~45	
6	Hexagon flange bolt M12×1.25×25	50~60	5.0~6.0	37~45	_




Roll cage removal


◆ Remove the bolts of the A-pillar decorative panel (hexagonal socket head screws M8×12) and remove the A-pillar decorative panel; remove the bolts (hexagonal flange bolts M8×16) connecting the left and right upper mounting bracket components of the cargo box. Before that, you may need to remove the left and right front covers of the tail light cover and other related plastic parts (refer to the relevant chapters for details)



◆ Remove the bolts of the upper welding assembly of the top beam (hexagonal flange bolt M12×1.25×25), and remove the upper welding assembly of the top beam. Before this, you may need to remove the roof and B-pillar related plastic parts (refer to the relevant chapters for details)




◆ Remove the A-pillar connecting bolt (hexagonal flange bolt M12×1.25×75); remove the B-pillar connecting bolt (hexagonal flange bolt M12×1.25×30, nut (hexagonal lock nut M10×1.25) and remove it Top beam left\right welding components. Before this, you may need to remove the relevant plastic parts of the B-pillar (refer to the relevant chapters for details)



◆ To install the roll cage, follow the reverse procedure.

EXPLODED VIEW OF FRAME ACCESSORIES




No.	Fastener		Torque		
NO.	i asteriei	N·m	kgf∙m	ft·lb	Remarks
1	Hexagon flange bolt M10×1.25×25	40~50	4.0~5.0	30~37	
2	Hexagon flange bolt M10×1.25×75	40~50	4. 0~5.0	30~37	
3	Hexagon flange bolt M10×1.25×40	40~50	4.0~5.0	30~37	
4	Hexagon flange face lock nut M10×1.25	40~50	4.0~5.0	30~37	
5	Hexagon flange bolt M10×1.25×20	40~50	4.0~5.0	30~37	
6	Hexagon flange bolt M8×20	22~30	2. 2~3.0	17~22	
7	Hexagon socket countersunk head screw M6×16	8~12	0.8~1.2	69~103.6 in·lb	
8	Hexagon flange bolt M8×16	22~30	2. 2~3.0	17~22	
9	Large pan head hexagon socket bolt M6×16	8~12	0.8~1.2	69~103.6 in·lb	
10	Hexagon flange bolt M8×40	22~30	2. 2~3.0	17~22	
11	Hexagon flange face lock nut M8	22~30	2. 2~3.0	17~22	
12	Hexagon flange bolt M6×16	8~12	0.8~1.2	69~103.6 in·lb	




Frame attachment removal


◆ Remove the bolts of the upper bracket of the rear storage box (hex flange bolt 4-M6×16) and remove the upper bracket of the rear storage box.




◆ Remove the bolts of the seat belt fixing bracket assembly (hex flange bolt 4-M10×1.25×25) and remove the seat belt fixing bracket assembly. Before this, you may need to remove the plastic parts such as the rear cargo box, the air filter, the auxiliary water tank components, and the seat belt (refer to the relevant chapters for details)




◆ Remove the upper mounting bolts (hex flange bolts 2-M10×1.25×75), lower mounting bolts (hex flange bolts 2-M10×1.25×40) and nuts (hex flange bolts) of the rear cargo box bracket assembly Tighten the nut 2-M10×1.25) and remove the rear cargo box bracket assembly. Before that, you need to remove the plastic parts such as the rear cargo box, the air filter, and the muffler cylinder (refer to the relevant chapters for details)




◆ Remove the front and rear mounting bolts (hexagonal flange bolt 2-M10×1.25×20) and the middle mounting bolt (hexagonal flange bolt M8×20) of the left guard bar assembly, and remove the left guard bar assembly. Also remove the right guard bar assembly.




◆ Remove the bolts of the seat mounting bracket assembly (hex flange bolt 4-M8×40) and remove the seat mounting bracket assembly. Before this, you need to remove the seat, middle guard and other plastic parts, the shifter and cable, the parking mechanism and the pipeline fixed to the seat mounting bracket assembly (refer to the relevant chapters for details)




◆ Remove the installation nut (hexagonal flange face lock nut 3-M8) of the co-pilot foot pedal assembly, and remove the co-pilot foot pedal assembly.




◆ Remove the mounting bolts (hexagonal flange bolts 4-M8×16) of the engine lower guard plate, and remove the engine lower guard plate.



◆ Remove the bolts of the middle bottom plate assembly (large pan-head hexagon socket bolts 6-M6×16), and remove the middle bottom plate assembly (one for each on the left and right).



- ◆ Remove the decorative plug fixing screw (hexagon socket countersunk head screw 2-M6×16) and remove the decorative plug; remove the front fixing bolt of the upper connecting plate of the front support (hex flange bolt 2-M8×20) And side fixing bolts, hexagonal flange bolts 2-M8×20), and remove the upper connecting plate of the front support.
- ◆ Remove the mounting bolts (hexagonal flange bolts 2-M8×16) of the front support assembly of the frame and remove the front support assembly of the frame. Before this, you need to remove the plastic parts such as the front headlight cover, front panel and the pipelines fixed on the front support assembly of the frame (for details, refer to the relevant chapters)




◆ To install the frame attachment, follow the reverse procedure


A CAUTION

After installation, the upper bracket of the storage box should be after the rear cargo box is assembled. (Refer to relevant chapters for details)

FRONT BUMPER EXPLODED VIEW



No.	Fastener		Torqu	Torque		
INO.	i astellel	N·m	kgf∙m	ft·lb	Remarks	
1	Hexagon flange bolt M10×1.25×20	40~50	4.0~5.0	30~37		
2	Hexagon flange bolt M10×1.25×25	40~50	4.0~5.0	30~37		
3	Hexagon flange face lock nut M10×1.25	40~50	4.0~5.0	30~37		
4	Large pan head hexagon socket bolt M6×16	8~12	0.8~1.2	69~103.6 in·lb		




Front bumper removal


◆ Remove the lock nut of the winch motor cable, and remove the winch motor cable.

A CAUTION


After removing the motor wire of the winch, the head of the cable should be protected to prevent short circuit.




◆ Remove the mounting bolts of the front bumper assembly (hex flange bolts 2-M 1 0 × 1.2 5 × 20 and hexagon flange bolts M 1 0×1.2 5×2 5), nuts (Hexagon flange face lock nut M10×1.25) and remove the bumper assembly.




Remove the mounting bolts of the front bumper trim panel assembly (large pan-head hexagon socket bolt 4-M6×16), and remove the front bumper trim panel assembly.



Unplug the pin of the winch hook, remove the winch hook and the winch rubber pad.




◆ Remove the mounting bolts of the winch guide wheel (hexagon flange bolt M10×1.25×20), the winch guide wheel




◆ Remove the mounting bolts of the winch motor (hexagonal flange bolts M8×20), and remove the winch motor.

◆ To install the front bumper, follow the reverse procedure

EXPLODED VIEW OF REAR BUMPER ASSEMBLY



No.	Fastener	Torque		ıe	Remarks
140.	1 dotonor	N·m	kgf∙m	ft·lb	rtemants
1	Hexagon flange bolt M10×1.25×20	40~50	4.0~5.0	30~372	
2	Hexagon flange bolt M8×20	22~30	2. 2~3.0	17~22	
3	Large pan head hexagon socket bolt M6×16	8~12	0.8~1.2	69~103.6 in·lb	
4	Cross recessed pan head screw M5×30				
5	Hex nut M6				_




Removal of rear bumper assembly


◆ Remove the mounting bolts of the rear bumper assembly (hex flange bolts M10×1.25×20 and hexagon flange bolts M8×20) and remove the rear bumper assembly. Before this, you need to unplug the rear license plate light and trailer power socket cable connector (refer to the relevant chapters for details)




◆ Remove the mounting screws of the trailer power socket (cross recessed pan head screw 3-M5×30) and remove the trailer power socket.



◆ Remove the mounting screws of the rear license plate lamp (large pan head hexagon socket bolt 4-M6×16), and remove the rear license plate lamp.




◆ Remove the mounting screws of the rear license plate lamp bracket (large pan-head hexagon socket bolt 4-M6×16), and remove the rear license plate lamp bracket.




- ◆ Remove the mounting nut (hex nut M6) of the circular reflector (amber) and the circular reflector (red), and remove the reflector
- ◆ To install the rear bumper assembly, follow the reverse procedure

EXPLODED VIEW OF FRONT AXLE DISASSEMBLY



No.	Fastener		Remarks		
140.	i dotellel	N·m	kgf∙m	ft·lb	Remarks
1	Hexagon flange bolt M8×20	22~30	2. 2~3.0	17~22	
2	Hexagon flange bolt M10×1.25×215	40~50	4. 0~5.0	30~37	
3	Hexagon flange face lock nut M10×1.25	40~50	4.0~5.0	30~37	
4	Hexagon flange bolt M8×90	22~30	2. 2~3.0	17~22	
5	Hexagon flange face lock nut M8	22~30	2. 2~3.0	17~22	
6	Hexagon flange bolt M10×1.25×20	40~50	4.0~5.0	30~37	





Front axle disassembly

- Remove the front drive shaft and the front drive shaft (see the chapter on transmission system for details).
- ◆ Unplug the cable input plug on the front axle.
- Use suitable tools to remove the hoop, and remove the front axle vent pipe;
- ◆ Remove the mounting bolts of the front axle lower guard plate C (hexagon flange bolts M10×1.25×20), and remove the front axle lower guard plate C.



Before removing the front axle assembly, please make sure that the wiring harnesses on the front axle assembly are completely disconnected from the frame or main cables






- Before removing the front axle assembly, please make sure that the wiring harnesses on the front axle assembly are completely disconnected from the frame or main cables
- ◆ Remove the mounting bolts (hexagon flange bolts M10×1.25×215) and nuts (type 2 non-metallic insert hexagon flange locking nuts M10×1.25) at the lower part of the front axle, and take out the front axle lower liner A


A CAUTION

When installing the mounting bolts (hexagonal flange bolts M8×20) on the upper part of the front axle, apply a proper amount of thread glue to the threads.



Front axle disassembly

 Carefully remove the front axle from the lower part of the frame (the removal process may require you to rotate and move the front axle)




- ◆ Remove the bolt D of the front axle box body.
- ◆ Remove the mounting bolts (hexagon flange bolts M8×90) and nuts (type 2 non-metallic insert hexagon flange locking nuts M8) of the front axle upper bracket assembly B. Remove the upper bracket assembly B of the front axle.

A CAUTION


After removing the upper bracket assembly B of the front axle, reinstall the front axle box bolt D.

◆ To install the front axle, follow the reverse procedure

ENGINE ASSEMBLY EXPLODED VIEW




No.	Fastener	Torque			Remarks
INO.	i asteriei	N·m	kgf∙m	ft·lb	Remarks
1	Hexagon flange bolt M12×1.25×85	50~60	5.0~6.0	37~45	
2	Hexagon flange bolt M12×1.25×220	50~60	5.0~6.0	37~45	
3	Hexagon flange face lock nut M12×1.25	50~60	5.0~6.0	37~45	
4	Hexagon flange bolt M10×1.25×160	40~50	40~50	30~37	
5	Hexagon flange face lock nut M10×1.25	40~50	40~50	30~37	
6	Hexagon flange bolt M10×1.25×40	40~50	40~50	30~37	
7	Hexagon flange bolt M10×1.25×25	40~50	40~50	30~37	
8	Hexagon flange bolt M10×1.25×20	40~50	40~50	30~37	




Engine disassembly


 Remove the rear body plastic parts such as the rear cargo box. (See related chapters for details)




 Remove the air filter assembly. (See related chapters for details)



 Remove the muffler assembly. (See related chapters for details)




- Remove the upper bracket assembly of the engine.
 (See related chapters for details)
- Safety belt fixing bracket combination. (See related chapters for details)



 Loosen the hoop and remove the CVT air inlet pipe and CVT air outlet pipe. (See related chapters for details)

A CAUTION


After removing the CVT air duct, please effectively protect the air inlet and outlet of the CVT to prevent sundries from falling into the engine, thereby damaging the engine




 Unplug the tubing connector [A] and unplug the negative pressure tube.

A CAUTION

When pulling out the oil pipe joint, please make sure that the oil pump of the whole vehicle has been cut off and use a rag to protect the joint to prevent gasoline spraying




 Remove the gear shift components installed on the engine.(See related chapters for details)




◆ Remove the rear section of the front drive shaft and the rear drive shaft. (See related chapters for details)







 Remove the rear section of the front drive shaft and the rear drive shaft. (See related chapters for details)




◆ Remove the mounting bolts (hexagon flange bolt M12×1.25×85) and nuts (hexagon flange lock nut M12×1.25) of the engine front mounting seat assembly, the engine lower mounting seat assembly and the frame, after removing the engine Install the mounting bolts (hexagonal flange bolts M12×1.25×220) and nuts (hexagonal flange bolts M12×1.25) of the seat assembly and the frame, and remove the engine rear liner [A] at the same time, and remove it from the top Lift out the engine.



◆ Remove the mounting bolts (hexagon flange bolts M10×1.25×40) and nuts (hexagon flange lock nuts M10×1.25) of the engine front mounting seat assembly, and remove the engine front mounting seat assembly.



◆ Remove the mounting bolts (hexagon flange bolts M10×1.25×160) and nuts (hexagon flange lock nuts M10×1.25) of the engine rear mounting seat assembly, and remove the engine rear mounting seat assembly.




- Remove the mounting bolts (hexagonal flange bolts) of the lower bracket assembly of the engine
- ◆ M10×1.25×20), remove the engine lower bracket assembly.
- ◆ To install the engine, follow the reverse procedure.

ELECTRICAL SYSTEM	14-1
EXPLODED VIEW	14-4
TECHNICAL PARAMETERS	14-8
SPECIAL TOOLS	14-9
Multimeter	14-9
BATTERY	14-10
Remove the battery	14-10
Battery installation	14-10
BATTERY CHARGING	14-11
Charging condition check	14-13
Generator inspection	14-14
Circuit diagram of charging system	14-15
Voltage regulating rectifier inspection	14-16
Remove	14-16
LIGHTING SYSTEM CIRCUIT	14-17
HEADLIGHT	14-18
Replace	14-18
TAIL LIGHT	14-19
Replace	14-19
LICENCE LAMP	14-20
Remove	
Replace	14-20
FLASHER	14-21
Power lock	14-22
SWITCH	14-22
Flameout Switch	14-24
Emergency switch	14-24
Start switch	14-25
2WD/4WD Drive mode Switch	14-25
2WD/4WD drive mode switch removal and installation	14-26
STARTING SYSTEM LAYOUT	14-27
SCHEMATIC DIAGRAM OF STARTING SYSTEM	14-28
STARTING SYSTEM TROUBLESHOOTING	14-28
SWITCH POSITION DIAGRAM	14-30
ELECTRICAL WIRING	14-31
Wiring check	14-31
DISASSEMBLY OF POWER LOCK, START BUTTON, VARIOUS SWITCHES, ETC	14-32
FUSE BOX	14-33
Combination fuse box main body segment	14-33
Combination fuse box cover inner part	14-33
Fuse continuity test	14-34

STARTING RELAY	14-36
Disassemble	14-36
Start relay troubleshooting	14-36
START MOTOR	14-37
Disassemble	14-37
installation	14-37
ECU	14-38
Disassemble the ECU	14-38
Install ECU	14-38
ECU connector removal skills	14-38
FUEL PUMP ASSEMBLY	14-39
Disassemble	14-39
Fuel pump assembly inspection	14-40
fuel pump assembly	14-41
TRAILER POWER SOCKET	14-42
Remove trailer power socket	14-42
Install trailer power socket	14-42
EFI SYSTEM	14-43
Schematic diagram of EFI system	14-43
COOLANT TEMPERATURE SENSOR	14-44
Function Description	14-44
working principle	14-44
Performance parameter	14-45
Fault diagnosis	14-45
OXYGEN SENSOR	14-46
Function introduction	14-46
Working principle	14-46
Performance parameter	14-47
Electrical characteristic parameter	14-47
Electrical characteristics	14-48
ELECTRONIC CONTROL UNIT (ECU)	14-49
Function Description	14-49
Electrical characteristics	14-50
Fault diagnosis	14-50
ECU pin definition	14-51
FUEL INJECTOR	14-53
working principle	14-53
Performance parameter	14-54
Fault diagnosis	14-54
IGNITION COILS	
Working principle	14-55
Performance parameters	
Fault diagnosis	
SPARK PLUG	14-57


ENGINE SPEED SENSOR
Fault diagnosis14-58
•
ELECTRONIC THROTTLE VALVE BODY ASSEMBLY14-59
Disassembly requirements14-59
INLET PRESSURE TEMPERATURE SENSOR14-60
Three-in-one sensor performance characteristics14-61
Fault diagnosis14-61
THROTTLE POSITION SENSOR AND THROTTLE ACTUATOR14-62
Throttle Position Sensor Performance Characteristics14-62
Throttle actuator (DC motor) technical performance parameters14-63
Fault diagnosis14-63
ELECTRONIC ACCELERATOR PEDAL14-64
Remove and install the accelerator pedal14-64
Technical performance parameters14-65
Fault diagnosis14-65
Fault code reading14-66
Troubleshooting instrument operation14-66
SUMMARY OF FAILURE CODES14-67
EPS14-72
EPS system wiring schematic diagram14-73
EPS trouble removal14-74
DISPLAY AND HUMAN-COMPUTER INTERACTION ASSEMBLY14-76
Instrumentation14-77
Technical parameters14-81
Meter dismantling14-81
CENTRAL CONTROL DISPLAY14-83
Disassembly and installation of central control14-84
Function introduced14-85
Performance parameter14-86
AM performance index14-86
FM performance index14-87
Fault diagnosis14-87
TBOX14-88
TBox fault code display area14-89
WINCH ASSEBLY14-90
Winch motor position14-92
Removal of winch motor14-92
Install winch motor14-93
SCHEMATIC DIAGRAM OF TRAILER SYSTEM14-95
WIRE COLOUR14-96
Color comparison table14-96
ELECTRIC SCHEMATIC DIAGRAM14-97

EXPLODED VIEW



		Torque				
No.	PART'S NAME	N·m	kgf·m	ft·lb	Remarks	
1	Right headlight		g	10.10		
2	Left headlight					
3	EPS controller					
4	Horn					
5	T-BOX					
6	Flasher					
7	Circular reflector (amber)					
8	uzzer					
9	Central control display					
10	Central control display					
11	Instrument Control Module					
12	Emergency switch					
13	Mode switch					
14	Power off switch					
15	Horn switch					
16	Antenna combination					
17	Start button switch					
18	Power lock					
19	Direction lock					
20	shboard					
21	2WD / 4WD integrated switch					
22	Headlight switch					
23	ner switch					
24	gnal switch					
25	Far and near light switch					
26	Gas pedal assembly					
27	Oil pump assembly					
28	USB power output holder					
29	Battery 32Ah					
30	Oxygen Sensor					
31	Terminal assembly					
32	Start relay					
33	ECU					
34	Voltage adjustment regulator					
35	aillight					
36	Circular reflector (red)					
37	Trailer power socket					
38	rear license Lamp					
39	Left taillight					
40	Hexagon flange bolt M8×16					
41	Hexagon flange bolt M6×12					
42	Cross groove disc head screw M5×16					
43	Cross groove disc head screw M6×14					
44	Large pan head hexagon socket bolt M6×16					
45	Cross recessed pan head tapping screws ST4.2×16					
46	Cross recessed round head tapping screws ST4.2×13					
47	Intercom switch					

No.	PART'S NAME		Torque	Damanda	
		N·m	kgf∙m	ft∙lb	Remarks
48	Hexagon flange bolt M6×20				
49	Hexagon socket head screw M8×25				
50	Hexagon flange bolt M6×35				
51	Hexagon flange bolt M5×16				
52	Rear fog lamp				
53	Cross recessed pan head screw M5×30				





No.	PART'S NAME		Torque	Damandra	
NO.	PART 5 NAME	N·m	kgf∙m	ft∙lb	Remarks
1	Winch power cord				
2	Winch relay				
3	Winch motor wire				
4	Winch hook				
5	Winch strap				
6	Winch guide wheel				
7	Winch motor				
8	Main cable				
9	Winch switch socket				
10	Winch wireless control module (including				
10	wireless switch)				
11	Winch switch				
12	Starter motor positive and negative wire				
13	Battery positive and negative wire				
14	Battery positive and negative wire				
15	Hexagon flange bolt M6×25				

TECHNICAL PARAMETERS

Project	Standard	Use limit
Battery:		
Туре	Sealed Battery	
Capacity	12 V 32 Ah	
Charging System:		
Alternator type Charging voltage	Three-phase AC 14 \sim 15 V	
(Regulator/rectifier output voltage) Alternator		
output voltage	$36\sim54$ V 3 000 r/min (rpm)	
Stator coil resistance	0.33 ~ 0.49	
Ignition System:		
Spark plug:		
Spark plug gap	0.7~0.9 mm	
Spark plug cap resistance	3~12kΩ	
Ignition coil:		
Primary winding resistance	466~593mΩ	
Secondary winding resistance	8.2~10.5kΩ	
Electric Starter System:		
Starter motor:		
Commutator diameter	28mm	
Brush length	11.5mm	
Fuel Pump:	330±20KPa	
Fuel pump pressure	JOUTSONLA	
Switch:		
Brake light switch timing of pedal travel	ON after 10 mm (0.4 in.) of pedal travel	
Rising temperature	From OFF to ON at 93°C	
	From ON to OFF at 88.5°C	


SPECIAL TOOLS





▲ CAUTION

- ◆ When the multimeter is measuring voltage, the meter pen should not be inserted into the current measuring hole
- ♦ When measuring resistance, please be sure to disconnect the battery positive pole.





BATTERY

Remove the battery

[A] Positive pole

【B】Negative pole

- ◆ Turn off the ignition switch.
- Remove seat (see the Frame Section)
- Loosen the bolt of the battery seat.
- Remove battery fixing tape.
- ◆ Disconnect the battery negative (-) cable first, and then disconnect the positive (+) cable.
- Take out the battery.

Battery installation

- ◆ Turn off the ignition switch.
- Put the battery with the battery box and fixer in place.
- ◆ Connect the positive cable first, and then connect the negative cable.
- ◆ Apply a thin layer of grease to the terminal to prevent corrosion.
- ◆ Tighten battery seat bolts.

Match the model type of the battery. The name should be the same.

Battery type Name: GHD32HL-BS

▲ CAUTION

This battery is a colloidal battery and does not need to add electrolyte.

BATTERY CHARGING

In the case shown in the following table, to start the vehicle fully to start the engine, and it should be charged before use. However, if the battery voltage is higher than 12.6V after 10 minutes of charging, no initial charge is required.

The conditions under which an initial charge is required	charging method
At low temperatures (below 0°C)	1.4 A x 2 _ 3 Hours
Batteries have been stored at high temperatures and in high humidity	
The seal has been removed or cracked - flaked, torn or torn	1.4 A x 15 _ 20 Hours
The battery life is more than 2 years after manufacture	

NOTE: Terminal voltage - To measure the terminal voltage of the battery, use a digital voltmeter. When measuring the terminal voltage after charging, the battery should stand still for more than 20 minutes.

Preventive measures:

- 1) Colloidal battery, no liquid filling is required
- ◆ Before normal use, there is no need to replenish the battery as long as it is not exhausted. It is very dangerous to pry open the sealing plug and add water. Never do that.

2) Recharge

- ◆ If the engine fails to start, the horn becomes weaker or the indicator light goes dark, it shows the battery is exhausted.
- ◆ Charge the battery for 5 to 10 hours according to the charging current as shown in the specification.
- ◆ When it is inevitable to need quick charging, please charge in strict accordance with the maximum charging current and the time conditions indicated on the battery.

▲ WARNING

The battery is designed to withstand no abnormal damage if it is recharged as specified above. However, if charged under conditions other than those described above, the performance of the battery may degrade significantly. Do not remove the seal cover during recharging. If excess gas is generated due to overcharging, a safety valve ensures battery safety.

3) When you don't use the vehicle for months

- ◆ Before storing the vehicle, please charge it and store it before removing the negative wire.
- Fully charged once a month during storage.

4) Battery life time

◆ If the battery fails to start the engine after several charges, it indicates that the battery has exceeded its service life. Please replace it. (But only if the vehicle itself has no problem starting the system.)

▲ WARNING

During charging, keep the battery away from sparks and naked fire. An explosive gas mixture that releases hydrogen and oxygen. When using a battery charger, connect the battery to the charger before turning on the charger. This process prevents the battery terminals from generating sparks that could ignite any combustible gas. Do not put the fire near the battery and do not loosen the terminal. Electrolytes contain sulfuric acid. Be careful and do not let it come into contact with your skin or eyes. If touched, rinse with plenty of water. If serious, seek medical attention immediately.

Swap places

- ◆ The sealed battery can give full play to its performance only when used in conjunction with appropriate vehicle electrical equipment.
- ◆ Therefore, the sealed battery can only be replaced on the vehicle originally equipped with the tool.
- ◆ If sealed batteries are installed on vehicles with ordinary batteries, please take care of the equipment, the life of sealed batteries will be shortened.

Charging condition check

Battery charging status can be measured to check the battery terminal voltage.

◆ Remove the battery (refer to the section on Removing the battery).

▲ WARNING

Measure the battery terminal voltage.

A CAUTION

The voltage to one decimal point is measured with a readable digital voltmeter 【A】.

If the reading is below the rated value, it needs to be recharged.

Battery terminal voltage standard: 12.6V or higher

- Remove the battery (refer to the Removal of batteries section)
- ◆ Recharge the battery in the following way.

WARNING

The battery is sealed. Do not open it. Do not add water when charging.

The charging current and time are described below.

Terminal voltage: 11.5 _ Less than 12.5 V Standard charge: 3.2 amps x 5 _ 10 hours

(see attached table)

Quick charge: 32 A x 1.0 hours

⚠ WARNING


If possible, do not charge quickly. If there is an inevitable situation that requires a quick charge, pay attention to the ambient temperature.

Test against the standard voltage later.

Terminal voltage: less than 11.5V Charging method: 3.2 A x 20 hours

Generator inspection

There are three types of alternator faults: short circuit, disconnection, or rotor magnetic loss. Short-circuiting one of the coils or disconnecting the wire will result in low output or no output at all. A loss of the magnetic field of the rotor may be caused by a drop or by placing the AC generator near the electromagnetic field, thereby hitting the magnetic field of the AC generator or simply due to aging, resulting in low output. To check the output voltage of the alternator, perform the following procedures.



Remove rear fender (see Chapter "Frames")

Disconnect the alternator connector **[A]** (1, 2, 3 in the connector are magneto three-phase outgoing lines)

Connect the handheld tester as shown in the following table

Start the engine. Run it at the speed shown in the table. Note the voltage reading (three measurements in total). Ac generator output voltage

Dan na taotan	Tester connection		Reading
Range tester	(+)	(-)	@3000 rpm
250 V AC	One Yellow wire	Another Yellow wire	36~54 V

If the output voltage is within the value in the table, the alternator is operating normally and the regulator/rectifier has been damaged. A much lower reading indicates that the AC generator is defective. Check the stator coil resistance as follows:

Stop the engine

Disconnect the AC generator connector

Connect the handheld tester as shown in the table below.

Pay attention to the readings (3 measurements in total).

Stator coil resistance


Range tester	Tester connection		Reading @3000 rpm
Kange tester	(+)	(-)	rteading @3000 rpm
×1 Ω	One Yellow wire	Another Yellow wire	0.30 _ 0.49Ω

One yellow wire and the other yellow wire if the resistance is greater than that shown in the table, or show nothing. Read the (infinity) of any two wires, the stator has an open circuit and must be replaced. Less resistance means that the stator is short-circuited and must be replaced.

Using a handheld tester, measure the resistance between each yellow lead with the engine. Any reading less than infinity must be replaced.

If the stator coil has normal resistance, but the voltage check shows that the AC generator is faulty then the rotor magnetism may have weakened and the rotor must be replaced.

Circuit diagram of charging system




- Alternator
 Main Fuse
- 2. regulator/rectifier
- 5. Ignition lock
- 3. Battery
- 6. Load

Voltage regulating rectifier inspection

Test and Judgment Method of Charging Voltage on Whole Vehicle

Test conditions and methods	Output voltage
Connect the product according to the normal loading state, after the vehicle started, the speed will remain above 2000rpm Connect a fully charged battery Use a multimeter to test the voltage at the output terminal of the regulator	Output voltage:14.0-15.0V Qualified otherwise unqualified



Remove


- ◆ Connector 【A】 (Disconnect)
- ◆ Bolt 【B】 and Voltage regulating rectifier 【C】

See the table below for the determination method of the voltage regulating rectifier resistance:


Output resistance characteristics (unit Ω)

Output resistance characteristics (unit Ω)						
	Output +	Y1	Y2	Y3	Output-	Digital multimeter (Diode gear)
Output+		_∞	_∞	_∞	_∞	Connect the red pen to output +, and the black test pen to measure the remaining terminals
Y1	0.12-0.25		®	∞	∞	Connect the red pen to Y1, and the black test pen to measure the remaining terminals
Y2	0.12-0.25	∞		8	_∞	Connect the red pen to Y2, and the black test pen to measure the remaining terminals
Y3	0.12-0.25	_∞	_∞		8	Connect the red pen to Y3, and the black test pen to measure the remaining terminals
Output-	0.5-0.7	0.4-0.6	0.4-0.6	0.4-0.6		Connect the red pen to output -, and the black test pen to measure the remaining terminals

LIGHTING SYSTEM CIRCUIT




Battery Main Fuse Lgnition lock Fuse Main relay High beam relay Daytime running light relay Low beam relay Daytime running light High/Low beam Position lights Lights switch turn switch Warning switch Flash CM turn sLights



HEADLIGHT

Headlamp rear guard (see "Frame" chapter)


- [A] Mounting bolt
- 【B】Headlamp rear guard
- [C] Headlamps
- 【D】Headlamp bolts*4
- **[E]** High-Low beam adjustment bolt



Replace

A CAUTION

- ◆ The lamps are LED lamps
- ◆ The far and near light of the LED headlights are damaged, only the headlights can be replaced
- ◆ If other light sources are damaged, only the headlights can be replaced.
- ◆ Remove the 4 bolts on the rear guard of the headlight 【A】
- ◆ Remove headlight rear cover 【B】 and front cover,side shield (refer to disassembly and assembly of plastic parts)
- ◆ Remove 4 headlamp bolts 【D】 with tools, disconnected the headlamp connector 【C】, take down the headlamp
- ◆ After replacement, adjust the far and near beam adjustment bolt 【E】 to adjust the headlight beam to the right position.



TAIL LIGHT

Rear guard for taillight (see the "Frame" chapter


- 【A】 Taillight guard bolt*4
- 【B】 Tail light shield
- 【C】Tail light lamp body
- 【D】Tail light bolt*5

Replace


▲ CAUTION

The lamps are LED lamps

The LED tail light source is damaged, only the tail light can be replaced.



- ◆ Remove the bolts of the tail lamp guard *4【A】
- ◆ Take off the tail light shield 【B】, and refer to the installation of plastic parts for the removal method.
- ◆ Remove the two tail lamp mounting bolts on the side and front cover*4 【D】, and remove the tail lamp body 【B】 after unplugging the tail lamp connector



LICENCE LAMP

- [A] Licence Lamp Bolt*2
- 【B】Licence Lamp

Remove

- ◆ Remove the licence lamp bolt 【A】
- ◆ Remove Licence Lamp 【B】
- ◆ Remove licence lamp wire harness

Replace

- ◆ Place the I icence lamp in the licence lamp
- installation position
- ◆ Tighten the licence lamp bolt*2【A】

FLASHER

Remove front cover (see the "Frame" chapter)

[A] Install rubber sleeve

【B】Flasher

Disassembly


Remove the installation rubber sleeve [A] from the installation bracket


Remove the wiring harness connector


Replace the flasher [B]




- ◆ If the turn signal does not flash or flashes abnormally on the whole vehicle (the normal turn signal flash frequency is 85/min)
- ◆ The lamp is out of light (one-side forward or backward turn light is damaged), and the turn signal flashes at a frequency of 120/min)









SWITCH

Power lock

A CAUTION

When the indicator does not display after the key is turned on, check the circuit failure, and replace the power lock after confirming that the power lock is broken

→ Check Power lock

After unplugging the connector, turn the multimeter to the conduction position. When the key is turned to the OFF position, the two wires should not be able to conduct when the key is turned to the ON position, the two wires should be able to conduct

When you need to replace the power lock, first remove the seat cushion and fuel tank guard (see "vehicle body and frame") .

[A] Ignition lock cover

【B】Ignition lock

[C] Connector

- ◆ After removing the plastic parts, rotate the ignition lock cap counterclockwise 【A】.
- ◆ Remove connector 【C】, Replace ignition lock.

TIP

When in normal condition, ON is directly above, clockwise rotation of 60 degrees is OFF

At ON, the vehicle circuit connected, the key can not be pulled out

At OFF, the vehicle circuit is disconnected and the key can be removed




▲ CAUTION


The switch is valid only when the ignition lock is in the ON position

- [A] Headlight
- 【B】Position Light
- [C] High Beam
- [D] Low beam
- [E] Left turn signal
- [F] Right turn signal
- 【G】Hazard warning lights
- 【H】Horn
- 【J】"S" mode
- 【K】"E" mode

▲ CAUTION

Since the switch is an integral part, any damage to the switch requires replacement of the entire switch







Flameout Switch

When the engine is running, press the stop switch button to stop the engine

When the engine is stopped, first press the stop switch button and then press the start button to start the engine; When the function fails, check the related circuit first When there is no problem in the inspection circuit, test the internal circuit of the flameout switch;


▲ CAUTION

Only when the fl ameout switch is in working condition, the engine can be started by pressing the start button

Test whether the flameout switch is damaged

When the flameout switch is pressed, red, gray and yellow should be able to conduct, and black and gray and black should be able to conduct, and when the start button is pressed at this time

When the flameout switch is pressed, red, gray and yellow black, gray and black can not be conducted




Emergency switch

When the emergency switch is pressed, the four front and rear turn signals fl ash at the same time When the emergency switch is pressed, if a single turn signal does not light up, the relevant insurance or the lamp itself should be checked.

Test whether the emergency switch is damaged

When the emergency switch is pressed, if the four front and rear turn signals do not flash, the internal circuit of the emergency switch should be tested When the emergency switch is not pressed, there should be no conduction in orange, gray, and light blue;

When the emergency switch is pressed, the orange, gray, and light blue should be able to conduct at the same time



Start switch

When the flameout switch is turned on, press the start switch button and the engine starts to run


When the function fails, check the related circuit first
When there is no problem in the inspection circuit, test
the internal circuit of the start switch

▲ CAUTION

Only when the flameout switch is in working condition, the engine can be started by pressing the start button



When the start switch is pressed, the blue, red and yellow should be able to conduct, and when the start button is pressed at this time, the engine can be started under normal conditions of other functions



2WD/4WD Drive mode Switch

▲ CAUTION

The switch is valid only when the power lock is in the ON position

[A] 2WD/4WD Drive mode Switch

[B] 4WD/4WD Lock Drive mode switch


→ Test whether the 2WD/4WD switch is damaged


When the shift lever is shifted to the left,

and the 2WD switch is not pressed, the switch is in the 2WD state, at this time the blue-green and gray-white, blue-black conduction

After pressing the two-four-wheel drive switch, the switch is in the four-wheel drive state. At this time, blue-green and blue-black, brown-red and brown green can be turned on;

When the lever is shifted to the right, after the four wheel drive lock switch is popped up, the brown-red and brown-green, gray and gray-white, light green brown and green, respectively, can be turned on.






2WD/4WD drive mode switch removal and installation

[A] Fixing bolts

【B】2WD/4WD Drive mode switch

- ◆ Remove the three fi xing bolts with tools.
- Remove the switch from the plastic part.
- When installing a new switch, tighten the three fixing bolts with a tool

STARTING SYSTEM LAYOUT



[A] Power lock

【B】Instrument

[C] Flameout switch

[D] ECU

[E] Oil pump

[F] Start button

【G】Start relay


[H] Fuse box

【K】32Ah battery


Description of engine starting process:

- 1. Turn on the power lock 【A】, power on the whole vehicle, and check whether the upper gear of the instrument 【B】 is in the N gear;
- 2. Turn on the flameout switch 【C】. After ECU 【D】 judges that it is powered on, it outputs a signal to the oil pump relay, and the oil pump relay coil is closed;
- 3. After the oil pump relay works, the current is output to the oil pump 【E】, the oil pump starts to work, and the oil pipe is filled with gasoline;4. Press and hold the start button 【F】 for a period of time, the auxiliary start relay will close;
- 5. After the auxiliary starting relay works, output the starting signal to the starting relay 【G】;
- 6. After the starter relay works, the starter motor starts to work;
- 7. After the starter motor works, drive the engine to work through the gear, and the engine starts to start at this time;

SCHEMATIC DIAGRAM OF STARTING SYSTEM



STARTING SYSTEM TROUBLESHOOTING



If the engine cannot be started by pressing the start button, first check whether the flameout switch is turned on, and the engine cannot be started when the flameout switch is off

NOTICE


When the flameout switch is off, the engine cannot be started



 Secondly, check whether the gear display on the instrument is in N gear. The starting strategy is to start the engine only in N gear;

NOTICE

Before starting the engine, first make sure that the gear is in the N gear.




Normal Broken

 If all the above are normal, please confirm whether the oil pump fuse is damaged. If the oil pump fuse is damaged, the engine cannot be started;



◆ Confirm whether the voltage of the 32Ah battery is greater than 12.6V. Generally, the engine cannot be started when the voltage is lower than 12.6V;

SWITCH POSITION DIAGRAM





- [A] lighting switch
- [C] Turn signal switch
- [E] 2WD/4WD switch
- 【G】Power lock
- 【J】 Mode switch
- [M] thrust augmentation switch
- 【B】 hight and low beam switch
- **[D]** Emergency switch
- [F] Start button
- 【H】Horn switch
- [K] Flameout switch

ELECTRICAL WIRING


Wiring check

- Visually inspect the wiring for signs of ablation, wear, etc.
- ◆ Remove each connector 【A】 and check for corrosion, dirt and damage.
- ◆ Remove each connector 【A】 and check for corrosion, dirt and damage.


Check the continuity of the wire

- Refer to the electrical schematic diagram to find the wire end suspected to be problematic.
- ◆ Connect the manual tester (multimeter) to both ends of the wire.
- ◆ Set the manual tester (multimeter) to the on-off gear.

If the reading of the manual tester (multimeter) is not 0 or the buzzer does not work, the wire is defective if necessary, replace the wire or the main harness 【B】.



DISASSEMBLY OF POWER LOCK, START BUTTON, VARIOUS SWITCHES, ETC



[A] Power lock

[C] Power lock cover

[E] Lock cover

【G】Limit card

【B】Gasket

[D] Start button


[F] Secondary lock cover

- 1. When removing the power lock, hold the power lock 【A】 from the inside of the instrument panel, and turn the power lock cover 【C】 counterclockwise with the other hand, and the power lock can be removed after unscrewing;
- 2. When disassembling the start button, turn the secondary lock cover **[F]** counterclockwise from the inside of the instrument panel, and the start button can be removed after unscrewing;
- 3. When disassembling the switch, use a suitable tool to pry the limit card 【G】 from above or below to remove the switch;

NOTICE


Before disassembling the power lock, start button, various switches, etc., at least the plastic parts such as the left lower cover of the instrument panel must be disassembled. For details, please refer to the disassembly steps of plastic parts.

FUSE BOX



Combination fuse box main body segment

- 【A】Combination fuse box body
- 【B】Relay (four-way)
- 【C】 Medium fuse
- [D] Micro fuse
- [E] Fuse




Combination fuse box cover inner part

- **[F]** Combination fuse box cover
- **[G]** Special tool for fuse removal
- 【H】Spare fuse

NOTICE


The fuse specification and label function position are subject to the actual product.




- After turn on the power lock, if the dashboard does not display, please confirm whether the fuse is damaged;
- ◆ The fuse box is under the dashboard, first open the electrical repair cover 【A】
- Press the fuse box cover lock 【B】 and remove the fuse box cover
- Use a multimeter to test whether the fuse is on

Fuse continuity test

- Before testing, disconnect the battery power supply
- ◆ Place the multimeter in the on position
- Put the red and black test leads of the multimeter to the two ends of the fuse respectively
- If it can be turned on, it means that the fuse is normal, and if it can't be turned on, it means that the fuse is damaged




Place the red and black test leads of the multimeter at both ends



NOTICE

Before testing the fuse, disconnect the battery power supply.




No.	Fuse/Relay	Туре	No.	Fuse/Relay	Туре
F1	12V,USB,Trailer	15A	R1	Remote power-on relay	12V 20A
F2	LAMP	15A	R2	IG1 relay	12V 20A
F3	Brake,Trailer,Speed,EPS	10A	R3	Auxiliary start relay	12V 20A
F4	2-4WD	15A	R4	Main relay	12V 20A
F5	Flameout	7.5A	R5	High light relay	12V 20A
F6	TBOX,IVI	7.5A	R6	Low light relay	12V 20A
F7	Winch	10A	R7	Day light relay	12V 20A
F8	ICU,LOCK,OBD,Buzzer	10A	R8	Fuel pump relay	12V 20A
F9	FUEL PUMP	10A	R9	FAN relay	12V 20A
F10	MAIN FUSE	50A	R10	2-4 Wheel drive relay	12V 20A
F11	TBOX,IVI,ICU	7.5A	R11	4 Wheel drive lock relay	12V 20A
F12	IGNITION COIL,INJECTOR	15A			
F13	EVAP	15A			
F14	EPS	40A			
F15	ECU	7.5A			
F16	High/Low LAMP	15A			
F17	FAN	20A			

NOTICE

All functional positions and specifications of the fuse lamp are subject to the actual product.

STARTING RELAY





Disassemble

- 1. Remove the harness plug 【A】
- 2. Open the **[B]** and **[C]** end rubber sleeves respectively
- 3. Remove the wires at the 【B】 and 【C】 ends respectively
- 4. Remove the bolts **[D]** separately;

installation

- ◆ Installation bolt 【D】
- ◆ Install the starter motor cable 【C】
- Install the battery cable 【B】
- ◆ Plug in the harness plug【A】





NOTICE


Before removing and installing the starting relay, disconnect the battery wiring


Start relay troubleshooting


- 1. Pull out the plugs at end A and test the two plugs with a multimeter. One end should be grounded. When the start button is pressed, the other end should be equal to the battery voltage. If there is no voltage, check the wiring problem first
- 2. If the test is normal, plug in the A plug, and then use a multimeter to test the B terminal voltage, one end is equal to the battery voltage, when the start button is pressed, the other end should also be equal to the battery voltage, otherwise please replace the starter relay

When the starting relay needs to be replaced, use a special tool to remove the two hexagonal flange bolts $M6\times12$ [C]

START MOTOR







Disassemble


- ◆ The starter motor 【A】 is installed on the engine 【B】, and the disassembly method is detailed in the engine chapter;
- Remove the CVT 【E】, see the engine chapter;;
- Remove the positive and negative wires of the starter motor [C];
- Remove the [F];
- ◆ Remove the motor 【A】 along the axis of the motor; [A]
- When disassembling the motor, pay attention that the O-ring 【H】 should not be damaged;

installation

Apply a small amount of lubricating oil to the O-ring of the starter motor, then install the starter motor into the crankcase along the axial direction, and fix it with two bolts [F].

The positive connector of the starter motor is installed on the starter motor, and the negative connector is installed on the engine base 【G】;


Connect the battery.



⚠ WARNING


Make sure to disconnect the battery negative (-) cable then disconnecting the battery positive (+) cable

ECU



Disassemble the ECU


- ◆ The ECU is installed on the right rear side of the vehicle, first remove the right rear mudguard 【B】, see the plastic parts chapter for details;
- Disconnect the battery wiring;
- ◆ Loosen the ECU connector lock buckle, and unplug the EFI auxiliary cable connector 【D】 and the main cable connector 【E】 on the ECU;
- ◆ Loosen the four fixing bolts 【C】 that fix the ECU on the frame.




Install ECU

- ◆ Fix four bolts and install ECU;;
- Connect the ECU with the main cable and the EFI auxiliary cable connector, and lock the buckle;
- ◆ Install the right rear mudguard 【B】;
- Connect the battery wiring;

ECU connector removal skills




- ◆ Move 【G】 in the direction of the arrow;
- ◆ Remove the plug-in of the EFI auxiliary cable to the ECU 【D】;
- ◆ Push the lock 【H】:
- ◆ Move 【J】 in the direction of the arrow;
- ◆ Remove the plug-in connecting the main cable to the ECU 【E】;




NOTICE

When removing the ECU connector, first remove 【D】, then 【E】; when installing, install 【E】 first, then 【D】

FUEL PUMP ASSEMBLY





Disassemble


- ◆ This model has two fuel tanks, the main fuel tank 【D】 and the auxiliary fuel tank 【E】. The fuel pump is pre-installed on the main fuel tank in advance and is located under the passenger seat;
- ◆ Use the special tool 【F】 to remove the fuel pump installation screw cap 【B】 counterclockwise;;
- ◆ Mark the direction of the fuel pump on the fuel tank, and remove the fuel pump 【A】
- ◆ Keep the fuel pump sealing ring 【C】 to prevent loss;
- See the fuel system chapter for details;


A CAUTION

After removing the fuel pump, please protect the fuel tank port effectively to prevent debris from falling into the fuel tank and damage the fuel pump.

WARNING

- Whenever the gasoline pipeline is removed, the battery must be disconnected to prevent the fuel pump from starting accidentally.
- ◆ Whenever any maintenance or inspection of the fuel system is carried out, fuel leakage may occur. There must be no welding, smoke, open flames,
- etc. in this area.





Fuel pump assembly inspection

- Structural drawing of the front view of the fuel pump assembly 【J】.
- ◆ Definition diagram of pin function of fuel pump electrical connector 【Ⅰ】.
- Remove the driver's seat assembly and the lower cover of the driver's seat then use a multimeter set to the resistance ohm position to check the fuel level sensor of the fuel pump according to the following steps.
- Move the floating rod to check if it can move freely. The float assembly should be able to return to a lower position freely. If not, please replace the fuel pump.
- Connect the multimeter to the middle two pins of the cable plug 【D】 to test the fuel position sensor. The multimeter displays $235\pm5\Omega$ on the full fuel position 【H】, and $40\pm2\Omega$ on the empty fuel position 【L】.


Lowest point (Logist)	Height (mm)	41±4
Lowest point (L point)	Resistance (Ω)	40±2
Highest point (H point)	Height (mm)	186±5
Highest point (H point)	Resistance (Ω)	235±5

◆ Use the pressure gauge **[F]** to test the pressure of the fuel pump supply port, and the test pressure value is 330±17Kpa under the power-on state.

Туре	Test pressure(Kpa)	Flow (L/h)	Electric current(A)	Sealing pressure(Kpa)
W380224A- JK	300	110- 140	5.5	550-850
A882CHT	300	≥100	≤5.8	330±5%

▲ CAUTION

- If the resistance reading shows unstable, please clean the resistance wiper with alcohol and retest.
 If it is still incorrect, please replace the fuel pump.
- ◆ If the fuel pump supply pressure test does not meet the requirements, please replace the fuel pump.



▲ CAUTION

During the process of disassembling any part of the fuel system, fuel leakage may occur. Wipe off the residual fuel with a cloth.

fuel pump assembly

【B】Fuel pump installation screw cap


- ◆ Confirm that the sealing ring 【C】 is installed on the fuel tank port;
- ◆ Confirm the orientation of the fuel pump and install it on the fuel tank;
- ◆ Tighten the fuel pump installation screw cap clockwise 【B】.

Fuel pump installation screw cap


▲ CAUTION

When disassembling the fuel pump, be sure to turn off the vehicle and leave it for more than 30 minutes to ensure that the pressure of the high-pressure fuel pipe is released to avoid danger

TRAILER POWER SOCKET



◆ The trailer power supply 【A】 is located at the rear of the vehicle, on the trailer power supply mounting bracket assembly 【B】.



Remove trailer power socket


- Use a screwdriver to loosen the 3 screws that fix the trailer's power socket 【A】;
- ◆ Unplug the connector between the trailer power socket and the main cable 【B】
- ◆ Take out the trailer power socket 【C】.

Install trailer power socket


- First pass the lead connector of the trailer power socket through the middle hole of the trailer power supply mounting bracket assembly.;
- ◆ Then connect the plastic connector with the main cable.;
- ◆ Use a screwdriver to fi x the trailer power socket on the trailer power supply mounting bracket assembly with 3 screws.

EFI SYSTEM

Schematic diagram of EFI system








Function Description

The coolant temperature sensor function is used to monitor the temperature of the engine coolant, on the one hand, the output signal enables the electronic system to make a judgment on the working condition of the engineon the other hand, the output signal to the instrument allows the operator to directly judge the working state of the engine by visual inspection.

The temperature sensor is generally installed on the intake side of the engine block, and the cylinder temperature sensor can be seen after disassembling the cargo box (see A in the figure below).



working principle

The NTC thermistor is packaged in the temperature sensor, and its resistance value changes with the change of the ambient temperature, so that the small change in the external temperature can be accurately and timely measured. Measuring its output resistance can reflect the temperature of the contacting medium. Among them, the A and C terminals output signals to the electronic control unit ECU, and the B terminal is suspended. The pin definition is shown in the figure below.

[A] Connect the positive signal

[B] Hanging

【C】Connect to the negative pole of the signal

Performance parameter

◆ Power: 0.25W under standard use conditions

♦ Working temperature: -30°C~+130°C

♦ Vibration level: ≤600m/s2

lacktriangle Insulation resistance: DC voltage of 500V is applied between the A and C end circuits and the B end circuit, and the insulation resistance is greater than 10MΩ.

♦ Resistance-temperature characteristics are shown in Table 1


Table 1 Temperature sensor resistance-temperature characteristics

Temperature range (°C)	A and C end resistances (KΩ)
-20±0.1	13.71~16.49
25±0.1	1.825~2.155
80±0.1	0.303~0.326
110±0.1	0.1383~0.1451
	B end resistances (Ω)
50±0.2	176~280
80±0.2	63.4~81.4
110±0.2	24.6~30.6

Fault diagnosis

When the cylinder temperature is greater than its credible upper limit or less than its credible lower limit, the fault flag is set, and the common fault codes are shown in the fault summary table. Cylinder temperature sensor failure check:


- ◆ First check whether the sensor harness connector is well connected
- ◆ Unplug the connector, check whether the sensor and the wire harness end pins are bent or deformed, etc.
- ◆ Use M19mm open-end wrench to remove the sensor and check whether the sensor probe is deformed
- ◆ Check the resistance between pins 【A】 and 【C】
- ◆ Connect the connector and check the voltage between pins 【A】 and 【C】



OXYGEN SENSOR

Function introduction

It is used in the feedback system of the electronic control fuel injection device to achieve closed-loop control and improve the control accuracy of the air-fuel ratio of the electronic control unit. It is installed on the exhaust pipe (see [A] in the figure below) close to the engine end. It determines whether the gasoline is completely burned by measuring the oxygen content in the exhaust gas to ensure that the three-way catalytic converter has the maximum of HC, CO and NOx in the exhaust gas.



Working principle


This is achieved by converting the difference in oxygen concentration inside and outside the sensing ceramic tube into a voltage signal output. When the temperature of the ceramic tube of the sensor reaches 350°C, the ceramic solid electrolyte has conductive properties. The oxygen molecules on both sides of the ceramic are catalyzed into oxygen ions by the platinum electrode of the sensor, and the oxygen ions can move inside the ceramic, therefore, the oxygen on both sides of the ceramic can diffuse through the ceramic itself.

It is this feature that converts the difference in oxygen concentration between the inner and outer sides of the ceramic into a potential difference, thereby forming an electrical signal output. If the mixed gas is thicker and the oxygen concentration in the exhaust gas produced by combustion is low, the oxygen ion concentration difference between the inside and outside of the ceramic tube is higher, the potential difference is higher, a large amount of oxygen ions move from the inside to the outside, and the output voltage is higher (about 800mv --1000mv) if the mixed gas is lean and the oxygen concentration in the exhaust gas produced by combustion is high, the difference in oxygen ion concentration between the inside and outside of the ceramic tube is low, the potential difference is low, the output voltage is low

sudden change occurs near the theoretical equivalent air-fuel ratio $% \left(1\right) =\left(1\right) \left(1\right) +\left(1\right) \left(1\right) \left(1\right) +\left(1\right) \left(1\right) \left(1\right) \left(1\right) +\left(1\right) \left(1\right) \left($

The oxygen sensor electrical connector has 4 pins:

- [A] connect to the negative signal of the signal (gray)
- [B] connect to the positive pole of the heating power supply (white)
- [C] connect to the positive signal of the signal (black)
- [D] connect to the negative pole of the heating power supply (white)



Performance parameter

Item	New o	oxygen	500h Durable after oxygen		
Exhaust temperature	350°C	850°C	350°C	850°C	
λ = 0.97 when the sensor element voltage(mv)	840±70	710±70	840±80	710±70	
λ = 1.10 when the sensor element voltage(mv)	20±50	55±30	20±50	40±40	
Internal resistance of sensing element (kΩ)	≤1.0	≤0.1	≤1.5	≤0.3	
Response time (ms) (600mv-300mv)	≤150	≤150	≤300	≤200	
Response time (ms) (300mv-600mv)	≤150	≤150	≤300	≤200	

Electrical characteristic parameter

Item			Unit
Edge resistance	Ambient temperature, heating element break resistance		МΩ
sensor heating	Exhaust temperature 350°C	≥30	МΩ
sensor connector	Exhaust temperature 850°C	≥30	ΚΩ
	Rated voltage	12	V
	Continuous working voltage		V
Power supply voltage on plug	Working voltage that can maintain 1% of total life at most (exhaust temperature ≤850°C)	15	V
	Up to 75s working voltage can be maintained (exhaust temperature≤350°C)	24	V
	Test voltage	13	V
Working voltage is 13V, heating power when reaching thermal equilibrium (exhaust temperature 350°C, exhaust flow velocity is about 0.7m/s)		12	W
Working voltage is 13V, heating current when ambient temperature is -40°C (exhaust temperature is 350°C, exhaust flow velocity is about 0.7m/s)			Α
Fuse of heating circuit			Α

Electrical characteristics

The electronic control unit ECU monitors various sensors, actuators, and power amplifier circuits and detection circuits. When the oxygen sensor fails, the system performs open-loop control, and the corresponding fuel consumption will increase. Common fault codes are shown in the fault summary table.

A CAUTION


When checking the oxygen sensor signal failure, the engine should be operated for at least 5-10min to ensure that the oxygen sensor heating is completed.

Oxygen sensor failure check:

- ◆ Check whether the oxygen sensor connector is well connected.
- Unplug the connector, check whether the sensor and the wire harness end pins are bent or deformed, etc.
- ◆ Check whether the resistance between pins B and D is normal.
- ◆ Check whether the voltage between pin B and the main relay is normal.
- ◆ Connect the connector and run the engine for a period of time, check whether the voltage between pins A and C is normal.
- ◆ Use an M22mm open-end wrench to remove the sensor, and check whether the sensor probe is deformed or damaged.

In addition, the oxygen sensor is an indirect reflection sensor. If other sensors are faulty, the oxygen sensor will also report a fault:

- ◆ The battery voltage is not credible.
- ◆ The absolute pressure signal of the intake manifold is unreliable.
- The signal of the engine temperature sensor is unreliable.



▲ WARNING

When disassembling the oxygen sensor, be careful of the muffler and engine, and be careful of burns!

ELECTRONIC CONTROL UNIT (ECU)

Function Description

The engine electronic control unit (ECU for short), as a key component of the engine control management system, is used to detect and control the normal operation of the engine system.load information is collected through sensors to predict the driver's driving intention and at the same time ensure the best fuel economy to meet the emission standards required by regulations. The engine management system is equipped with sensors and actuators necessary for ECU work, the ECU calculates the required air-fuel mixture ratio and the ignition advance angle of the engine according to the input data of the sensor, and according to the measured data and the working status of other accessory systems, it controls the fuel supply, fuel injection timing, high-pressure ignition timing, ignition closing angle, closed-loop control of engine idling speed, etc. under various operating conditions.

The ECU is installed under the seat cushion (see A in the figure below) and is fixed to the frame by 4 M8 bolts B (see B in the figure below), with the ECU socket facing downwards.



A CAUTION

The ECU socket faces downwards to prevent water and dust.

Electrical characteristics

Working voltage:

◆ Rated voltage: 13.5V

◆ Full-function working voltage range: 9 V ~16 V

♦ Function limited voltage range: 6 V~9 V, 16 V~18 V

♦ Guaranteed diagnostic function voltage range: 8 V~16 V

Working current:

Working current: <10A@13.5VQuiescent current: <1mA@13.5V


Electrical protection:

- ◆ Overvoltage protection: ECU can withstand 24V overvoltage for 60 seconds (ambient temperature is 23°C±5°C). If the system returns to normal operating voltage within 60 seconds, ECU can still ensure normal operation.
- ◆ System reverse voltage protection: If UBR (Pin15, 16) is powered by the main relay, the ECU can withstand a reverse voltage of 14.0 V for 60 seconds (ambient temperature is 23°C ±5°C, other connections are correct),if the system recovers to normal operating voltage within 60 seconds, the ECU can still ensure normal operation.
- ◆ Output level protection: The controller driver level has diagnostic protection functions, such as short-circuit to ground, short-circuit to power supply, and open circuit.

Fault diagnosis

The ECU can call out the fault information record in the ECU, or manually input some instructions such as clearing the fault information record, self-learning, etc.when the ECU has a fault, the engine will generally fail to start, the actuator does not work, etc. The ECU fault check mainly checks whether the connectors are well connected and whether the pins are bent or deformed.

ECU pin definition




Item	Name	Item	Name
1	CAN1H CAN (HIGH)	25	BRAKE LIGHT
2	NC	26	NC
3	NC	27	NEUTRAL SWITCH SIGNAL
4	NC	28	NC
5	MAIN RELAY	29	REVERSE GEAR SWITCH
6	FOUR-WHEEL DRIVE SWITCH	30	ACCELERATOR PEDAL SENSOR2
7	GROUND FOR PEDAL 1	31	NC
8	NC	32	NC
9	CRUISE CONTROL INPUT	33	NC
10	NC	34	NC
11	SAFETY BELT SWITCH	35	IGNITION SWITCH
12	INTAKE MANIFOLD PRESSURE2	36	SENSOR SUPPLY FOR PEDAL 2
13	NC	37	SENSOR SUPPLY FOR PEDAL 1
14	THRUST AUGMENTATION SWITCH	38	NC
15	SWITCHED BATTERY VOLTAGE	39	NC
16	SWITCHED BATTERY VOLTAGE	40	NC
17	CAN1L CAN (LOW)	41	FUEL PUMP RELAY
18	NC	42	HEAD LAMP RELAY
19	REGULATED SENSOR SUPPLY 5V	43	GROUND FOR LAMBDA
20	CONTINOUS SUPPLY VOLTAGE	44	NC
21	LAMBDA SENSOR2	45	ACCELERATOR PEDAL SENSOR1
22	NC	46	NC
23	BRAKE SWITCH	47	GROND FOR ANALOG
24	LOW SPEED SWITCH	48	LAMBDA SENSOR HEATING2

Item	Name	Item	Name
49	NC	82	MIL FUNCTION INDICATOR LAMP
50	NC	83	NC
51	NC	84	GROUND FOR SENSOR
52	NC	85	GROUND FOR MANIFOLD
53	NC	86	GROUND FOR THROTTLE
54	NC	87	THROTTLE ACTUATOR
55	NC	88	NC
56	FAN RELAY CONTROL	89	NC
57	NC	90	NC
58	CRANK RELAY	91	INTAKE MANIFOLD PRESSURE1
59	GROUND FOR PEDAL2	92	NC
60	NC	93	NC
61	NC	94	CANISTER PURGE VALVE
62	NC	95	NC
63	ECU MAIN GROUND 2	96	ENGINE SPEED SENSOR A
64	ECU MAIN GROUND 1	97	ENGINE SPEED SENSOR B
65	NC	98	NC
66	NC	99	IGNITION COIL2
67	NC	100	IGNITION COIL2
68	INJECTOR1(CYL.1)	101	ENGINE COOLANT TEMP SENSOR
69	NC	102	INTAKE AIR TEMPERATURE SENSOR1
70	NC	103	NC
71	SECOND AIR SOLENOID	104	LAMBDA SENSOR1
72	INJECTOR2(CYL.2)	105	NC
73	LAMBDA SENSOR HEATING1	106	PARKING SWITCH P
74	NC	107	SENSOR SUPPLY FOR THROTTLE
75	THROTTLE ACTUATOR	108	NC
76	NC	109	SENSOR SUPPLY FOR MAINFOLD
77	THROTTLE POSITION SENSOR 1	110	NC
78	THROTTLE POSITION SENSOR 2	111	ECU MAIN GROUND 4
79	NC	112	ECU MAIN GROUND 4
80	GROUND FOR LAMBDA		
81	NC		

FUEL INJECTOR

The fuel injector provides fuel to the engine and atomizes it within a specified time according to the instruction of the ECU.

The fuel injector (see A in the figure below) is installed on the electronic throttle body, and the other end is connected to the fuel pipe through the injector rail (see B in the figure below).



working principle


The ECU sends out electrical pulse signals to the injector coil to form a magnetic field force. When the magnetic field force rises enough to overcome the combined force of the return spring pressure, the needle valve's gravity and the friction force, the needle valve begins to rise and the fuel injection process begins. The maximum lift of the needle valve does not exceed 0.1mm. When the fuel injection pulse is cut off, the pressure of the return spring causes the needle valve to close again.

Performance p	parameter
---------------	-----------

project	parameter
Static flow	207.8g/min
Dynamic flow	6.65mg/stroke(冲程)
Jet angle	23°
Coil resistance	12Ω
Hydraulic leak	1.8mm³/min

Fault diagnosis


ECU only performs fault diagnosis for the fuel injector drive stage. When the fuel injector drive stage is short-circuited or overloaded to the battery voltage, short-circuited to the ground, or disconnected, the fault flag is set. When the injector fails, the engine cannot start without the injector or the injector keeps injecting fuel, causing the cylinder to flood, etc. The common fault codes are shown in the fault summary table.



- ◆ Check that the connectors are well connected.
- Check whether the wiring harness and injector pins are bent or deformed.
- ◆ Check whether the fuel injector cap (at 【C】 in the left picture) and the fuel pipe are reliably connected.
- ◆ Unplug the connector and check the coil resistance between pins 【A】 and 【B】.
- Check the resistance between the pins (【A】 on the left) and the main relay.
- Check the resistance between the pins (B in the left picture) and the ECU pins (see ECU pin definition).



When removing the oil pipe, there is high-pressure oil in the oil pipe, pay attention to fire safety and be careful to spray it into your eyes.



IGNITION COILS

The ignition coil converts the low-voltage electricity of the primary winding into the high-voltage electricity of the secondary winding, and generates sparks through the discharge of the spark plug to ignite the fuel-air mixture in the gas cylinder.

The ignition coil is installed on the engine, and the ignition coil installed on the engine can be seen after disassembling the cargo box (see A in the figure below).




Working principle

The ignition coil is composed of a primary winding, a secondary winding, an iron core, and a shell. When the voltage of the battery is applied to the primary winding, the primary winding is charged. Once the ECU cuts off the primary winding loop, the charging is stopped, and high-voltage electricity is induced in the secondary winding at the same time.


There are three pins on the low voltage side of the ignition coil:

- ◆ PIN 1: Connect to ECU control signal
- PIN 2: The pin is grounded
- ◆ PIN 3: Connect to the positive pole of the battery



Performance parameters

Item		Value			11:4
		Min	Rated	Max	Unit
Calibration vo	oltage	/	14	/	V
Operating vo	ltage	6	14	16.5	V
Resistance	Primary winding	466	530	593	mΩ
(2025°C	Secondary winding	8.27	9.4	10.53	kΩ
Primary current (Charging time 3.9ms)		7.4	8.0	8.6	А
Secondary voltage (Load 35pF)		34	/	/	kV
lgnition energy (Zener voltage 1000V)		40	/	/	mJ



Fault diagnosis


The ECU does not perform the fault diagnosis function for the ignition coil, so there is no ignition coil related code in the fault code list. If there is no ignition, please check whether the ignition coil connector is well connected, whether the pins are deformed, and whether the ignition coil wire and the spark plug are in good contact.

⚠ WARNING

If the spark plug wire (point [A] in the left picture) is installed incorrectly, it will cause the engine to shut down.

SPARK PLUG

The spark plug introduces the pulsed high voltage electricity generated by the ignition coil into the combustion chamber, and uses the electric spark generated by the electrode to ignite the mixture to complete the combustion. The spark plug sample diagram (see the figure below).



▲ WARNING

If the spark plug gap (point [A] in the left picture) is outside the range of 0.8±0.1, it will lead to unreliable ignition or failure to ignite. Please adjust the gap or replace the spark plug in time.

Remove and install spark plugs

- ◆ Remove the ignition coil.
- Use the spark plug sleeve to remove the spark plug.
- ◆ Take out the spark plug and check the state of the spark plug.
- If there is no problem, please replace with a new spark plug.

Spark plug torque

15N·m (1.5kgf·m, 11.1ft·lb)

▲ CAUTION

In the process of disassembly and installation, be careful not to hit the spark plug against any hard objects such as the engine block. If so, please replace with new spark plugs in time.




ENGINE SPEED SENSOR

The working principle of the speed sensor is to use the magnetoelectric effect. When the shaft rotates, the signal wheel is driven to rotate together, and the teeth on the signal wheel will cut the magnetic line of the sensor. This change in magnetic flux causes a certain frequency at both ends of the sensor coil. The output voltage is output to the electronic controller, and the output signal can represent the crankshaft speed and position (see A in the figure below).

Technical performance test

The speed sensor outputs a sinusoidal voltage signal, and the output signal (see 【B】 on the left).

Coil resistance (23 $^{\circ}$ C) : 950-20 Ω Coil inductance (1000HZ) : 450±15 mH



Fault diagnosis

- When the engine cannot be started, the remaining fault points have been eliminated. Use a multimeter to test whether the coil resistance of the speed sensor is the resistance required by the technical performance.
- ◆ If the resistance value is normal, please use an oscilloscope to check whether the voltage signal output by the sensor is as shown in the figure (B in the left figure).


▲ CAUTION

When the two pins of the sensor are connected reversely, the first gear signal after the missing gear in the output voltage signal is negative, which will cause the engine to be turbulent, idling unstable or unable to start.

ELECTRONIC THROTTLE VALVE BODY ASSEMBLY

The electronic throttle valve body assembly is connected to the engine and the air filter, and the electronic throttle body is installed in the intake system of the engine.the air flow into the cylinder is controlled by adjusting the angle of the throttle valve plate.its main function is to adjust the opening and closing angle of the throttle valve plate according to the driver's driving intention to meet the intake demand of the engine under different operating conditions. At the same time, it feeds back the position signal of the throttle valve plate to the control unit for precise control the valve body assembly includes: throttle valve body, fuel injector, fuel rail assembly, pressure and temperature sensor, throttle position sensor, throttle actuator, etc.

Open the cargo box to see the electronic throttle valve body assembly (see A in the figure below).



▲ CAUTION


After the electronic throttle body is installed, you must make sure to perform a throttle body self-learning. After the self-learning is completed, start the vehicle and observe whether it works normally.

Disassembly requirements

- ◆ It is strictly forbidden to disassemble the charged electronic throttle body.
- ◆ The electronic throttle body can be disassembled after the vehicle is cooled to room temperature to prevent the black cover and connectors from being wetted by the overheated antifreeze liquid.
- ◆ During the disassembly process, disassemble the mounting bolts diagonally, with even force, not to damage the upper and lower mounting surfaces, and at the same time ensure that the electronic throttle body does not fall or hit.
- ◆ The force of the return spring inside the electronic throttle body is relatively large. Be careful to hurt your hands when pushing the valve plate gently.

WARNING

It is forbidden to collide with the electronic throttle body during maintenance, and it is forbidden to use the electronic throttle body after it has fallen.



INLET PRESSURE TEMPERATURE SENSOR

The intake air pressure and temperature sensors include: intake air pressure and intake air temperature sensors.

The pin diagram is shown at 【A】 in the left figure.

- 1: Inlet pressure signal output OUTPUT SIGNAL
- 2: Supply voltage SUPPLY VOLTAGE
- 3: Thermistor NTC
- 3: Sensor ground GROUND

The core of the intake air temperature sensor is the thermistor that reacts quickly to temperature.


The intake pressure sensor passes through the air pressure channel on the throttle body and the main throttle body.

The channels are connected together to detect the absolute pressure of the intake air. When the pressure in the main channel changes, the output voltage of the pressure chip will also change accordingly. Through the corresponding relationship between the output voltage and the absolute pressure of the main channel, the ECU can obtain the absolute pressure value of the main channel at this time.


▲ CAUTION

When disassembling the intake air pressure and temperature sensor, to ensure that there is no condensed water on the pressure sensitive element, it is forbidden to use high-pressure gas to impinge on the vacuum element during the maintenance process.

Three-in-one sensor performance characteristics



Intake temperature sensor		
R25	2kΩ±3%	
B25/85	3520k±2%	
Temperature-resistance characteristics	See the left picture	



Intake pressure sensor		
Change sensitivity	40.5mv/kPa	
Output voltage characteristic	See the left picture	

Fault diagnosis


ECU monitors various sensors, actuators, power amplifier circuits and detection circuits. When the intake pressure is faulty, the engine may not be able to start or it may be difficult to start. The common fault codes are shown in the fault summary table.

Inlet pressure temperature sensor failure check:

- ◆ Check that the connectors are well connected.
- ◆ Check whether the wiring harness and sensor pins are bent or deformed.
- ◆ Check the continuity of each pin.

THROTTLE POSITION SENSOR AND THROTTLE ACTUATOR

The throttle position sensor is a Hall sensor with a linear output, pass **[**A**]** voltage of 5V is applied to both ends of the sensor to form a Hall voltage when the throttle rotates Output, like an Angle potentiometer.




The throttle actuator and sensor are mounted on the throttle body (see figure B on left).

Definition of its stitches:

1: actuator motor + 2: actuator motor -

3: sensor ground4: throttle position signal 25: sensor power supply6: throttle position signal 1



Throttle Position Sensor Performance Characteristics

Throttle Position Sensor		
Linearity	see left picture	
Working Temperature	-30°C+110°C	


Throttle actuator (DC motor) technical performance parameters

- 1. electronic throttle body connector on the motor PIN between the (room temperature) resistance name Mean value R = $1.4\Omega\pm0.3$.
- 2. Inductance L=1.1± 0.1MH3 at 1KHz (room temperature), working in the opposite direction the allowable force on: < 200 N.
- Maximum continuous power loss P = 8 W at ambient temperature T=100°C, The maximum allowable reversal current I is less than or equal to 10 A during reversal.

4. Minimum working voltage: 8V

5. rated working voltage: 12V

6. overload working voltage: 17V




Fault diagnosis

ECU for a variety of sensors, actuators, and power amplifier and detection circuits. To monitor when the throttle position signal has a fault, the engine may not have. If the method is started or the startup is difficult, the common fault codes can be seen in the General Table of Fault Codes.

Fault inspection of throttle position sensor and actuator:

- Check that the connector is well connected.
- ◆ Check whether the wire harness and sensor pins are bent and deformed.
- ◆ Check the opening and breaking of all stitches (see the definition of stitches in Figure A on the left).
- Check whether the supply voltage of pin 5 sensor is 5V.
- ◆ Check whether pin 1 voltage is 12V.



(B) (C) (D) (E) (F)

ELECTRONIC ACCELERATOR PEDAL

Electronic accelerator pedal connector pin definition:

【A】: 5V power supply for accelerator pedal 2

【B】: 5V power supply of accelerator pedal 1

[C] : accelerator pedal 1 ground wire

【D】: Acceleration pedal sensor 1

[E]: Acceleration pedal 2 ground wire

[F]: Acceleration pedal sensor 2




Remove and install the accelerator pedal

- Unplug the wire harness connector and remove 3 self-locking bolts with the nail sleeve (see figure B on the left).
- ◆ The fastening torque of the mounting bolt of the accelerator pedal module should be less than 10Nm, recommended value 8Nm(M6), connect the harness connector.
- ◆ Impurity must be prevented during and after the installation of the accelerator pedal module quality entry, otherwise may predamage the throttle pedal module function.

⚠ WARNING

The accelerator pedal module must be installed and fixed in accordance with the drawings.Don't Allow to use the accelerator pedal module to support other parts, do not allow to disassemble any parts.



Technical performance parameters

- Permissible pedal pressure in the working direction:
 500 N (400N①).
- Allowable force perpendicular to the rotation plane: < 200 N
- Allowable force in the opposite direction of work: <
 200 N.
- 4. The spring reset time at -40°C : ≤ 3 s②.
- 5. The spring reset time at -18°C : \leq 1 s2.
- 6. Minimum pedal rebound force: ≥ 5N.
- ① 400N is suitable for projects with external mechanical stops.
- ② To ensure that one of the two springs can meet the requirements.
- 7. Electric-displacement characteristics of electronic accelerator pedal (see A in the left figure)

Working conditions:

Permissible operating temperature: -40°C ~+85°C.

Storage condition: dust-free.


Temperature: -30°C ~ +60°C.

Fault diagnosis

ECU for a variety of sensors, actuators, and power amplifier and detection circuits monitoring, when the electronic accelerator pedal has a fault, the vehicle may not exist method acceleration, abnormal engine speed and other phenomena, commonly used fault code see the total fault table:

Electronic accelerator pedal fault inspection:

- ◆ Check that the connector is well connected
- Check whether the wire harness and accelerator pedal pins are bent and deformed
- ◆ Measure the voltage of pin 1 and pin 2
- ◆ Measure the voltage of pin 4 and pin 6
- ◆ Measure the on-off of all stitching wire harness ends



Fault code reading

There is **[**A**]** fault indicator light in the meter (Fig. **[**A**]** on the left). When the key switch is turned on.

Trouble indicator light is always on. When the engine is running, the vehicle electronically controls the fuel.

If there is no fault in the jet system, the indicator light should be extinguishedIndicator light in case of failure.

It should be on frequently to indicate a failure of the system.It can be shown in the meter (left figure 【B】).

Show the relevant fault codes, and query the specific fault letters through the fault code master table.



When the engine is running, the instrument fault indicator light is always on, indicating the existence of a system fault.

A system fault. Currently, the phase should be read using a dedicated fault diagnoser (lower left).

Should be the fault information. Use the OBD diagnostic interface corresponding to the vehicle diagnostic interface Connect and connect the other end of the device to the computer (the computer should be equipped with diagnostics.

Software and corresponding driver), the key switch should be in the open state.specific.

Operation steps:

- ◆ Connect the device, select "Open CAN", and press the "OK" button.
- Enter the main interface, you can check the engine operating parameters and fault message Interest rates.



A CAUTION

If the vehicle is on without the engine running, then the failure light will remain on. This is not an indication of failure and does not require attention.

SUMMARY OF FAILURE CODES


NO.	Pcode	Description (UAES)	fault indicator on
1	P0108 17	Manifold Absolute Pressure/Barometric Pressure Circuit High	√
2	P0107 16	Manifold Absolute Pressure/Barometric Pressure Circuit Low	√
3	P2A0D 17	Mass or Volume Air Flow "B" Circuit Low	√
4	P2A0C 16	Mass or Volume Air Flow "B" Circuit High	V
5	P0113 17	Intake Air Temperature Sensor 1 Circuit High	√
6	P0112 16	Intake Air Temperature Sensor 1 Circuit Low	V
7	P0118 17	Engine Coolant Temperature Sensor 1 Circuit High	√
8	P0117 16	Engine Coolant Temperature Sensor 1 Circuit Low	√
9	P0650 11	MIL Control Circuit Low	√
10	P0650 13	MIL Control Circuit Open	√
11	P0692 12	Fan 1 Control Circuit High	√
12	P0691 11	Fan 1 Control Circuit Low	√
13	P0480 13	Fan 1 Control Circuit	√
14	P0629 12	Fuel Pump "A" Control Circuit High	√
15	P0628 11	Fuel Pump "A" Control Circuit Low	√
16	P0627 13	Fuel Pump "A" Control Circuit /Open	√
17	P0459 12	Evaporative Emission System Purge Control Valve Circuit High	√
18	P0458 11	Evaporative Emission System Purge Control Valve Circuit Low	√
19	P0444 13	Evaporative Emission System Purge Control Valve Circuit Open	√

20	P0412 12	Secondary Air Injection System Switching Valve "A" Circuit	\checkmark
21	P0414 11	Secondary Air Injection System Switching Valve "A" Circuit Shorted	\checkmark
22	P0413 13	Secondary Air Injection System Switching Valve "A" Circuit Open	\checkmark
23	P0262 12	Cylinder 1 Injector Circuit High	√
24	P0261 11	Cylinder 1 Injector Circuit Low	√
25	P0201 13	Injector Circuit/Open – Cylinder 1	√
26	P0265 12	Cylinder 2 Injector Circuit High	√
27	P0264 11	Cylinder 2 Injector Circuit Low	√
28	P0202 13	Injector Circuit/Open – Cylinder 2	√
29	P0563 17	System Voltage High	√
30	P0562 16	System Voltage Low	√
31	P0560 1C	System Voltage Not plausible	√
32	P0501 29	Vehicle Speed Sensor "A" Range/Performance	√
33	P0641 00	Sensor Reference Voltage "A" Circuit/Open	√
34	P0651 00	Sensor Reference Voltage "B" Circuit/Open	√
35	P0571 29	Brake Switch "A" Circuit	√
36	P0571 1C	Brake Switch "A" Circuit	V
37	P0123 17	Throttle/Pedal Position Sensor/Switch "A" Circuit High	V
38	P0122 16	Throttle/Pedal Position Sensor/Switch "A" Circuit Low	V
39	P0121 29	Throttle/Pedal Position Sensor/Switch "A" Circuit Range/Performance	V
40	P0223 17	Throttle/Pedal Position Sensor/Switch "B" Circuit High	V
	•	•	

	_		
41	P0222 16	Throttle/Pedal Position Sensor/Switch "B" Circuit Low	V
42	P0221 29	Throttle/Pedal Position Sensor/Switch "B" Circuit Range/Performance	V
43	P2106 12	Throttle Actuator Control System Forced Limited Power	V
44	P2106 19	Throttle Actuator Control System Forced Limited Power	V
45	P2106 92	Throttle Actuator Control System Forced Limited Power	V
46	P2106 13	Throttle Actuator Control System Forced Limited Power	V
47	P1568 00	Idle Speed Contr.Throttle Pos. mechanical Malfunction	V
48	P1545 00	Throttle Pos.Contr. Malfunction	V
49	P1545 22	Throttle Pos.Contr. Malfunction	V
50	P1545 21	Throttle Pos.Contr. Malfunction	V
51	P1565 00	Idle Speed Control Throttle Position lower limit not attained	V
52	P2123 17	Throttle/Pedal Position Sensor/Switch "D" Circuit High	V
53	P2122 16	Throttle/Pedal Position Sensor/Switch "D" Circuit Low	V
54	P2138 29	Throttle/Pedal Position Sensor/Switch "D"/"E" Voltage Correlation	V
55	P2128 17	Throttle/Pedal Position Sensor/Switch "E" Circuit High	V
56	P2127 16	Throttle/Pedal Position Sensor/Switch "E" Circuit Low	V
57	P0606 94	ECM/PCM Processor	V
58	P0606 92	ECM/PCM Processor	V
59	P2106 29	Throttle Actuator Control System Forced Limited Power	V
60	P0606 64	ECM/PCM Processor	V
61	P0606 61	ECM/PCM Processor	V

62	P 0 6 0 6 67	ECM/PCM Processor	V
63	P 0 6 0 6 1C	ECM/PCM Processor	V
64	P 0 6 0 6 55	ECM/PCM Processor	V
65	P 0 6 0 6 00	ECM/PCM Processor	V
66	P 0 6 0 6 62	ECM/PCM Processor	V
67	P 0 6 0 6 96	function monitoring: fault of ECU ADC - Null Load Test Pulse	\checkmark
68	P 0 6 0 6 97	function monitoring: fault of ECU ADC - test voltage	\checkmark
69	P 0 6 0 6 47	function monitoring:fault of ECU monitoring modul error	V
70	P 0 6 0 6 17	Reported OverVoltage of VDD5	V
71	P 0 6 0 6 16	Reported UnderVoltage of VDD5	V
72	P 0 6 0 6 49	Diagnostic fault check to report "WDA active"	√
73	P 0 6 0 6 48	Diagnostic fault check to report "WDA active" due to errors in query-/response communication	~
74	P 0 6 0 6 91	Diagnostic fault check to report "WDA active" due to overvoltage detection	\checkmark
75	P 0 0 3 2 12	O2 Sensor Heater Control Circuit High Bank 1 Sensor 1	\checkmark
76	P 0 0 3 1 11	O2 Sensor Heater Control Circuit Low Bank 1 Sensor 1	\checkmark
77	P 0 0 3 0 13	O2 Sensor Heater Control Circuit Bank 1 Sensor 1	V
78	P 0 1 3 2 17	O2 Sensor Circuit High Voltage Bank 1 Sensor 1	V
79	P 0 1 3 1 16	O2 Sensor Circuit Low Voltage Bank 1 Sensor 1	V
80	P 0 1 3 0 29	O2 Sensor Circuit Bank 1 Sensor 1	√
81	P 0 1 3 4 13	O2 Sensor Circuit No Activity Detected Bank 1 Sensor 1	√
82	P 0 0 5 2 12	O2 Sensor Heater Control Circuit High Bank 2 Sensor 1	V

83	P0051 11	O2 Sensor Heater Control Circuit Low Bank 2 Sensor 1	√
84	P0050 13	O2 Sensor Heater Control Circuit Bank 2 Sensor 2	√
85	P0152 17	O2 Sensor Circuit High Voltage Bank 2 Sensor 1	V
86	P0151 16	O2 Sensor Circuit Low Voltage Bank 2 Sensor 1	V
87	P0150 29	O2 Sensor Circuit Bank 2 Sensor 1	V
88	P0154 13	O2 Sensor Circuit No Activity Detected Bank 2 Sensor 1	V
89	U0073 88	Control Module Communication Bus Off	V
90	U0140 87	Lost Communication With Body Control Module	V
91	U0121 87	Lost Communication With Anti-Lock Brake System (ABS) Control Module	V
92	P0322 00	Crankshaft signal loss	V
93	U0155 87	Lost Communication With Instrument Panel Cluster (IPC) Control Module	V
94	U0198 87	Lost communication with TBOX	V
95	U0293 00	Lost Communication With Hybrid/EV Powertrain Control Module	V
96	P0688 16	ECM/PCM Power Relay Sense Circuit/Open	×
97	P0688 29	ECM/PCM Power Relay Sense Circuit/Open	×
98	P0650 12	MIL Control Circuit High	×
99	P2138 00	Throttle/Pedal Position Sensor/Switch "D"/"E" Voltage Correlation	×
100	P1559 00	Idle Speed Contr.Throttle Pos. Adaptation Malfunction	×
101	P1579 00	Idle Speed Contr.Throttle Pos. adaptation not started	×
102	P1564 00	Idle Speed Contr.Throttle Pos. Low Voltage During Adaptation	×
103	P1559 29	Idle Speed Contr.Throttle Pos. Adaptation Malfunction	×
	•		







▲ CAUTION


The method of disassembling the EPS motor [B] refers to the method of disassembling the steering assembly. Only the electrical functions of the EPS controller [A] are introduced here.

- ◆ The steps to disassemble the EPS controller are as follows:
- ◆ First, remove the bolt 【E】, and remove the EPS controller 【A】 and bracket 【D】 from the frame
 【C】 together
- ◆ Then remove the bolt [F] and remove the bracket【D】











EPS system wiring schematic diagram



- 1. Battery
- 2. Fuse50A
- 3. Fuse 40A
- 4. Fuse 5A
- 5. Fuse 5A

- 6. IG relay 11.Motor
- 7. Diode
- 8. Key switch
- 9. OBD
- 10. EPS




EPS trouble removal

→ TROUBLE SHOOTING


If the EPS is not working, first check whether the EPS fault light [E] on the meter is on. If the fault light is not on, check whether the 5A fuse [A] and 50A fuse [B] in the fuse box are blown, and check whether there is engine speed on the meter [C] display, if there is no engine speed display, EPS will not work, and the EPS fault light on the meter will not light up.

◆ The position of EPS gear in the meter, EPS is divided into three gears: H/M/L【D】, the default is M gear, when in four wheel drive locking mode(四驱开关【G】按下), it will immediately switch to H gear; M gear and L gear are adjusted on the mobile phone APP (only vehicles with TBOX can be adjusted)



If the EPS fault light on the meter is on, it means that the EPS is malfunctioning.


- ◆ EPS fault light 【E】 and fault code 【F】 in the indicator
- ◆ The location is shown left.



EPS fault code

NO.	Fault description	Fault rank	Have EPS or not	Power on then restorability or not	Fault code	Trouble light
1	Torque midpoint not written	3	Yes	Yes	E0001	on
2	End of rotor angle is not written	1	No	No	E0002	off
3	Storage read and write failure	1	Yes	Yes	E0003	on
4	The main torque sensor is disconnected	1	No	No	E0004	on
5	The main torque sensor output is abnormal	1	No	No	E0005	on
6	The secondary torque sensor is disconnected	1	No	No	E0006	on
7	Secondary torque sensor output failure	1	No	No	E0007	on
8	The main and auxiliary torque differ too much	1	No	No	E0008	on
9	differenc of the main torque is too large before and after amplification	1	No	No	E0009	on
10	motor offer no assistant power	1	No	No	E0010	on
11	overcurrent	1	No	No	E0011	on
12	Abnormal current	1	No	No	E0012	on
13	CAN communication abnormal	2	Set the vehicle speed to 30, cancel the positive and damping	restorability after normal CAN	E0013	on
14	Rotor angle jump (abnormal output)	1	No	No	E0014	off
15	Rotor angle sensor disconnected	1	No	No	E0015	on
16	Power module failure	1	No	No	E0016	on
17	A phase current abnormal	1	No	No	E0017	on
18	C phase current abnormal	1	No	No	E0018	on
19	Steering wheel angle small teeth abnormal	2	No returnability	No	E0019	No
20	Steering wheel angle middle teeth abnormal	2	No returnability	No	E0020	off
21	Steering wheel angle jump	2	No returnability	No	E0021	off
22	The steering wheel angle value exceeds the limit	2	No returnability	No	E0022	off
23	Steering wheel angle is not centered	2	No returnability	No	E0023	off
24	Motor terminal voltage is abnormal	1	No	No	E0024	off

DISPLAY AND HUMAN-COMPUTER INTERACTION ASSEMBLY




No.	Fastener		Tor	Remarks	
140.	i asteriei	N·m	kgf∙m	ft·lb	remarks
1	INSTRUMENT COMBINATION				
2	HEXAGON SOCKET LARGE PAN HEAD BOLT M6×16	4~5	0.4~0.5	35.4∼44.2in.lb	
3	CROSS RECESSED HEXAGON SCREW ST4.8×16	4 ∼5	0.4~0.5	35.4∼44.2in.lb	
4	INSTRUMENT CONTROL MODULE				

Instrumentation

The dashboard displays key information to the user. See next page for display features and instructions

▲ WARNING

The use of a high-pressure water gun may damage the meter. The vehicle should be cleaned with neutral soap, either by hand or through a hose. Do not use alcohol or corrosive detergents, such as insect repellent, to clean your meter.



No.	Item	Function description	Fault phenomenon	Fault cause analysis and solution method
1	Engine speed	shows the real-time engine speed, ECU message is read through CAN	Engine speed is not displayed Or showing an exception	 Check the CNA-H,CAN-L wiring harness Unresolved check ECU Check the crankshaft position sensor
2	Speed display	displays the current real-time speed	Powering with APP Bluetooth After the instrument did not display the figure mark	 ◆ Check the meter CAN-H,CAN-L lines beam ◆ Unsolved, change TBox ◆ Unsolved, change instrument

3	Fuel quantity indicator	shows the current oil quantity fuel	油量不显示	 Check the CNA-H,CAN-L wiring harness Check oil level according to electrical schematic diagram line Replace the instrument control module
4	Coolant temperature indicator	Displays current coolant temperature H -High temperature C -Low temperature	Water temperature not displayed	 Check the CNA-H,CAN-L wiring harness Check the water temperature sensor and related lines beam Replace the ECU
5	Time	display Current time	display Inaccurate	check TBox
6	Submeter mileage	shows submeter mileage		
7	Engine running	Engine running time is not correct	Check meter engine running time	 ◆ Whether or not shown ◆ If displayed, replace the instrument of you don't, Display the reference engine speed not, Display inspection items
8	Dynamic Residual Mileage	Display Dynamic Residual Mileage	not display	Check CNA-H,CAN-L wiring harness Replacement of TBox is not resolved
9	Fault code display	When the vehicle is equipped with CAN electrical parts When a failure occurs in this area Display fault code		
10	Vehicle voltage	shows current vehicle battery power pressure		
11	Total mileage	Displays the total mileage accumulated by the vehicle		

project	Diagram	diagram function	describes the fault phenomenon	fault cause analysis and solution
Left turn Indicator	4	This light when left turn signal is turned on Light up	With the turn signal on the indicator light is not on	Check left turn to the lamp protection wire, check PIN16 is a high level input, if Yes, replace meter, if not, check phase close the circuit
High beam indicates		this light point when the high beam is turned on bright	With the high beams on the indicator light is not on	Check the remote light switch off circuit, check whether PIN10 has a high level input, if Yes, replace meter, if not, check phase close the circuit
Position indicator	₹DQ €	Front light, rear light, license plate Lamp and instrument panel headlight This lamp lights when it is turned on	With the position light on The indicator light is not on	Check the switch circuit of the position lamp, check whether PIN11 has a high level input, if Yes, replace meter, if not, check phase close the circuit
Failure light	Õ	When the fault indicator light is on The following systems are failing: • Emission control system • Electrical control system of engine		
Oil pressure	1	This lamp is used when oil pressure is too low Light up	If the meter misreports the oil pressure alarm lamp	Check the oil pressure sensor
off cushion alarm	OPC	Leaving your seat without pulling up parking switches ,this lamp on and Accompanied by buzzer alarm	Leave your seat unlifted parking switch, OPC The alarm light isn't working, Hummy,The buzzer didn't go off	Check the parking switch signal
Right turn indication		This light point when the right turn signal is turned on bright	Turn right signal on rear instrument indicator light No bright	Check the right turn signal fuse, check is there a high level input for PIN15, If so, replace the meter. If not, Check related wiring
Gear display Gear display	a 8 E F	Gear display Gear display	Gear display is not correct or the gear position is not displayed	 Check the gear related wiring harness Replace the instrument control module Replace the gear sensor

The braking system Warning lights		Low brake fluid level Failure of braking system		
EPS System warning light	Θ!	Indicates that the EPS system has a fault (Optional equipment, if equippeda)		
"ABS" Warning lights	(ABS)	ABS Indicates a failure of the following system: ◆ ABS ◆ Brake Assist System (Optional equipment, if equippeda)		
Coolant high temperature Warning lights		Displays engine coolant temperature high indicator light, this lamp point when the alarm lights on, stop immediately turn off the engine and allow to cool Continue to normal temperature drive		
Seat belt light	Ä	Not tied while the vehicle is in motion Safety belt alarm	Not tied while driving seat belts, but gauges there is no alarm	 Check the safety belt switch Check the gauge to see if the speed is normal
Parking instructions	(P)	After using the parking brake this light point bright	When the parking switch is pulled up, Instrument parking indicator light No bright	Check whether PIN10 has low power flat input, if so, replace the instrument Table, if not, check the correlation wiring, wiring harness whether loose or The fracture
The bluetooth indicator	*	When the mobile APP successfully connects Display this icon when TBox bluetooth	Use the APP Bluetooth to power it rear meter does not display icon	Check the instrument CAN- H,CAN-L wiring harness ◆ Unsolved, change TBox ◆ Unsolved, change instrument

Technical parameters

Working voltage range: DC 8V-18V

◆ Maximum resistance voltage: DC 24V < 60 seconds

◆ Static current: less than 1mA

◆ General current consumption: 120mA + 20mA

◆ Maximum current consumption: 175mA±20mA


◆ Storage temperature- 30 °C to + 80 °C

◆ Working temperature: -20°C -+ 70°C


Meter dismantling


▲ CAUTION

Before disassembling the instrument, be sure to the vehicle is power off.




- Unplug the connector on the back of the instrument
- ◆ Remove the two bolts 【B】, remove the plastic part【C】, and replace with a new instrument






PIN	Description	Note	PIN	Description	Note
1			10	high beam level	high level
2			11	position lamp	high level
3	OPC Cushion Switch	low level	12		
4	Parking	low level	13	Engine failure light	low level
5	key power		14	buzzer alarm output	low level
6	voltage		15	right turn	high level
7	ground		16	left turn	high level
8	Speed	pulse signal	17	CANL	
9			18	CAN-H	

CENTRAL CONTROL DISPLAY



No.	PART'S NAME	Torque		Domorko	
NO.	PARTS NAIVIE	N·m	kgf∙m	ft·lb	Remarks
1	Central control display				
2	Instrument desk				
3	Hexagon socket flat head screw M6×12				



▲ CAUTION

Before disassembling the central control, be sure to the vehicle is power off.

Disassembly and installation of central control

- ◆ Power off the whole vehicle first;
- Remove related plastic parts;
- Unplug the central control connector;
- ◆ Remove the four bolts 【C】

pin	Illustrate	Remarks
1	BAT+	Battery electric
2	GND	GND body grounding
3	ACC	key electricity
4	ANT-VCC reserved	
5	USB1-VCC	
6	USB1-DM	
7	USB1-DP	
8	USB1-GND	
9	CVBS-GND reserved	
10	CVBS-IN reserved	
11	CVBS-VCC reserved	
12	CAN1-L	
13	CAN2-L reserved	
14	USB2-VCC reserved	
15	USB2-DP reserved	
16	RCA-RL reserved	
17	RCA-RR reserved	
18	RCA-GND reserved	
19	CAN1-H	
20	CAN2-H reserved	
21	LIN Key	

Function introduced

- ♦ 10.4 inch ultra clear color screen touch
- ◆ Local audio playback
- ◆ Bluetooth music, phone
- ◆ Mixer FM/AM
- ◆ Dual USB interface
- ◆ Customized map
- ♦ Mixer V2V team
- ◆ Mixer DMR intercom
- ♦ Bluetooth headset adaption
- ♦ Body information display
- ◆ Vehicle parameter display and control

Performance parameter

No.	Items	Description	
1	Rated voltage	DC12V	
2	Working voltage	DC 9-16V	
3	Dark current (i.e. standby)	ACC OFF:≤3mA	Turn off ACC for about 1 hour and enter standby mode
4	Sleeping current	ACC OFF:≤10mA	Turn ACC into hibernation mode for about 30S
5	Peak current	5A	
6	Display Specifications	10.4寸	
7	Display resolution	1280 (H) *960 (V)	
8	USB interface communication protocol	USB2.0	
9	Working Humidity	10%-95%	normal temperature
10	Display working temperature	-30°C— +75°C	
11	Operating temperature of the main engine	-30°C— +85°C	
12	Storage temperature	-40°C— +95°C	

AM performance index


Test Item	Unit	
Test project	KHZ	531-1629KHz (AM1、AM2)步长9KHz
Frequency range	KHZ	450±5
Intermediate frequency	dΒμV	≤30
Finite noise sensitivity	dB	≥50
Manic ratio	dB	36±10
Automatic selection of station sensitivity	dB	≥45
Single signal selectivity	dB	≥60
Image reject	dB	≥60
Intermediate frequency suppression	dB	≤3
balance	dB	0— -3dB
Frequency characteristics	dB	≤1.0
Harmonic distortion	dB	≤1.0
Overload distortion	dB	≥45
-10dB Automatic Gain Control (AGC) (5mV input)		

FM performance index

Test Item	Unit			
Frequency range	KHZ	87.5-108MHz (FM1、FM2、FM3)步长 0.1MHz		
Intermediate frequency	KHZ	10.7±0.3		
Finite noise sensitivity (30dB S/N)	dB μ V	≤6		
Signal impetuous ratio (monophonic)	dB	≥55		
Static sensitivity	dB	≤20		
Stereo noise limit sensitivity (S/N=30dB)	dB	≤15		
Stereo noise limit sensitivity (S/N=50dB)	dB	≤26		
Stereo Signal to Noise Ratio (A weight)	dB	≥50		
Automatic selection station sensitivity dB 24±8	dB	24±8		
Double signal selectivity	dB	≥70(±400KHZ)		
Image reject	dB	≥70		
Intermediate frequency suppression	dB	≥70		
Am inhibition	dB	≥45		
balance	dB	≤15		
Stereo separation (A weight)	dB	≥22		
balance	dB	≤1		
Frequency characteristics (50uS pre-weighted)	dB	03		
-3dB limiting sensitivity	dB	≤15		

Fault diagnosis

Failure phenomenon	failure cause analysis		
The key switch turns on and the screen goes black	 Check whether the central control fuse is in good condition and the circuit is in good condition according to the electrical schematic diagram Check whether the central control connector is loose Check whether the central control power supply voltage is normal, if less than or equal to 7V or 18V, the screen will be black 		
The map cannot be loaded	 Check the location to see if there is an offline map downloaded in advance If you do not download the offline map, check whether the central control is connected to WiFi 		
The map cannot display the current position of the vehicle in real time.	 ◆ Check whether the central control PIN12 and PIN19 have signals ◆ If there is a signal, replace the TBOX 		
Radio can not search the radio	Check whether the radio antenna interface is loose		
When the radio works or the music works When, the external speaker or Bluetooth headset can not listen To the sound	 ◆ Check whether the external device is normal ◆ Reconnect the external device with Bluetooth 		



TBOX


▲ CAUTION

If more than one vehicle is maintained at the same time, do not replace and install the TBOX.

- Power off the whole vehicle first, and remove the relevant plastic parts;
- Unplug the connector;
- ◆ Remove the four bolts 【A】

⚠ WARNING

If you replace a new TBox, be sure to use the Segway APP-TBox replacement function for operation, so that the intelligent function can serve the customer properly. See the APP operation guide for the specific TBox replacement process.



PIN	Description	Note
1	GND	
2	MIgnition	Check whether the mechanical key is energized
3		
4	CAN1+	The body CAN +
5	CAN1-	The body CAN -
6	REALY_OUT	Remote power on relay interface
7	ACC	
8	CAN3+(Reserve)	
9	CAN2+	The engine CAN +
10	B+	Battery electric
11	OIL+	
12	OIL-	
13	CAN3-(Reserve)	
14	CAN2-	The engine CAN-


TBox fault code display area





T0001	GPS module failure
T0002	4G module failure
T0003	Bluetooth module failure
T0004	Sensor failure
T0005	Power CAN failure
T0006	Body CAN failure

Failure phenomena and causes			
NO.	Trouble phenomenon	solution	
1	when the meter appears T0001	Replace the TBOX	
2	when the meter appearsT0002	Replace the TBOX	
3	when the meter appearsT0003	Replace the TBOX	
4	when the meter appearsT0004	Replace the TBOX	
5	when the meter appearsT0005	check whether PIN9 and PIN14 have letters No.	
6	when the meter appearsT0006	check whether PIN4 and PIN5 have signal	
7	APP has no response after remote power on.	There is no problem after checking the relevant circuit after the replacement of TBOX	

WINCH ASSEBLY








▲ CAUTION


When removing the winch, first turn off the vehicle key.

The wireless control module is removed


- ◆ Remove external related plastic parts
- ◆ Remove the nut 【A】 from the terminal with a tool
- ◆ Remove the positive wire of the power cord 【B】
- ◆ Remove the bolt 【C】
- ◆ Remove the negative wire of the power cord 【D】




- ◆ Unplug the plug-in 【E】first
- ◆ Remove the bolt [F] with a tool




- ◆ Remove two nuts 【H】 with tools
- ◆ The motor wire 【J】 can be removed
- ◆ Cut off the wire tie, then the relay 【G】 can be removed




- Remove external related plastic parts
- First remove the self-tapping screw [A]
- Unplug the plug-in 【B】
- ◆ The winch wireless control module 【C】 can be removed






Removal of winch socket

- ◆ After removing the external related plastic parts
- First remove the self-tapping screw [A]
- ◆ Then unplug the plug-in 【B】
- ◆ The winch socket 【C】 can be removed




Winch motor position

◆ The winch motor 【A】 is located under the front of the car




Removal of winch motor

- First remove the bumper [D] and the three M8 bolts [C] on the top of the frame and on the left and right sides according to the disassembly and assembly sequence of plastic parts and body accessories.
- ◆ Remove one M8 nut 【B】 under the bumper
- ◆ The winch motor 【A】 and the front bumper 【D】 can be removed together



- ◆ Remove the four bolts [E] connecting the winch motor and the bumper
- ◆ Then remove the two nuts [F] at the positive and negative ends of the winch motor
- ♦ The winch motor 【A】 can be removed



- ◆ After disassembling the pin 【H】 and the wire rope, then you can remove the pull-down strap 【G】, hook【Ⅰ】, and rubber pad【J】
- ◆ Remove the bolt 【K】, and remove the guide wheel 【L】

Install winch motor

- ◆ The order of assembly and disassembly is reverse, install the winch motor and connect the cables:
- Then connect the battery.

▲ CAUTION

winch work shall not exceed 1min each time, and shall work after 30S interval

- Rated working voltage DC12V
- ◆ The maximum working tension is 3500LB,
- ◆ The maximum working current ≤ 1 8 5 A, the maximum working current lasts for 1 min, and works after an interval of 30 seconds, and continues to work in this way
- ◆ The diameter of the wire rope is 4.8, and the length of the wire rope is 14.5 meters

The color of the insulation pad of the winch motor terminal and the heat shrinkable tube of the cable is oneto-one correspondence

[A] YELLOW

[B] BLUE

[C] NUT

Torque of nut 【C】

4 N·m (0.4 kgf·m, 2.9ft·lbs)

NOTICE

The winch motor is a component that cannot be repaired. If the winch motor is faulty, the component must be replaced in time.

The color of the winch relay terminal corresponds to the color of the heat shrinkable tube of the cable one-to-one

[C] YELLOW


[D] BLACK


[E] RED

(F) BLUE

NOTICE

The winch relay is a component that cannot be repaired. If the winch relay is faulty, the component must be replaced in time.







Instructions for use of winch remote control switch:

- Press the 2 buttons at the same time and keep it there for 3S to activate the remote control switch, at this time the indicator light will flash 3 times
- You can press a button to control the rotation of the winch motor
- Press the 2 buttons at the same time and keep it for 3S, turn off the remote control switch, the indicator light will go out at this time



Instructions for use of winch switch:


◆ Insert the winch switch into the winch socket, then press the winch switch left and right, winch motor rotation can be controlled



Instructions for manual release switch of winch:

◆ Turn the manual release switch clockwise, then you can pull out the wire rope by hand. If you need to retract the wire rope, you must turn the manual release switch counterclockwise and use the switch to control the rotation of the motor to retract the wire rope.

SCHEMATIC DIAGRAM OF TRAILER SYSTEM



COLOUR

mparison table

R	R/B	R/W	R/G	R/Y	R/L	R/Br	R/O	
Red	Red/Black	Red/White	Red/Green	Red/Yellow	Red/Blue	Red/Brown	Red/Orange	
Р	В	B/R	B/W	B/Y	B/L	B/V	B/Br	
Pink	Black	Black/Red	Black/White	Black/Yellow	Black/Blue	Black/Violet	Black/Brown	
W	W/R	W/B	W/G	W/Y	W/L	W/V	W/Gr	
White	White/Red	White/Black	White/Green	White/Yellow	White/Blue	White/Violet	White/Gray	W
Gr	Gr/R	Gr/B	Gr/W	BR	Br/R	Br/B	Br/Y	
Gray	Gray/Red	Gray/Black	Gray/White	Brown	Brown/Red	Brown/Black	Brown/Yellow	
0	O/R	O/B	O/W	O/G	O/L	O/Gr		
Orange	Orange/Red	Orange/Black	Orange/White	Orange/Green	Orange/Blue	Orange/Gray		
G	G/R	G/B	G/W	G/Y	G/L	G/V	G/Br	
Green	Green/Red	Green/Black	Green/White	Green/Yellow	Green/Blue	Green/Violet	Green/Brown	
Y	Y/R	Y/B	Y/W	Y/G	Y/L	Y/Gr	Y/Br	
Yellow	Yellow/Red	Yellow/Black	Yellow/White	Yellow/Green	Yellow/Blue	Yellow/Gray	Yellow/Brown	
L	L/R	L/B	L/W	L/G	L/Y			
Blue	Blue/Red	Blue/Black	Blue/White	Blue/Green	Blue/Yellow			
V	V/R	V/B	V/W	V/G	V/L	V/Br	V/O	
Violet	Violet/Red	Violet/Black	Violet/White	Violet/Green	Violet/Blue	Violet/Brown	Violet/Orange	
Lg	Lg/R	Lg/G	Lg/Y	Lg/Br	Lg/P			
ight Green	Light Green/Red	Light Green/Green	Light Green/Yellow	Light Green/Brown	Light Green/Pink			
Sb	Sb/R	Sb/B	Sb/W	Sb/Gr				
Sky Blue	Sky Blue/Red	Sky Blue/Black	Sky Blue/White	Sky Blue/Gray				

ELECTRIC SCHEMATIC DIAGRAM

