




SEGWAY

SEGWAY AT6 ACCESSORIES INSTALLATION MANUAL



REAR CARGO BOX

REAR CARGO BOX




ITEM	PART NAME	PART NUMBER	QTY	REMARKS
1	AT10 REAR CARGO BOX	A12-H091000-000-00	1	
2	SELF-LOCKING MECHANISM	A02H18100001	4	
3	SCREWS M5×12	GBT000818004	16	
4	NUT M5	GBT061871001	16	
5	SPRING WASHER	—	16	
6	PLAIN WASHER	—	16	
7	REAR CARGO BOX COVER PANEL	A02-H102001-0B0-01	1	Suitable for vehicles with AT6 cargo box covers without mounting holes

REAR CARGO BOX


TIPS

This cargo box is only suitable for vehicles with four mounting holes on the shelf cover plate. If the cover plate lacks these holes, a new shelf cover plate must be replaced.




REAR STORAGE BOX INSTALLATION

1、 If the vehicle is equipped with passenger armrests, they must be removed first




2、 Remove the self-locking mechanism, rotate the handwheel on the self-locking mechanism, and turn the side marked with "△" to the "🔒" position



3、 Place the self-locking mechanism into the designated hole in the rear cargo compartment's bottom according to the specified orientation.


TIPS

Pay attention to the placement direction of the self-locking mechanism.




flat washers, spring washers, and nuts to secure the 4 self-locking mechanisms to the holes on the bottom of the rear cargo box.


- ① screw M5 x12 ② Flat washer
- ③ Spring washer ④ nut



5、 Place the rear cargo with the self-locking mechanism installed on the vehicle's rear rack, aligning the self-locking mechanism with the fixed position on the rack cover plate.



6、 Rotate the handle on the self-locking mechanism to position the side marked with "△" to the "🔒" position. Once all four self-locking mechanisms are fully secured, the rear cargo The box can be fixed on the shelf.



TIPS

After installation, check whether it is properly installed.